



CHORS Maxime R IN Recessed LED Light Instruction Manual

[Home](#) » [CHORS](#) » CHORS Maxime R IN Recessed LED Light Instruction Manual 

Contents

- [1 CHORS Maxime R IN Recessed LED Light](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 MOUNTING HOLES](#)
- [5 ELECTRICAL WIRING DIAGRAMS](#)
- [6 ASSEMBLY INSTRUCTIONS](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)

CHORS

CHORS Maxime R IN Recessed LED Light



Product Information

- **Product Name:** Maxime R IN 48.3114.xxx.xxx
- **Electrical Wiring Diagrams:** Schematy Podłączenia Elektrycznych

- **Light Source:** 1 x DC 350/700 mA, 230V 50Hz
- **Max. Output:** 3 x DC 350/700 mA, Max. 60 VDC
- **Manufacturer:** CHORS
- **Address:** Soltysowicka 19C, 51-168 Wrocław, Poland
- **Contact:** T: +48 71 323 14 00-01, W: CHORS.PL

Product Usage Instructions

1. Make sure the product is connected to a power source of 230V with a frequency of 50Hz.
2. Refer to the electrical wiring diagrams for proper installation and connection.
3. Ensure that the light source is connected to the product using a DC power supply of 350/700 mA.
4. The maximum output of the product is 3 x DC 350/700 mA with a maximum voltage of 60 VDC.
5. Position the product in the desired location and secure it properly.
6. Connect the necessary wires and ensure proper polarity (+/-) for correct functionality.
7. Refer to the user manual for any additional instructions or troubleshooting information.

MOUNTING HOLES




Maxime R IN 48.3114.xxx.xxx

Maxime R IN 48.3114.xxx.xxx

ELECTRICAL WIRING DIAGRAMS


1. 1 LIGHT SOURCE

48.31XX.IXX.XXX



2. MAX. 3 LIGHT SOURCES


48.31XX.IXX.XXX



MAX.3 X DC 350/700 MA, MAX. 60 VDC

3. MAX. 1 LIGHT SOURCE – SUNLIKE

48.31XX.GXX.XXX



1 X DC 350 MA, MAX. 60 VDC


ASSEMBLY INSTRUCTIONS

1. Turn off the power.


1



2. Cut the mounting hole (dimensions of mounting).



3. Connect a 350 or 700mA DC power supply depending on the light source (LED/SUNLIKE) (electrical wiring diagrams on the other side of the page).
4. Lift the springs.
5. Insert the lamp into the mounting hole. The springs will return to the original position and press the lamp against the ceiling, holding it.
6. Turn on the power.



SOŁTYSOWICKA 19C | 51-168 WROCŁAW | POLAND
 T: +48 71 323 14 00-01
 W: CHORS.PL

Documents / Resources

	<p>CHORS Maxime R IN Recessed LED Light [pdf] Instruction Manual 48.3114.xxx.xxx, Maxime R IN, Maxime R IN Recessed LED Light, Recessed LED Light, LED Light, Light</p>
--	--

References

- [Strona główna - Chors](#)