

# **CHOYONG LC90M Portable Multi Band Internet Radio User** Manual

Home » CHOYONG » CHOYONG LC90M Portable Multi Band Internet Radio User Manual



## **CHOYONG LC90M Portable Multi Band Internet Radio User Manual**


# **Contents**

- 1 Location of Controls:
- 2 Instructions for use:
  - 2.1 Getting started
  - 2.2 Charging battery
  - 2.3 Bluetooth playback
  - 2.4 Software Update
  - 2.5 Telescopic antenna assist Middle

Wave

- 2.6 Trouble Shooting:
- 2.7 Product Specification:
- 2.8 Important function tips:
- 3 Documents / Resources
  - 3.1 References
- **4 Related Posts**

## **Location of Controls:**



## 1. ON / OFF

Press 2 seconds to turn the radio ON/OFF, press 5 seconds till the white screen appeared to force restart the radio.

### 2. FM mode

A short press to enter FM mode.Press and hold 2 seconds to turn on FM ATS(Auto Searching and save) function.

## 3. MW mode / LW mode

First short press to enter MW mode. In MW mode, press and hold 2 seconds to turn on MW ATS(Auto Searching and save) function.

If the radio is in MW mode, another short press will enter LW(Long Wave)mode, press and hold 2 seconds to turn on LW ATS(Auto Searching and save) function.

#### 4. SW mode

A short press to enter SW mode.Press and hold 2 seconds to turn on SW ATS(Auto Searching and save) function.

### 5. Bluetooth mode

A short press to enter Bluetooth mode, the radio will work as a Bluetooth speaker.

### 6. TF card mode

A short press to enter TF card mode. The radio need to restart after the TF-Card inserted.

### 7. Tag button

Press this key to choose different internet radio stations by tag like POP/NEWS/ MUSIC/ ROCK...

#### 8. Menu button

Press Menu button to open the main menu.

## 9. Language mode

Press this key to choose different internet radio stations by language like German, French, English etc...



### Lock button

Press this key to lock the keypad and the knob, press again to unlock the keypad.



### **Favorited**

While playing, press this key to bookmark your favourite radio stations, When not playing press this key to view your favourite stations.



# Set UP

Press this key to enter the settings menu.

### 13. Confirm button

Press this button for confirm what you choose.



# 4. Music stations shortcut key

Press this key will present a list of internet radio stations labeled with music.

### 15. Podcast stations shortcut key

Press this key will present a list of internet radio stations labeled with podcast.

# 16. News stations shortcut key

Press this key will present a list of internet radio stations labeled with NEWS.



## Add / Edit stations

Press this key and follow the instructions you can add or edit the website of internet radio stations to local memory.

## 18. Number

By pressing these buttons, you can input the radio frequency, the password of Wi-Fi, and the numbers of the music in TF-Card for direct tuning.

### 19. VF / VM button

- 1. Switch Input Method when imputing Wi-Fi password.
- Switch the function of the tuning knob when working in regular radio mode, VF—Switching frequency, VM
  —Switching saved frequency.

## 20. Re tun button

Press this key back to Upper level.

# 21. Previous

Press this key to shift to previous Song/Channel.

# 22. Pause button

Press this key to Pause/Replay.

# 23. Next

Press this key to shift to next Song/Channel.

#### 24. TF card slot

After insert a TF-Card and restart the radio, you can play the music that you have prepared in TF-Card. Supports a maximum of 32 GB TF-Card.

You can copy music to TF-Card or delete music by connecting the radio to a computer.

## 25. SIM card slot

Support Nano Sim Card, you need to restart the radio after insert SIM-Card.

## 26. Tuning knob

- 1. In regular radio mode use for tuning frequency by steps(FM 100KHz,MW 9/10KHz,SW 5KHz);A short press during playing will turn on the meter-band selection interface.
- 2. In VM Mode use for switching saved frequency.
- 3. In internet radio mode use for switching internet radio stations.
- 4. A short press to confirm.
- 5. In main menu interface use to select and confirm

## 27. Volume control with switch

Turing to increase or decrease volume. Rotate counter-clockwise until hear a 'click' sound, the radio will enter sleep mode. Turn on the volume switch the machine will continue to play.

### Instructions for use:

## **Getting started**

LC90M is powered by a rechargeable lithium battery. A USB-Type-C cable is supplied in the package.

Press and hold the ( ) button to power on. To shutdown the radio, press and hold the same button.

## **Charging battery**

To charge the battery, connect the Type-C cable to 5V power adapter, you can use any mobile phone charger, the mobile quick charge protocol ensures that the output voltage of the charger will adjust to 5V when charging to radio, but **DO NOT USE THE CHARGER OF IPAD OR COMPUTER!** 

Note: The charging might take much longer to complete if the radio is playing while charging.

## Bluetooth playback

Press the BT ( $^{\mbox{*}}$ ) Key to make the radio enter Bluetooth mode.

Open your device's Bluetooth setting, and active the pairing mode, the device scans for Bluetooth devices. When the radio is found, your Bluetooth device shows its name "Chongqing-LC90M", sect the radio and connect it.

Then you can start playback on your Bluetooth device, you can control the playback by the radio(next, previous, pause... etc).

The connection will be restored automatically when both devices are in range and the radio in Bluetooth mode.

## **Software Update**

There may be software release to upgrade features of the radio from time to time. Check the update regularly to keep your radio up to date with the latest software.

Caution: Do not do any operation during the upgrade progress!!! Or the radio will be damaged!

# Telescopic antenna assist Middle Wave

An auxiliary middle wave receiving circuit is integrated in the radio, you can try to use telescopic antenna to increase the MW signal strength and to improve the performance of SNR, especially effective outdoors.

# **Trouble Shooting:**

Problem	Solutions	
Connect to the network successfully, but unable to play particular stations  The station is not broadcasting at this time of the day, remember in a different time zone. The station has too many people trying to tation server capacity is not large enough. The internet connection adio and the radio station server is too slow or unstable to support of broadcast. The link of the radio is out of the date, please contact estation list.		
The radio got freeze or no re sponse	Forced restart the radio,Press the ( ) and hold for 5 seconds until the radio res tarted (show white screen),then release the button.	
Can not connect to Wi-Fi net work	, , ,	
Insufficient Wi-Fi signal stre ngth	Check the distance to router,see if a computer/mobile phone can connect to the network in this location,if the signal is weak,please optimise the distance of the router's location.	

# **Product Specification:**

	Model: L0	C90M
	Colour: Spa	ace Gray
	Weight:	410g
	<b>Size</b> 160*39	9*95mm
FM	Frequency	64-108MHz
FIVI	Step	10KHz/100KHz
LW	Frequency	153-279KHz
LVV	Step	1KHz/9KHz
MW	Frequency	522-1710KHz
IVIVV	Step	1KHz/9KHz/10KHz
sw	Frequency	2300-26100KHz
3 <b>v</b> v	Step	1KHz/5KHz
	Speaker	5W
	Lithium Batter	<b>y</b> : 2500mAh
	Network: 4G Band supported: FDD Ba	and2/3/4/5/;TDD Band38/39/40/41.
	Bluetooth ve	ersion:5.2
	TF card: Maxin	num 32 GB
	Earphone: 3.	5mm jack


# Important function tips:

# How to connect Wi-Fi?

Press( ) button into the Wi-F setting page. Choose the Wi-Fi that you want to connect, then input the password. Use( VF/VM) to shift input method. (abc/ABC). you need to restart the radio to remember the password

# How to add internet radio website?

Press( )'Add radio',will come out a QR Code.Use any QR Scan app on your phone,then type the website you want to listen.



More details and operation tips,please check our instruction videos on You tube: <a href="https://www.youtube.com/@choyongradio">https://www.youtube.com/@choyongradio</a>

24 hour service Team please contact:

choyongradio@gmail.com

Official Website:

http://www.sz-chaoyuan.com

Portable Multi-Band Internet Radio LC90M



## **Documents / Resources**



<u>CHOYONG LC90M Portable Multi Band Internet Radio</u> [pdf] User Manual LC90M Portable Multi Band Internet Radio, LC90M, Portable Multi Band Internet Radio, Multi Band Internet Radio, Band Internet Radio, Internet Radio

# References

# • User Manual

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.