
Home » chuanqiang » chuanqiang CQ172 Wireless Keyboard User Manual

chuanqiang CQ172 Wireless Keyboard User Manual

Contents

- 1 Wireless keyboard user manual
 - 1.1 Bluetooth keyboard connection steps
 - 1.2 Keyboard shortcut function description
 - 1.3 Attention
 - 1.4 Energy saving sleep mode
 - 1.5 Charging
 - 1.6 IOS13 system touchpad gestures
 - 1.7 Troubleshooting
- 2 Documents / Resources
 - 2.1 References
- **3 Related Posts**

Wireless keyboard user manual



Bluetooth keyboard connection steps

1 .After the power switch is turned to the ON position, the power indicator light is on for 3 seconds, the Bluetooth indicator starts to flash, and the keyboard automatically enters the pairing mode.



2. Open and unlock your tablet and click on the "Settings" icon.





3.In the settings menu, click on the "Bluetooth" menu.



4. Turn on the Bluetooth switch, hen press the FN + C key on the keyboard, and the light flashes to start pairing;



5.Discover the Bluetooth keyboard device: Bluetooth Keyboard ***, and click on it, the Bluetooth keyboard will automatically connect.



6.After the Bluetooth connection is successful, the pairing indicator is off, and "Connected" will appear in the list of Bluetooth devices.



Keyboard shortcut function description

\triangle	Back to Home page
* -	Brightness –
* +	Brightness +
Q	search
	Screen keyboard
*	Cropping
I44	Previous track
►II	Pause/Play
▶ ▶I	Next track
connect	Bluetooth pairing
₫-	Volume –
₫+	Volume+
All	Select all
Q.	Сору
	Paste
	Lock screen
Fn	Function key
- \	Backlight brightness adjustment

After switch system push above multimedia function show:

Notice 1: This keyboard is 3-system universal keyboard, after confirming using it then push FN+QNV/E to choose suitable system.

Notice 2: Only backlight kind keyboard has this button.



Color adjust: total 7 kind colors circulating

Backlight model:

1.1 Single color backlight (RGB) 2. Breathing light 3. Backlight turn off .

2.RGB backlight switch: Under single color model situation, Press RGB key to switch backlight.

! Attention

- 1. When not use for long time, suggest to close keyboard, in order to prolong battery lift.
- 2. In order to get longer battery lift ,charging before keyboard power light flashes, charging time must be better more than 2 hours.

Energy saving sleep mode

When keyboard not use will be enter sleep mode after 15minutes, keyboard indicator will off, press any key 5s to wake it up when need use again, then keyboard indicator will turn on.

Charging

When the battery is low, the low battery indicator will flash continuously, and the keyboard needs to be charged at this time. During the charging process of the keyboard, the charging indicator light will be on for a long time and will automatically turn off after it is fully charged.

IOS13 system touchpad gestures

Sliding finger	Moving the cursor
Single finger fast double click without loose drag	Left click to select the target drag
Two-finger vertical /horizontal movement	Vertical/horizontal scrolling
Three fingers move up at the same time	Recent task window switch
Three fingers sliding left /right at the same time	Active window left /right slide switch
Single finger tap	Left mouse button
Two-finger tapping	Right mouse button
Three-finger tap	Middle mouse button
Three fingers move down at the same time	Back to Home page

IOS 13 mouse function is enabled: "Settings" – "Accessibility" – "Touch" – "Auxiliary Touch" – "Open"

Troubleshooting

If your keyboard doesn't work properly;

- 1. Please make sure that your computer bluetooth function is enabled.
- 2. The keyboard should be within 10 meters of the computer.
- 3. The connection password entered is correct.
- 4. keyboard built-in battery power is too low, please charge the keyboard.
- 5. if the keyboard is not connected or paired with the tablet computer after successful pairing, the text input delay

or even typing letters appear in the process, please according to the following steps: delete all Bluetooth devices, tablet computer Bluetooth option in the closed on a tablet computer Bluetooth option – restart the tablet computer keyboard and tablet computer again.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction

Documents / Resources



chuanqiang CQ172 Wireless Keyboard [pdf] User Manual

2BDM3-CQ172, 2BDM3CQ172, cq172, CQ172 Wireless Keyboard, CQ172, Wireless Keyboard, Keyboard

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.