

Chug PCWC001 Compact Wireless Keyboard Owner's Manual

Contents

- [1 Chug PCWC001 Compact Wireless Keyboard](#)
- [2 Square Low Profile Keys](#)
- [3 Product Requirements](#)
- [4 Connecting via Receiver And Pairing](#)
- [5 Troubleshooting](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

Chug PCWC001 Compact Wireless Keyboard

Square Low Profile Keys

- 1 x Compact Keyboard
- 1 x USB-A 2.4Ghz Receiver
- 1 x Instruction Manual

Back AAA Battery Slot USB Receiver



Indicators:

Caps Lock
2.4G
BT2



- product design may vary

Product Requirements

- PC with a USB-A port
- 1 PC AAA Battery

LED Indicators

- **2.4G Indicator:** Flashing Red – 2.4G Pairing
- **Caps Lock Indicator:** Flashing Blue – BT1 Pairing; Solid Blue – Caps Lock
- **BT2 Indicator:** Flashing Blue – BT2 Pairing

Keyboard Multimedia Keys

- **Fn Key + F1:** Media Player
- **Fn Key + F7:** Play/Pause
- **Fn Key + F2:** Volume
- **Fn Key + FB:** Stop
- **Fn Key + F3:** Volume +
- **Fn Key + F9:** Home
- **Fn Key + F4:** Mute

- **Fn Key + F10:** Mailbox
- **Fn Key + F5:** Previous Track
- **Fn Key + F11:** My Computer
- **Fn Key + F6:** Next Track
- **Fn Key + F12:** Collect

Connecting via Receiver And Pairing

Connecting via the Receiver

- Remove the battery cover on the back of the keyboard remove the USB receiver, and install 1 AAA battery, align the “+” and “-” symbols, and switch the power to on
- Hold Fn+1, when the 2. 4G indicator flashes red it has entered pairing.
- Plug the receiver into your computer, the keyboard and receiver will automatically pair. The indicator will fade when pairing is successful.

Note: To use the media keys hold Fn and press the secondary function (play/pause, volume up/down, etc.) you’d like to use.

Connecting via Pairing

- Remove the battery cover on the back of the keyboard and install 1 AAA battery, align the “+” and “-” symbols, and switch the power to on.
- To enter pairing hold Fn+2, the Caps Lock indicator will flash blue. Hold Fn+3 to use secondary pairing, the BT2 indicator will flash blue.
- Use your device to pair with “PCWC-001”. The indicator will fade when pairing is successful.
- The keyboard can be connected to two devices at the same time. Press Fn+2 or Fn+3 to switch between the two devices.

Note: The keyboard will automatically pair the same way the next time it is powered on. The indicator will flash blue to show it is in wireless pairing.

Troubleshooting

- If the keyboard is not connecting make sure the receiver is properly plugged into the computer or make sure wireless pairing is enabled on your device and pairing is successful.
- If the keyboard is not responding check if the battery is low. If it is please replace the battery.
- If you’re still having connectivity issues, move closer to the device or reduce interference from other wireless devices by moving them away from the keyboard.
- Having trouble with your device? Be sure you’re running the latest software on your devices. You can do this by doing a ‘software update’ in the settings of your device.

Safety

- Do not use near any water source.

- Do not modify or repair this device.
- Do not use chemical detergents to clean your device, use a soft dry cloth

WARNING: The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.

- **Keyboard Model:** PCWC001
- **FCC ID:** 2A023-PCWC001
- **Receiver Model:** Y2W1
- **FCC ID:** 2A023-YZW1
- **Receiver Input:** DC 5V
- **Working distance:** 8~10m

Made in China

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful Interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. gemsfindyours.com 7157 Shady Oak RD. Eden Prairie, MN 55344
Distributed by Chug, Inc.

For qualified repair specialists requesting repair information and parts please contact the original manufacturer at customersupport@gemsfindyours.com

Documents / Resources



[Chug PCWC001 Compact Wireless Keyboard](#) [pdf] Owner's Manual
2AO23-PCWC001, 2AO23PCWC001, PCWC001 Compact Wireless Keyboard, PCWC001, Compact Wireless Keyboard, Wireless Keyboard, Keyboard

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.