

Chug PMWCW09 3 In 1 Wireless Charging Stand User Manual



Chug PMWCW09 3 In 1 Wireless Charging Stand User Manual

[Home](#) » [Chug](#) » Chug PMWCW09 3 In 1 Wireless Charging Stand User Manual 

Contents

- [1 Chug PMWCW09 3 In 1 Wireless Charging Stand User Manual](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 QUICK TIPS](#)
- [5 HOW TO CHARGE](#)
- [6 TROUBLESHOOTING](#)
- [7 SAFETY](#)
- [8 SAVE THESE INSTRUCTIONS](#)
- [9 FAQs](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)



Chug PMWCW09 3 In 1 Wireless Charging Stand User Manual




Specifications

- Dimensions: 7 inches x 4.65 inches
- Product Name: 3-IN-1 WIRELESS CHARGING STAND
- Features: Charge phone, watch, and earbuds simultaneously
- Charging Indicators: Light separately when charging
- Input: 9.0V 3.0A / 12.0V 2.5A
- Phone Charging Stand Output: 10W Max
- Watch Charging Stand or Earbud Case Charging Base Output: 5W Max (each)
- Manufacturer: Made in Vietnam

Product Usage Instructions

What's Included

The package includes the 3-in-1 wireless charging stand and a USB-C cable for power.



LED Indicator Guide

Solid White: Charging your device / Fully charged

Flashing White: Foreign object detection – remove any metal or materials causing overheating immediately

How to Charge

Place your phone, watch, and earbuds on the corresponding stands on the charging base. Connect the USB-C cable to the charging base and a power source.

Troubleshooting

If you encounter issues with charging, ensure your devices are properly aligned on the stands. You can also try a 'software update' on your device settings.

Safety Instructions

Follow all safety instructions provided in the manual. Keep the charging stand away from water or moisture. Do not attempt to modify the device as it may void the warranty.

QUICK TIPS

Double check your alignment – be sure to center the device on the charging surface to ensure the most efficient and fastest charge times.

Certain materials and thicker phone cases can interfere with wireless charging.

Not all devices are compatible with wireless charging, please check the devices user manual for compatibility information.

This is a high speed 3-in-1 charger, please use the USB-C cable and power delivery wall plug that was included; using different items may cause slower charging.

HOW TO CHARGE

- Place the charger on a flat, sturdy surface.
- Plug the wall plug into an outlet, and the USB-C cable into both the wall plug and 3-in-1 charger. If you need to use a different power source be sure it is a USB power supply of DC9V 3A minimum. warning: please use a UL compliant power supply.
- Place your device on the correct charging surface making sure the device is centered on the charging surface or the device will not charge.
Note: The phone charging stand will charge all Qi-enabled devices. Remove anything with a magnetic strip, like credit cards, to prevent damage before charging.
- The phone charging stand allows for wireless charging up to 10W; the watch charging stand and earbud case charger allow for wireless charging up to 5W.

Remove the phone from the phone charging stand before changing the orientation of the phone. Charge time will vary by device.

TROUBLESHOOTING

- Double-check the connections between the USB-C cable and wall plug, ensuring they are fully plugged in.
- Some phone cases may cause interference with wireless charging; remove the case for best results. Make sure the device is centered on the wireless charger.
- Wireless charging is compatible with newer devices as well as other Qi-enabled devices; consult your devices user guide to ensure compatibility.
- When using the earbud case charging base the device may still charge even when not fully centered, if the indicator light is white the device is being charged.
- If the indicator light flashes white while switching the phone orientation on the phone charging stand, remove the phone and recenter it in the preferred position.
- Having trouble with your device? Be sure you're running the latest software on your devices. You can do this by doing a 'software update' in the settings of your device.

SAFETY

- Do not modify or repair this device.
- Do not use in high temperatures or extreme weather.
- Do not use chemical detergents to clean your device, use a soft dry cloth.
- Immediately unplug it from its power source if it gets wet.
- Keep the charger away from heat and direct sunlight.
- Remove credit cards and other cards with magnetic strips to prevent damage to the cards.

SAVE THESE INSTRUCTIONS

FCC ID: 2AO23-PMWCW09 Model: MWCW09 Input: 9.0V 3.0A / 12.0V 2.5A Phone Charging Stand Output: 10W

Max

Watch Charging Stand or Earbud Case Charging Base Output: 5W (for each) Max Made in Vietnam

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

8725 COLUMBINE RD EDEN PRAIRIE, MN 55344-6695, PO Box # 44895 Distributed by ZSOU.

For qualified repair specialists requesting repair information and parts please contact the original manufacturer at support@zsoupower.com

FAQs

Q: What should I do if the charging indicators do not light up?

A: Check the power source and connections. Ensure that the devices are properly placed on the stands.


Q: Can I use a different cable for charging?

A: It is recommended to use the provided USB-C cable for optimal charging performance. Using different cables may result in slower charging.

Q: How do I know if my device is fully charged?

A: The LED indicator will turn solid white when your device is fully charged.

Documents / Resources

	<p>Chug PMWCW09 3 In 1 Wireless Charging Stand [pdf] User Manual 2AO23-PMWCW09, PMWCW09 3 In 1 Wireless Charging Stand, PMWCW09, 3 In 1 Wireless Charging Stand, Wireless Charging Stand, Charging Stand, Stand</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.