Manuals+ — User Manuals Simplified.

‧ı‧ı‧ı‧ı
CISCO
150AX
Business
Access
Point

CISCO 150AX Business Access Point User Guide

Contents

‧ı‧ı‧ı‧ı
CISCO

CISCO 150AX Business Access Point

Specifications:

- **Product:** Cisco Business 150AX Access Point
- **Wi-Fi Standard:** Wi-Fi 6
- **Ports:** PoE (Power over Ethernet)-In Port, Kensington Lock
- **Features:** Status LED, Mode Button, Security Screw Hole,Mounting Bracket

Product Usage Instructions

Get Connected:
Connect the access point to a PoE LAN port on your switch or router using the provided ethernet cable. If you don't have a PoE switch or router, use a PoE injector.

Get Configured:
Download the Cisco Business Mobile app on your mobile device.
Scan the QR code provided or visit **cisco.com/go/cbapp** to download the app.

Setting up a new network or adding to an existing network:

Set up a new network:
If setting up a new network, wait for the LED on the device to turn solid green before proceeding to configuration.

Add to an existing CBW Wi-Fi 6 wireless network:
Allow the access point to boot up and update its firmware and configuration to match the existing network. Once the LED is solid green, the setup is complete.

Alternative: Web UI Setup:
If you prefer not to use the mobile app, you can set up the device using a web browser. Refer to the Web UI Setup Document for instructions.

Mounting and Grounding:
The access point can be mounted in various configurations. Refer to the Administration Guide for detailed mounting instructions.

Get Support:
For Cisco support and additional product documentation, visit:
Cisco Business 150AX Support

FAQ

Q: What do I need to set up the Cisco Business 150AX Access Point?
A: You will need an active Internet connection, a mobile device with Wi-Fi capability, the Cisco Business Mobile app or a compatible web browser, a PoE switch/router/injector, and a router/switch as your DHCP server.

Q: How do I know when the access point is ready for configuration?
A: For setting up a new network, wait for the LED to turn solid green. For adding to an existing network, wait for the LED to cycle through green, red, and off before turning solid green.

Thank you for choosing the Cisco Business 150AX Access Point.
This access point can be used to create a new Wi-Fi 6 wireless network, or expand coverage of your existing Cisco Business Wireless (CBW) Wi-Fi 6 Network.

This Quick Start Guide will get you up and running in no time.

What's in the Box

- Cisco Business 150AX Access Point
- Mounting Kit
- Ethernet Cable
- Quick Start Guide
- Technical Support Contact List
- Pointer Card China RoHS
- Compliance Information (for EU SKU only)

Product Features

1. Status LED
2. PoE (Power over Ethernet)-In Port (Ethernet Uplink Port)
3. Kensington Lock
4. Disabled
5. Mode Button
6. Security Screw Hole
7. Mounting Bracket

First, You'll Need…

- An active Internet connection.
- A mobile device with Wi-Fi capability (not connected to an active wireless network).
- Cisco Business Mobile app or a compatible web browser such as Microsoft Edge (ver. 10 or above), Safari (ver. 7 or above), Firefox (ver. 33 or above) or Chrome (ver. 38 or above).
- A PoE (Power over Ethernet) switch, router, or a PoE injector to supply power to the access point.
- A router or switch (to act as your DHCP Server).

Get Connected

1. Connect your access point via ethernet cable (provided) to a PoE LAN port on your switch or router. If you do not have a PoE switch or router you will need to use a PoE injector.

Setting up a new network or adding to an existing network?

Set up a new network

If setting up a new network the device will begin initial boot up. The LED will cycle through patterns of green, red and off. This is normal and can take up to 6 minutes or longer. The device is not ready until the LED is solid green. Once this occurs you can proceed to "Get Configured".

2. Add to an existing CBW Wi-Fi 6 wireless network

Allow the access point to boot up and automatically update its firmware and configuration to match the existing network. This can take 10 minutes or more, and the LED will cycle through green, red and off. This is normal. Once the LED is solid green the setup is complete and ready to be connected to the network. Once you are connected the LED turns blue.

Download the Cisco Business Mobile app

- No computer is needed for setup, just use the app on your mobile phone.
- Scan the QR code here to download the app or go to **cisco.com/go/cbapp** and follow the installation instructions.

Alternative: Web UI (Internet Browser) Setup
If you do not wish to use the Cisco Business Mobile app you can use the Web UI for setup. These instructions can be found online in the Web UI Setup Document.

To download the instructions see the "Get Support" section below.

Mounting and Grounding

Cisco Business Wireless access points can be mounted in several configurations—on a suspended ceiling, on a hard ceiling or wall, or in the plenum air space above a suspended ceiling.

Mounting instructions are located in the Administration Guide, see the "Get Support" section below.

For Cisco support and additional product documentation, including the Web UI Setup Document and Administration Guide, visit: **https://cisco.com/go/cbw150ax**

Documents / Resources

CISCO 150AX Business Access Point [pdf] User Guide
150AX, 150AX Business Access Point, 150AX, Business Access Point, Access Point

References

- **Cisco Business Mobile app Landing Page**
- **One moment, please...**
- **Cisco Trademarks - Cisco**
- **User Manual**