



Activate Windows
Go to Settings to activate Windows.

Cld Distribution GSPS4 Wireless Game Controller Instruction Manual

[Home](#) » [Cld Distribution](#) » Cld Distribution GSPS4 Wireless Game Controller Instruction Manual 

Contents

- 1 Cld Distribution GSPS4 Wireless Game Controller
- 2 Wireless Game Controller Manual
- 3 SAFETY INSTRUCTIONS
- 4 PRODUCT FEATURE
- 5 OVERVIEW
- 6 PAIRING PROCESS
- 7 UPDATE FOR THE GAMEPAD
- 8 FUNCTIONS (Sorted regarding product plan
- 9 SPECIAL FEATURES
- 10 RGB DISPLAY
- 11 ELECTRIC ALIMENTATION INFORMATION
- 12 Documents / Resources
- 13 Related Posts



Cld Distribution GSPS4 Wireless Game Controller



Wireless Game Controller Manual

Here's the new Dragon Shock 4 Bluetooth Wireless Controller in its 5th Edition, design for PlayStation 4 console. This controller is compatible with PlayStation 4 Bluetooth Wireless specifications, corresponding to 4 analog axis, 2 analog keys and 16 digital buttons, RGB LED, 4 atomic buttons and 3D with LED underneath, Big and Small Vibration, 6-axis Motion Sensor, Headset jack port, Wireless pairing function. Compatible with the new DualShock 4 wireless controller (CUH-ZCT 2 series)..

SAFETY INSTRUCTIONS

- Please do not store the product in a humid or high-temperature place
- Don't knock, beat, drub, pierce or try to decompose the gamepad to avoid unnecessary damage to the gamepad.
- Built-in battery, please do NOT throw this product in the trash
- Do not charge the controller near fire or other heat source
- Non-professionals should not disassemble this product, otherwise it is not be eligible to after-sales warranty service
- If the controller cannot turn on, please fully charge it

PRODUCT FEATURE

- Compatible with all button functions, NO touch function, motor corresponding functions, With sensor function .
- Includes RGB LED function, 3 blue LEDs and 4 atomic buttons under the left and right joysticks correspond to

LED of different colors.

- Includes 16 buttons function input keys.
- Built-in twin motors, High precision 3d rocker.
- Sensitive button response, easy to use.
- Support PlayStation 3 console.(By micro–USB cable).
- Support Bluetooth wireless(Bluetooth 5.0).
- Support USB wired pairing (USB 1.1 or USB 2.0, micro USB B).

OVERVIEW

1. SHARE Button
2. Touch pad button-NO touch function
3. Option button
4. Directional buttons
5. Triangle Button with green backlight
6. Square Button with pink backlight
7. Circle Button with red backlight
8. Cross Button with blue backlight
9. RGB LED
10. Left analog joystick/L3 button with blue backlight-Press down on the stick to use it as the L3 button
11. PS button
12. Right analog joystick/R3 button with blue backlight-Press down on the stick to use it as the R3 button
13. Speaker



14. R1 button
15. R2 trigger
16. USB pppt

- 17. L1 button
- 18. L2 trigger
- 19. RESET button
- 20. Headset jack port




PAIRING PROCESS

- Connect the Dragon Shock 4 controller to the PlayStation 4 console with the micro-USB cable provided.
- After pairing is complete, please press the PS button to activate wireless connection.
- Dragon Shock 4 controllers can be paired to a PlayStation 4 at the same time. PlayStation 4 can recognize up to 32 different paired controllers. Press the PS button to take the console out of its Sleep Mode

UPDATE FOR THE GAMEPAD

1. Open the firmware update, as indicated below. Note: The following upgrade tools may differ from the picture, but the operation method stays the same.



2. When the Dragon Shock 4 is in standby mode, long-press the SHARE and Cross buttons and connect the gamepad to the computer with the micro-USB cable provided. The controller driver will enter in update mode. Then select DOWNLOAD to launch the update. Refer to the second image below to see if the update was successful.



FUNCTIONS (Sorted regarding product plan

Number	Name		Function
1	SHARE Button		SHARE functions (printscreen, recording video, ...)
2	Touch button	pad	action button – activates an in-game command (depending on the game settings)

3	OPTION Button		OPTION button / in-game pause button
4	Directional buttons		8-position directional action button – activates in-game commands (depending on game's settings)
5	Triangle Button		action button – activates an in-game command (depending on game's settings)
6	Square Button		action button – activates an in-game command (depending on game's settings)
7	Circle Button		action button – activates an in-game command (depending on game's settings)
8	Cross Button		action button – activates an in-game command (depending on game's settings)
9	Touch pad light bar		Power indicator / in-game light bar status indicator (depending on game's settings)
10	Left joystick button	analog / L3	Directional joystick / action button – activates an in-game command when pressed down (depending on game's settings)
11	PS Button		Controller power button / exit console sleep mode / back to console's main menu
12	Right joystick button	analog / R3	Directional joystick / action button – activates an in-game command when pressed down (depending on game's settings)
14	R1 button		action button – activates an in-game command (depending on game's settings)
15	R2 button	trigger	action button – activates an in-game command (depending on game's settings)

17	L1 button		action button – activates an in-game command (depending on game's settings)
18	L2 button	trigger	action button – activates an in-game command (depending on game's settings)
19	RESET button		allows to reset the controller

SPECIAL FEATURES

- PS button: display the console's main screen (when PlayStation 4 console power is on), allow to exit console's sleep mode and to switch between applications during launch; press long PS button allows to enter settings menu
- SHARE button: open the SHARE menu to select options available as print screen, recording an in-game video, etc.
- OPTIONS button: opens in-game options/main menu or pause the game (depending on game's settings)

This product does not support PS VITA TV

RGB DISPLAY

Colorful RGB LED: To display the player's status, press the PS button and the light bar will turn on the light of the corresponding player as: Player one: Blue / Player two: Red / Player three: Green / Player four: pink

1. During pairing, the light bar will flash in white and, after connection, will light in solid blue
2. During charging mode with the controller off, the light bar will illuminate orange in slow pulses.
3. During charging mode with the controller on, the light bar will illuminate solid blue.

ELECTRIC ALIMENTATION INFORMATION

1. ELECTRIC ALIMENTATION INFORMATION
2. Operating current without vibration: less than 100mA
3. Operating time in constant use: about 4 hours
4. Standby current: less than 10mA
5. Charging voltage/current: about DC5V / 200mA
6. Bluetooth transmission distance: $\leq 8\text{m}$
7. Battery capacity: 500mAh
8. Standby time: for about 30 days when fully charged
9. Low power 3.5V, entering standby
10. The light bar will turn off when the battery is fully charged with 4.15-4.22V

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference
2. this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources

<div><p>Wireless Game Controller Manual</p><p>Read the User Manual before using the product to avoid damage to the product and to ensure safe use. The manual contains important information about the product, its use, and safety. It also contains information about the product's features and functions. Please read the manual carefully before using the product.</p><p>SAFETY INSTRUCTIONS</p><ul style="list-style-type: none">• Please do not use the product in a flammable or explosive atmosphere.• Do not use the product near water or other liquids.• Do not use the product near fire or heat.• Do not use the product near electrical equipment.• Do not use the product near children or pets.• Do not use the product near medical equipment.• Do not use the product near aircraft.• Do not use the product near ships or boats.• Do not use the product near power lines.• Do not use the product near high voltage equipment.• Do not use the product near magnetic fields.• Do not use the product near radio waves.• Do not use the product near electromagnetic interference.• Do not use the product near electromagnetic radiation.• Do not use the product near electromagnetic fields.• Do not use the product near electromagnetic energy.• Do not use the product near electromagnetic waves.• Do not use the product near electromagnetic signals.• Do not use the product near electromagnetic noise.• Do not use the product near electromagnetic pollution.• Do not use the product near electromagnetic contamination.• Do not use the product near electromagnetic degradation.• Do not use the product near electromagnetic deterioration.• Do not use the product near electromagnetic destruction.• Do not use the product near electromagnetic disaster.• Do not use the product near electromagnetic emergency.• Do not use the product near electromagnetic exception.• Do not use the product near electromagnetic exemption.• Do not use the product near electromagnetic excuse.• Do not use the product near electromagnetic justification.• Do not use the product near electromagnetic necessity.• Do not use the product near electromagnetic propriety.• Do not use the product near electromagnetic reason.• Do not use the product near electromagnetic right.• Do not use the product near electromagnetic title.• Do not use the product near electromagnetic interest.• Do not use the product near electromagnetic claim.• Do not use the product near electromagnetic demand.• Do not use the product near electromagnetic requirement.• Do not use the product near electromagnetic rule.• Do not use the product near electromagnetic law.• Do not use the product near electromagnetic regulation.• Do not use the product near electromagnetic statute.• Do not use the product near electromagnetic ordinance.• Do not use the product near electromagnetic decree.• Do not use the product near electromagnetic edict.• Do not use the product near electromagnetic order.• Do not use the product near electromagnetic command.• Do not use the product near electromagnetic directive.• Do not use the product near electromagnetic instruction.• Do not use the product near electromagnetic guidance.• Do not use the product near electromagnetic suggestion.• Do not use the product near electromagnetic recommendation.• Do not use the product near electromagnetic advice.• Do not use the product near electromagnetic tip.• Do not use the product near electromagnetic hint.• Do not use the product near electromagnetic nudge.• Do not use the product near electromagnetic prod.• Do not use the product near electromagnetic prompt.• Do not use the product near electromagnetic reminder.• Do not use the product near electromagnetic cue.• Do not use the product near electromagnetic signal.• Do not use the product near electromagnetic notice.• Do not use the product near electromagnetic warning.• Do not use the product near electromagnetic caution.• Do not use the product near electromagnetic alert.• Do not use the product near electromagnetic notice.• Do not use the product near electromagnetic announcement.• Do not use the product near electromagnetic declaration.• Do not use the product near electromagnetic statement.• Do not use the product near electromagnetic expression.• Do not use the product near electromagnetic opinion.• Do not use the product near electromagnetic view.• Do not use the product near electromagnetic belief.• Do not use the product near electromagnetic faith.• Do not use the product near electromagnetic trust.• Do not use the product near electromagnetic confidence.• Do not use the product near electromagnetic assurance.• Do not use the product near electromagnetic security.• Do not use the product near electromagnetic safety.• Do not use the product near electromagnetic protection.• Do not use the product near electromagnetic defense.• Do not use the product near electromagnetic shield.• Do not use the product near electromagnetic barrier.• Do not use the product near electromagnetic obstacle.• Do not use the product near electromagnetic hindrance.• Do not use the product near electromagnetic interference.• Do not use the product near electromagnetic disruption.• Do not use the product near electromagnetic interruption.• Do not use the product near electromagnetic obstruction.• Do not use the product near electromagnetic blockage.• Do not use the product near electromagnetic barrier.• Do not use the product near electromagnetic obstacle.• Do not use the product near electromagnetic hindrance.• Do not use the product near electromagnetic interference.• Do not use the product near electromagnetic disruption.• Do not use the product near electromagnetic interruption.• Do not use the product near electromagnetic obstruction.• Do not use the product near electromagnetic blockage.</div>	<div><p>Cld Distribution GSPS4 Wireless Game Controller [pdf] Instruction Manual</p><p>GSPS4, 2AY59-GSPS4, 2AY59GSPS4, GSPS4 Wireless Game Controller, GSPS4, Wireless G ame Controller</p></div>
--	---