

CLI-MATE CLI-AD-LED Ultrasonic Aroma Diffuser Instruction Manual

Home » CLI MATE » CLI-MATE CLI-AD-LED Ultrasonic Aroma Diffuser Instruction Manual



Contents

- 1 CLI-MATE CLI-AD-LED Ultrasonic Aroma **Diffuser**
- **2 SAFETY PRECAUTIONS**
- **3 COMPONENT IDENTIFICATION**
- **4 OPERATION INSTRUCTIONS**
- **5 CLEANING AND MAINTENANCE**
- **6 TROUBLESHOOTING**
- **7 Warranty**
- 8 Documents / Resources
 - 8.1 References



CLI-MATE CLI-AD-LED Ultrasonic Aroma Diffuser



Congratulations on your purchase of a Cli~Mate Ultrasonic Aroma Diffuser

The Cli~Mate Ultrasonic Aroma Diffuser disperses and fills the room with your favourite aroma through a fine cool mist.

Note:

Please read through the instructions carefully before using or installing the product and ensure that the manual is kept in a safe place for future reference.

- The system must be properly installed and located under the installation instructions before it is used.
- During the set-up of this product if you have any questions/comments/issues DO NOT RETURN TO STORE.
- FOR SERVICE AND TECHNICAL ADVICE ON THIS PRODUCT, CALL 1300 764 325.

SAFETY PRECAUTIONS

Read all instructions carefully.

- All components need to be installed by the user manual instructions for the correct performance of the unit.
- This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure they do not play with the product.
- Do not operate the unit with a damaged cord or plug or after the unit malfunctions or has been damaged in any manner.
- To protect against the risk of electric shock and personal injury, do not immerse cords, plugs or products in


water or other liquids.

- Switch the unit off and unplug it from the wall outlet when not in use and before cleaning.
- Operate the unit on a stable level flat surface, keep away from moving parts.
- When moving the device, hold the bottom of the device.
- Do not move or shake the device during operation or when the power is on.
- Do not try to remove any parts of the device during operation.
- Do not move or incline the device to prevent overflow of water during operation.
- Do not pour water or other liquid into the vent.
- Do not try to touch the transducer piece which is highly sensitive with bare fingers, or scrape it with metal tools, otherwise it will reduce mist output.
- Dispose of any unused liquid after each use.
- Do not use the device if the glass case is broken.
- Do not use water warmer than 55°C to prevent damage to the transducer piece.
- Do not use dirty water to prevent clogging and damage to the transducer piece.

	Ultrasonic Aroma Diffuser	
Model Code	CLI-AD-LED	
Input Voltage	100-240 Volts AC	
Rated Voltage	24V DC	
Power Consumption	Maximum 12W	
Water Sink Capacity 100ml		
Misting Output	Approx. 30 ml per hour	
Dimension	(D) 90 x (H) 191 (mm)	
Net Weight	586 grams	

COMPONENT IDENTIFICATION

- a. Glass Case
- **b.** Mist On/Off Button
- c. LED Light On/Off Button
- d. Transducer Piece
- e. Water Sink
- f. Water Level Line
- g. Water Stopping Cap
- h. Vent
- i. Silicon O-Ring
- j. LED Light (Inside)
- k. Power DC Jack



OPERATION INSTRUCTIONS

- 1. Locate a flat stable location and plug the power adapter into the appropriate electrical outlet.
- 2. Fill the water sink with water no higher than the water level line.
- 3. Add 3 to 5 drops of essential oil. (If desired).
- 4. Replace water stopping cap.
- 5. Press the Mist on/off button and select the setting:
 - 1st Stage Continuous mode- Mist emits continuously. Automatically turns off after 3 hours.
 - 2nd Stage Intervals of 30 seconds mode Mist emits at intervals of 30 seconds and automatically turns
 off after 6 hours.
 - 3rd Stage Power off- Mist off and LED light off.
- 6. Press the LED light button to switch on the 7-colour LED lighting. Press the button once again to fix the light in any one colour you prefer out of the seven colours.

Important Tips:

- The amount of mist gradually increases as the water goes down from the water level line. However, when the water goes down to under around 1/3 water level line, the amount of mist begins decreasing. This is normal, not the malfunction of the unit.
- When the water depletes, the unit turns off automatically and the indicator light goes out.

CLEANING AND MAINTENANCE

Before carrying out cleaning or maintenance of the product, always unplug the adaptor from the aroma diffuser and power socket.

- Clean the water sink before using different essential oils.
- Clean the water sink and the water-stopping cap with a soft cloth if necessary.
- Clean off any scales (white mineral deposits and debris) from the transducer piece with a soft cloth. Do not use

any metal to scrape the transducer piece, or touch it with your fingers.

- Do not rinse the unit or immerse the unit in water.
- Do not pour any water or liquid into the vent.
- Clean the surface of the device with a soft cloth.
- The glass case can be cleaned with water but avoid any sharp objects.

TROUBLESHOOTING

BEFORE YOU CALL FOR SERVICE PLEASE REVIEW THE TROUBLESHOOTING TIPS FIRST.

Problem	Possible Causes	What To Do
No Power	The adaptor is not properly plugged in	Check connection to wall socket and unit
	The mist on/off button is not pressed	Press the button again
No Mist	No water or too little water in the water sink	Pour enough water into the sink
Reduced or almost no mist when water sink is full	The transducer piece is contaminated	Clean the transducer piece
	Water is higher than the water level line	Pour out the excess water
	Excluding the above two reasons, if there is still sound of the fan working, check if the vent is obstructed	Remove any obstacle on the vent

Warranty

Your Aquaport 12-Month Repair or Replacement Warranty

Aquaport warrants this appliance to the first purchaser and subject to the stated conditions:

- The warranty covers any defects in material or workmanship in the manufactured product within the first twelve months from the date of purchase.
- To make a warranty claim you must call Aquaport on toll free number 1300 764 325 for instructions. If a product is found to be faulty there is a 90-day return policy from the date of purchase.
- For warranty claims outside of 90 days from the date of purchase, the product will be repaired or replaced at our discretion. Repair or replacement costs of the product will be covered under warranty by Aquaport.
- Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired.

 Refurbished parts may be used to repair the goods.

Warranty does not cover filters that are consumable unless proven to have defects in material or workmanship in the manufactured product. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure.

Conditions of this Warranty:

- 1. This product has been fully installed under the user manual installation instructions.
- 2. The warranty extends only to repairing or replacing any component that proves to be defective in material or workmanship.
- 3. The warranty does not cover defects occasioned by misuse, alterations, accidents, or use for other than the

intended purpose.

- 4. The warranty does not cover damage to the product caused by an accident, fire, or flood.
- 5. Proof of purchase is required for warranty claims.

Please keep the purchase receipt in a safe place.

To enable us to register your warranty and provide service should a problem occur, we recommend you register your warranty online at: www.cll-mate.com.au/warranty-and-registration.

Aquaport Corporation Pty Ltd

- 70 Hardys Road, Torrensville South Australia 5031
- Customer Care 1300 764 325

CUSTOMER HOTLINE: 1300 764 325

Aquaport Corporation pty Ltd 70 Hardys Road, Torrensville SA 5031

Telephone: 08 8354 0711Facsimile: 08 8354 0722

• Email: aquaport@aquaport.com.au.

• Web: www.cli-mate.com.au.

Social:

Facebook/climatebrand

Twitter@climatebrand

Documents / Resources



<u>CLI-MATE CLI-AD-LED Ultrasonic Aroma Diffuser</u> [pdf] Instruction Manual CLI-AD-LED Ultrasonic Aroma Diffuser, CLI-AD-LED, Ultrasonic Aroma Diffuser, Aroma Diffuser . Diffuser

References

- <u>Manual-Hub.com Free PDF manuals!</u>
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.