

**COBY
CD-191-BLK
Portable CD
Player**



Coby CD-191-BLK Portable CD Player User Manual

[Home](#) » [Support](#) » Coby CD-191-BLK Portable CD Player User Manual 

Contents

- [1 Coby CD-191-BLK Portable CD Player](#)
- [2 Introduction](#)
- [3 Specifications](#)
- [4 Package Includes](#)
- [5 Features](#)
- [6 Usage](#)
- [7 Care and Maintenance](#)
- [8 Troubleshooting](#)
- [9 Pros and Cons](#)
- [10 Contact Information](#)
- [11 Warranty](#)
- [12 FAQs](#)
- [13 Video-Coby CD-191-BLK Portable CD Player](#)
- [14 References](#)
- [15 Related Posts](#)

COBY

Coby CD-191-BLK Portable CD Player



Launch Date: April 20, 2015

Price: \$34.27

Introduction

It's easy and quick to enjoy your music collection on the go with the Coby CD-191-BLK Portable CD Player, which blends retro style with up-to-date features. This small and light device is perfect for people who like the old-school CD format and the flexibility of newer features. The Coby CD-191-BLK is convenient because it has FM radio, MP3 support, and various playing modes, so you can use it at home, on the road, or outside. Because it protects against shock, you can listen to music without any problems wherever you are. You can use either AA batteries or a micro-USB wire to power the player, which gives you more options for listening while you're on the go. With simple buttons and an LCD screen, the design makes it easy for users to move around in their song library. The Coby CD-191-BLK is a small music player that is both useful and fun. It has a lot of useful features.

Specifications

- **Brand:** Coby
- **Model Name:** CD-191-BLK
- **Color:** CD191 (Black)
- **Connectivity Technology:** Auxiliary (3.5mm headphone jack and aux port for external speaker connection)
- **Special Feature:** Ultra-Portable
- **Product Dimensions:** 5.5 x 1 x 5 inches
- **Item Weight:** 11.7 ounces

- **Item Model Number:** CD-191-BLK
- **Batteries:** 2 AA batteries (required, not included)
- **Manufacturer:** Summit Electronics, LLC

Package Includes

- 1 x Coby CD-191-BLK Portable CD Player
- 1 x Pair of high-quality stereo earbuds
- 1x User Manual

Features

1. Small and Lightweight Design

It is easy to take the Coby CD-191-BLK Portable CD Player with you anywhere because it is small and light. Its small size makes it easy to carry around in your bag or backpack, so you can listen to music on the go. This CD player is great for taking with you on the go, whether you're working or visiting.

2. Protection Against Shock

This CD player is movable and has anti-shock safety, so it will play music smoothly even when you're moving. The technology reduces the effects of bumps and movement so that you can listen to music without any interruptions while walking or taking public transportation.



3. Different Playback Modes

Playback choices on the Coby CD-191-BLK are flexible, with mix, repeat, and program modes. When you

switch between these modes, you can enjoy your songs in different ways. This CD player lets you make your mix, play your favorite song over and over, or pick a random playlist.

4. Supports several CD formats

This player works with many types of CDs, such as regular CDs, CD-Rs, CD-RWs, and MP3 CDs. You can enjoy music from a variety of sources and forms thanks to this, whether you're using a store-bought CD or a custom MP3 collection.

5. Headphone Jack

The Coby CD-191-BLK has a 3.5mm headphone jack, so you can listen to music alone without bothering other people. You can listen to music privately anywhere—at home, on the bus, or anywhere else—just plug in your favorite headphones or earbuds.

6. LCD Screen

The Coby CD-191-BLK features a clear and easy-to-read LCD panel that shows important information such as track numbers, song length, and battery life. This makes it easy to find songs in your library and shows you details about the song you're listening to right now.

7. Simple to Use

The Coby CD-191-BLK makes it easy to control your music with its simple button layout. The device is easy for anyone to use because the buttons for play/pause, skip, level adjustment and mode selection are all close at hand and respond quickly.

8. Plays MP3s and FM radio

This Coby CD-191-BLK player can play regular CDs as well as MP3 files, so you can listen to your digital music library on a real disc. There is an FM radio built in that lets you listen to your favorite stations. This way you can enjoy your CDs and MP3s as well as news, music, and talk shows.

9. Two AA batteries or a micro-USB cable can power it.

The Coby CD-191-BLK can play music for up to hours on end with just two AA batteries (not included).

Connecting the player to a micro-USB cord is an easy way to power it when you don't have batteries on hand.



10. Shockproof and doesn't skip

This CD player has technology that stops skips and protects against shocks, so bumps and movement won't mess up the music or the player. You can listen to music without having to worry about skips or sudden stops, which makes it a great choice for walking or traveling.

11. Aux port comes with earbuds

For a better hearing experience, the Coby CD-191-BLK has an aux port that lets you connect it to external speakers and boost the sound. The package also comes with high-quality earbuds, so you can start listening to music right away of receipt. You can also connect your favorite 3.5mm headphones for a more customized sound experience.



12. **Boost Your Playlist**

The Coby CD-191-BLK has an aux port that lets you connect it to external speakers and get better sound. Keep in mind that the 3.5mm aux wire is not included. You can share your music with friends or play your favorite songs in a whole room with this feature.

13. **The functionality of an FM radio**

The Coby CD-191-BLK has a full-band FM radio that lets you tune in to bands from 76MHz to 108MHz. You can listen to live radio shows, like music and talk shows, as well as news and weather reports, with this feature. It will keep you entertained no matter where you are.

14. **Unmatched Sound Experience**

The Coby CD-191-BLK lets you enjoy clear and full sound from your CDs, MP3s, or FM radio. It doesn't matter if you're listening to music or a radio show—this CD player has great sound quality, from deep bass to clear highs.



15. Feels from the past and new grooves

The form of the Coby CD-191-BLK was influenced by old-school portable CD players. It combines retro style with current technology. It works with MP3s, CDs, and FM radio, so you can enjoy all kinds of music in one device. The buttons and LCD screen are easy to use, too.

Usage

1. **Insert Batteries or Power Adapter:** Open the battery compartment and insert 2 AA batteries or connect an AC adapter (sold separately) to the player for power.
2. **Load a CD:** Open the disc compartment, insert your CD (CD, CD-R, or CD-RW), and close the lid securely.
3. **Select Playback Mode:** Use the buttons on the front to choose your preferred playback mode (shuffle, repeat, or program).
4. **Adjust Volume:** Use the volume control to set your preferred listening level.
5. **Connect Headphones:** Plug your headphones into the 3.5mm jack for private listening.
6. **Play Music:** Press the play button to start enjoying your music.
7. **Skip/Repeat Tracks:** Use the skip buttons to move between tracks, or press the repeat button for continuous play.

Care and Maintenance

- **Clean the CD Player:** Use a soft, dry cloth to wipe the surface of the CD player. Avoid using harsh chemicals or abrasive cleaners that could damage the exterior.

- **Store Properly:** Keep the CD player in a safe, dry place when not in use. Avoid exposing it to excessive heat, moisture, or direct sunlight.
- **Clean CDs Regularly:** To ensure optimal playback, clean your CDs using a soft cloth before inserting them into the player. Keep CDs free from scratches, dust, and dirt.
- **Replace Batteries:** If the CD player stops functioning or the sound becomes distorted, replace the AA batteries with fresh ones.
- **Use a Compatible Power Adapter:** If using an AC power adapter, ensure it is compatible with the **Coby CD-191-BLK** to prevent damage to the player.

Troubleshooting

- **No Sound or Low Volume:**
 - Ensure the headphones are securely plugged into the headphone jack.
 - Check the volume settings and adjust accordingly.
 - Replace the batteries if the sound quality is low or there is no sound.
- **CD Won't Play:**
 - Make sure the CD is properly inserted, and the compartment is closed securely.
 - Check that the CD is clean and free of scratches or dirt.
 - Confirm that the CD is compatible with the player (CD-R, CD-RW, or MP3 CDs).
- **Player Skipping or Freezing:**
 - This may occur due to scratches or dust on the CD. Clean the CD and try again.
 - Ensure the player is placed on a flat, stable surface to avoid movement while playing.
- **Battery Issues:**
 - If the player is not turning on, replace the batteries with fresh AA batteries.
 - Ensure the batteries are installed correctly, matching the positive (+) and negative (-) terminals.
- **No Power with AC Adapter:**
 - Ensure that the AC adapter is properly connected and is compatible with the **Coby CD-191-BLK**.
 - Check the power outlet to make sure it is working properly.

Pros and Cons

Pros	Cons
Portable and lightweight	Requires AA batteries (not included)
Easy to use with intuitive controls	Limited to CD format only
Includes earbuds for immediate listening	No advanced features like Bluetooth

Contact Information

- **Customer Service Phone Number:** [718-416-3300](tel:718-416-3300)
- **Media Inquiries:**[212-564-2122](tel:212-564-2122) ext 325
- **Corporate Office Address:** 1991 Marcus Avenue, Suite 301, Lake Success, New York, 11042, USA
- **Website:** www.cobyusa.com

Warranty

The Coby CD-191-BLK Portable CD Player comes with a limited 1-year warranty covering manufacturing defects. Keep your purchase receipt for warranty claims.

FAQs

What is the model of the portable CD player?

The model of the portable CD player is the Coby CD-191-BLK.

What type of batteries does the Coby CD-191-BLK require?

The Coby CD-191-BLK requires 2 AA batteries to operate.

How can I connect the Coby CD-191-BLK to external speakers?

You can connect the Coby CD-191-BLK to external speakers using its aux port.

How can I power the Coby CD-191-BLK if I don't have AA batteries?

If you don't have AA batteries, the Coby CD-191-BLK can be powered via a micro-USB cable.

What size is the Coby CD-191-BLK portable CD player?

The Coby CD-191-BLK has dimensions of 5.5 x 1 x 5 inches, making it easy to carry around.

What formats does the Coby CD-191-BLK support?

The Coby CD-191-BLK supports standard CDs, CD-Rs, CD-RWs, and MP3 CDs.


How do I navigate through tracks on the Coby CD-191-BLK?

You can navigate through tracks using the easy-to-use buttons on the Coby CD-191-BLK.

What is the weight of the Coby CD-191-BLK portable CD player?

The Coby CD-191-BLK weighs 11.7 ounces, making it lightweight and portable.

Video-Coby CD-191-BLK Portable CD Player



<https://manuals.plus/wp-content/uploads/2025/01/Coby-CD-191-BLK-Portable-CD-Player.mp4>

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.