



Advanced Barcode Readers T500 User Guide

[Home](#) » [code](#) » **Advanced Barcode Readers T500 User Guide** 

Contents

- [1 Advanced Barcode Readers T500](#)
- [1.1 Bluetooth Settings](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

Advanced Barcode Readers T500



CONFIGURATION GUIDE

T500

www.codecorp.com

[YouTube.com/codecorporation](https://www.youtube.com/codecorporation)

Configuration barcodes generated based on current firmware versions

D036897 T500 Configuration Guide

4-29-2020

Bluetooth Settings

T500 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

Bluetooth Settings	T500 Bluetooth® iOS Keyboard Mode	T500 Bluetooth® Disconnect - Default	T500 Bluetooth® HID Keyboard Mode
	 M10502_01	 M10501_01	 M10500_01
	A2	A3	A4
	T500 Bluetooth® Serial Port Profile (SPP) One-way Mode	T500 Bluetooth® iOS App Mode	T500 Bluetooth® Serial Port Profile (SPP) Two-way Mode
 M10498_01	 M10495_01	 M10497_01	
B1	B2	B3	B4
Intentionally Blank	Intentionally Blank	Intentionally Blank	Intentionally Blank
C1	C2	C3	C4
Intentionally Blank	Intentionally Blank	Intentionally Blank	Intentionally Blank
D1	D2	D3	D4
Intentionally Blank	Intentionally Blank	Intentionally Blank	Intentionally Blank
E1	E2	E3	E4

For questions regarding reader configuration contact

Documents / Resources

	code Advanced Barcode Readers T500 [pdf] User Guide code, T500, Advanced, Barcode Readers
---	--