

CODE CM-SR900 Series Solace LED Mirror Instruction Manual

Home » code » CODE CM-SR900 Series Solace LED Mirror Instruction Manual

CODE CM-SR900 Series Solace LED Mirror
Instruction Manual

Instruction manual of LED mirror - SOLACE

IMPORTANT


- This is a high quality product and must be installed and maintained as per these instructions or it may invalidate the Warranty.
- When using electrical appliances, comply with basic safety precautions in order to reduce the risk of fire, electric shocks and personal injury.
- Input voltage of this product is 220V~240V. The power supply must be switched off before installation. Remove fuse or de-activate it, and make sure that it cannot be reactivated.
- All electrical works/connections must be done by a qualified electrician. Any failure to follow this can be particularly dangerous to users and will invalidate the warranty.
- DO NOT spray cleaning solutions directly to the glass. We recommend spraying cleaner directly to a soft cloth before applying.
- The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Children should be supervised so that they do not to play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Contents

- 1 Power ON/OFF
- 2 Wireless Music
- **3 INSTALLATION**
- 4 Documents /
- Resources
- 4.1 References


Power ON/OFF

- Press o to turn power on and off.
 The defogger is turned on or off with the mirror light.
- When the power in on, press and hold the touch switch to adjust brightness of the light.



Wireless Music

- On your phone/pad, enable your Bluetooth function.
- Search for 'Elite mirror' and Pair the mirror with your phone/pad
- Enter Password
- The light & demister do not have to be on to use the music function. However there must be power to the unit.




• Decide what height (X) the mirror (top of mirror) sits from floor. Work out height (Y) of wall bracket holes position from floor.

Height Y = Height X - H (you can find H of your mirror in the table provided)

Step 2

• Fix the wall bracket in the required position. Please make sure there is timber fixing behind OR there is enough support to hold the mirror unit.



	Model		Distance "H"
CM-SRT1645	(install horizontally)		133mm
CM-SRT8060	CM-SRT8075	CM-SRT9075	
CM-SRT1675	(install horizontally)		
CM-SRT1575	(install horizontally)		163mm
CM-SRT1075	(install horizontally)		
CM-SRT1275	(install horizontally)		
CM-SR650	CM-SR750	CM-SR900	
CM-SO5080	CM-SO6090	CM-SA4590	203mm
CM-SR700B	CM-SR900B	CM-SO5080B	
CM -SRM700B	CM -SRM900B	CM-SA4590B	
CM-SRT1075	(install vertically)		
CM-SRT1275	(install vertically)		
CM-SR1100	CM-SR1050B	CM -SRM1100B	
CM-SRT1575	(install vertically)	11.0	273mm
CM-SRT1645	(install vertically)		
CM-SRT1675	(install vertically)		

Step 3

- Get a qualified electrician to connect the cable to the power supply.
- · Hang the mirror up.





CODE CM-SR900 Series Solace LED Mirror [pdf] Instruction Manual

CM-SRT1645, CM-SRT8060, CM-SRT8075, CM-SRT9075, CM-SRT1675, CM-SRT1575, CM-SRT1075, CM-SRT1275, CM-SR650, CM-SR750, CM-SR900, CM-SR900 Series Solace LED Mirror, CM-SR900 Series, Solace LED Mirror, LED Mirror, Mirror

References

• User Manual

Manuals+, Privacy Policy