



## COLOP e-mark Create User Manual

[Home](#) » [colop](#) » COLOP e-mark Create User Manual 

### Contents



- [1 COLOP e-mark Create User Manual](#)
- [2 QUICK SET UP GUIDE](#)
- [3 PRINTING AT A GLANCE](#)
- [4 MENU GUIDE](#)
- [5 IMPRINT SETTINGS](#)
- [6 MULTI-LINE PRINTING](#)
- [7 CONTINUAL PRINTING](#)
- [8 AUTOMATIC CLEANING CYCLE](#)
- [9 LIGHT GUIDE](#)
- [10 Questions about your Manual? Post in the comments!](#)
  - [10.1 Related Posts](#)

### COLOP e-mark Create User Manual



### QUICK SET UP GUIDE

For complete instructions visit: [emarkcreate.colop.com/support](http://emarkcreate.colop.com/support)




## PRINTING AT A GLANCE



- In the app select New Imprint from the drop down menu.
- Choose Start Without Template or select a pre-made template from your preferred category.
- Arrange or edit your artwork on the canvas.

- Once your design is ready to go select the e-mark® create icon in the top right corner.
- The e-mark® create will beep & the app will indicate when your print has been received.
- Simply swipe e-mark® create to print your design.

## MENU GUIDE




- Print your design
- Connect your e-mark® create check battery & ink levels
- Choose a customizable template or design your own.
- View, edit or print a previous design.  
Updated preferences, clean print head, & more.
- Web instructions, order ink cartridges, & more

## IMPRINT SETTINGS



- Choose between single line or multi-line canvas.
- Adjust the width of your canvas.
- Turn continual printing on or off.

## MULTI-LINE PRINTING



- Choose either two or three line printing option.
- Once your design is ready to go select the e-mark® create icon in the top right corner.
- The e-mark® create will beep & the app will indicate when your print has been received.
- Follow the chart above to print each line. The e-mark® create will beep to indicate when you should change direction.

## CONTINUAL PRINTING



- Make sure continual marking is turned on in imprint settings.
- Once your design is ready to go select the e-mark® create icon in the top right corner.
- The e-mark® create will beep & the app will indicate when your print has been received.
- Swipe e-mark® create to print your design. The e-mark® create will continue to print as long as it is in motion.

## AUTOMATIC CLEANING CYCLE



The e-mark® create cleans its print head automatically whenever it is taken from the docking station. The intensity of cleaning increases the longer the e-mark® create is not used.

- Take e-mark® create from docking station.
- Hold briefly in the air (wait for ink to disperse).
- Put on Paper & print.

Do not point towards the eyes, face, or skin. Do not point towards docking station or towards the print surface during the cleaning cycle.

## LIGHT GUIDE



**Continuous Green Light**  
On, not connected via WIFI.



**Continuous Green & Blue Lights**  
On & connected to WIFI



**Flashing Yellow Light**  
Charging, battery is charged between 0-49%.



**Flashing Green Light**  
Charging, battery is charged above 49%.



**Continuous Green Lights**  
Plugged in and fully charged.



**Flashing Red Lights**  
Return e-mark create® to the docking station.

Read More About This User Manuals...

[COLOP-e-mark-Create-Manual-Optimized.pdf](#)

[COLOP-e-mark-Create-Manual-Original.pdf](#)

—

Questions about your Manual? Post in the comments!