



COMET Accupack A8205 Replacement Procedure Instruction Manual

[Home](#) » [COMET](#) » COMET Accupack A8205 Replacement Procedure Instruction Manual 



Accupack A8205 Replacement Procedure Instruction Manual

Contents

- [1 Accupack A8205 Replacement Procedure](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)
- [3 Related Posts](#)

Accupack A8205 Replacement Procedure


The accupack is designed exclusively for dataloggers: U0110M, U0121M, U0141M, U0843M, U2422, U3120M, U3121M, U3430, U3631M, U4440, U4440M, U5841M, U6841M, U7844M, U8410, U8410M

WARNING

- Replacement may only be carried out by a qualified service technician
- Read this procedure in detail before you replace it
- To add any additional information provided here, use manuals and other documents available in the Downloads section for a particular device at www.cometsystem.com

- Turn off the device:
 - press and hold down the lower button and release the button when the menu item bar lights up
 - briefly press the upper button – press the upper button briefly again to select OFF

- press the lower button to turn off the device
- Unscrew the rear of the device where the accu is located (use the TORX T10 screwdriver)
- Disconnect the old accupack from the device
- Connect the USB charger to the device, and wait until the full battery symbol will be permanently lit (see fig.)



- Unpack the new A8205 accupack, check and, if necessary, adjust the position of the seal in the groove
- Compare the nominal capacity data of the old and new accupack, if they differ, contact the manufacturer or distributor of the device
- Again check that the fully charged battery symbol is on the display and then connect the new accupack to the device -! failure to observe this step can lead to the destruction of a new accupack!
- Assemble the device (the screws tighten gently)
- Charge the unit fully (full-battery symbol must be permanently lit):
 - When charging, the device must be installed indoors with a maximum humidity of 85%, at an indoor temperature ranging between 0°C and +40°C.
- Turn device ON

**COMET SYSTEM, s.r.o., Bezrucova 2901,
756 61 Roznov pod Radhostem, Czech republic
I-Igr-A8205-04
Specifications are subject to change without notice.**

Documents / Resources



[COMET Accupack A8205 Replacement Procedure](#) [pdf] Instruction Manual
Accupack A8205 Replacement Procedure, Accupack, Accupack Replacement Procedure, A8205 Replacement Procedure, Replacement Procedure, A8205, U0110M, U0121M, U0141M, U0843M, U2422, U3120M, U3121M, U3430, U3631M, U4440, U4440M, U5841M, U6841M, U7844M, U8410, U8410M

References

- [Manufacturer of Dataloggers, Thermometers, Hygrometers, CO2 meters](#)
- [Manufacturer of Dataloggers, Thermometers, Hygrometers, CO2 meters](#)
- [Výrobce snímačů teploty, vlhkosti, atmosférického tlaku, dataloggerů, monitorovacích systémů](#)
- [Výrobce snímačů teploty, vlhkosti, atmosférického tlaku, dataloggerů, monitorovacích systémů](#)