




Comiso Speaker Instructions: X26 Waterproof Wireless Bluetooth Speaker Manual

[Home](#) » [COMISO](#) » **Comiso Speaker Instructions: X26 Waterproof Wireless Bluetooth Speaker Manual** 

The Comiso X26 Waterproof Wireless Bluetooth Speaker is a versatile and portable speaker that offers high-quality sound and a range of useful features. This instruction manual provides detailed information on how to use the speaker, including precautions to take when cleaning or handling it, how to charge and power on/off the device, and how to pair it with other Bluetooth-enabled devices. The manual also includes troubleshooting tips, specifications, and warranty information. Customers can rely on the Comiso X26 to provide an enjoyable listening experience both indoors and outdoors, thanks to its waterproof design and long-lasting battery life. If customers have any questions or concerns about the product, they can contact Comiso's customer support team for assistance. Overall, the Comiso X26 is a reliable and user-friendly speaker that is perfect for anyone looking for a high-quality audio experience on-the-go.



X26 Waterproof Wireless Bluetooth Speaker Instruction Manual



Contents

- [1 Precaution](#)
- [2 Accessories](#)
- [3 Product Overview](#)
- [4 Functions](#)
- [5 Troubleshooting](#)
- [6 Warranty Service](#)
- [7 Specifications](#)
- [8 Warranty Card](#)
- [9 FCC Statement](#)
- [10 Documents / Resources](#)
- [11 Related Posts](#)

Precaution


1. It is normal that the speaker will get hot in playing or charging.
2. Please turn off the speaker and disconnect it with all audio devices before cleaning. Do not use alcohol, benzene, or other chemicals to clean the speaker.
3. Do not throw or tread on the speaker. Please place it on a stable surface when in use.
4. Do not place the speaker close to extremely cold or hot objects.
5. Please use the original accessories provided by us. 6. Do not disassemble the speaker without authorization.

Accessories

Charging Cable x 1 Instruction x 1 Hook x 1









Product Overview

1. Vol-(Previous track)
2. Vol+(Next track) 0 Play/Pause
3. Power ON/OFF
4. TWS pairing
5. Reset
6. Indicator light
7. Mic





Functions

1. **Charging:** Please fully charge the speaker for about 5-6 hours before first use. (The indicator light is red when charging, and it will turn to green after fully charged.) Use the original charging cable to connect to the power adapter (DC 5V/1A) to get charged.
2. **Power On/Off:** Long press the power button' ('until the blue indicator light flashes, then release the power button, the speaker turns on with a prompt tone.
3. **Bluetooth Pairing:** After turning on, the blue indicator light keeps flashing quickly. Then open your smartphone's Bluetooth function, search for and choose "comiso-X26". After successful pairing, you will hear the "di-di" prompt tone. Now you can play music on your smartphone with this speaker.
4. **Automatic Connection:** If you already paired it with a phone, tablet, or other Bluetooth device, when It turns on (not for the first time), the speaker will automatically pair with this smartphone.
5. After paired successfully, the blue light stays lighting, and you can play music or video via it, and you can check the battery level on your phone.
6. When you are playing music via Bluetooth, short press "+" to increase the volume, long press "+" to listen to the next song
7. When you are playing music via Bluetooth, short press "-" to decrease the volume, long press "-" to listen to previous song.
8. When the speaker is connected with the IOS device, the volume control is synchronized.

9. After paired successfully, short press "  " to play and pause.
10. After paired successfully, when there is a calling, short press "  " button to pick up the call by this speaker, long-press the "011- button for 2 seconds to reject this call, and when answering the call, short press the  " button to end it. Redial: double press the "  " button, your smartphone will redial your last dialed number.
11. .Automatic Power Off: the speaker will turn off in 10 minutes in the below situations to save battery power: A: the device is not connected B: the phone is out of transmission range. C: the Bluetooth is turned off on your phone.
12. Pair to Another Smartphone: Method A: Turn off the smartphone A's Bluetooth function, you will hear the "  " prompt tone and the blue indicator light will turn to flash quickly. Then the smartphone B can search for "Comiso -X26" and choose it to pair. Method B: Long press the "  " button for 3 seconds until you hear the " prompt tone, the blue indicator light will turn to flash quickly, it means that the smartphone B could search for "Comiso -X26 " and choose it to pair.
13. Clear Paired Information: The speaker can remember up to 8 device's pairing information, if you need to clear this information, turn on the speaker, and long-press the "A" button for 6 seconds until you hear the "di-di" prompt tone and the pairing information list is cleared.
14. TWS connection: Power on the two speakers.do not pair it with your phone, first short press the "  " button of each speaker to set them into the TWS pairing mode, and the blue indicator flashes twice with a "di-di- prompt tone after being paired successfully. And then open the Bluetooth in your phone to connect one of the Comiso-X26 to play music. Under TWS mode, long press "  " of either speaker to disconnect the TWS function.
15. Low Battery Warning: When the speaker's battery is less than 20%, the red indicator light will flash, then please charge the speaker. When the battery is less than 5%,it will turn off automatically.
16. If the speaker is not to be used for a long time, please fully charge it at least once a month to avoid decreasing the speaker battery life.
17. Note: When speakers are in TWS pairing mode, all the control functions are in sync, so please only operate one of them.

Troubleshooting

1. The "Comiso-X26" device is in the smartphone's Bluetooth device list, but failed to connect. Reason A: The speaker is not in pairing mode Solution: Long press the "  " button for about 3 seconds to set it to pairing mode, when the blue indicator light flashes fast, choose "comiso-X26" to pair. Reason B: The speaker's paired information has been cleared. Solution: Delete the device "comiso-X26" in your phone, then search"comiso-X26- and choose it to pair again.
2. The smartphone could not search"comiso-X26". Reason: The speaker is not in pairing mode. Solution: Long press the "  " button for about 3 seconds to set it into pairing mode, when the blue indicator light flashes fast, choose "Comiso-X26" to pair.
3. The charging time is too long. Reason: The adapter's power output is too low, and the charging cable's

consumption is too high. Solution: Please choose the adapter with output not less than DC 5V/1A and use the original charging cable.

Warranty Service

We provide the following warranty services:

1. 12-month warranty for quality-related issues: Within 12 months after the date of purchase, we take care of all quality-related issues with a replacement or full refund.
2. Within the warranty validity, we provide free after-sale service, except for the following cases: A. No original warranty card or valid invoice. B. The speaker's malfunction or damage is caused by force majeure, incorrect operation (not as this instruction manual directed) or any man-made factors. C. The speaker is not purchased from an authorized dealer and no authorized dealer's stamp on the warranty card. D. The date of purchase on the warranty card has been changed. E. The speaker's malfunction or damage appears during shipment. F. The speaker's malfunction or damage is caused by disassembly or repairing without authorization.

Specifications

Bluetooth Solution	BK5.0+TW5
Waterproof level	IPX65
Voltage input	DC5V/1A
RMS Power	6W*2
Speaker	040*2 406W
Battery	lithium 3.7V/ 2200 mAh
Product Size	D70mm * H150.5mm
Product Weight	390g

Warranty	12-month warranty for quality-related issues
FCC Statement	Complies with part 15 of the FCC Rules
RF Exposure Information	Meets general RF exposure requirements
Customer Support	Email support@comiso.com.cn

Warranty Card

Please ask the dealer to fill out the warranty card immediately after purchasing. We recommend keeping this card for future reference.

Name		Age	
Tel Num.		Postcode	
Gender		Product	
Date of Purchase		Product Code	
Part Num.		Sale Num.	
Postal Address			

Dealer Stamp:..... User Signature:



..... Company:Qing UG (haftungsbeschränkt) Address:Undinestr. 712203 Berlin E-Mail:pmdheinrich@gmail.com

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. **RF Exposure Information** The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Customer Support: If you have any questions about this product, please email us via support@comiso.com.cn. Our customer support team will handle it for you.

FAQS

How can I contact customer support if I have questions or concerns?

You can email us via support@comiso.com.cn for customer support.

What is the warranty period for this product?

We provide a 12-month warranty for quality-related issues from the date of purchase.

What should I do if the speaker fails to connect to my smartphone?

If the speaker is not in pairing mode, long press the " " button for about 3 seconds to set it into pairing mode. If the speaker's paired information has been cleared, delete the ice "comiso-X26" in your phone, then search "comiso-X26" and choose it to pair again.

What should I do if the speaker's battery is low?

When the battery is less than 20%, the red indicator light will flash. Please charge the speaker at this point. If it is less than 5%, it will turn off automatically.

How do I connect two speakers using TWS pairing?

Power on the two speakers and short press the " " button of each speaker to set them into TWS pairing mode. The blue indicator flashes twice with a "di-di" prompt tone after Being paired successfully. Then open Bluetooth in your phone to connect one of the Comiso-X26 to play music.

How do I clear paired information from the speaker?

Turn on the speaker and long-press the "A" button for 6 seconds until you hear the "di-di" prompt tone and the pairing information list is cleared.

How do I answer or reject a call using the speaker?

When there is a call, short press " " button to pick up the call by this speaker, long-press the "011-" button for 2 seconds to reject this call. When answering the call, short press the " " button to end it.

How do I play/pause music via Bluetooth?

After successfully pairing, short press " " to play and pause.

How do I increase or decrease the volume while playing music via Bluetooth?

Short press "+" to increase the volume and short press "-" to decrease it.

How do I pair the speaker with my Bluetooth-enabled device?

After turning on the speaker, the blue indicator light will flash quickly. Then open your smartphone's Bluetooth function, search for and choose "comiso-X26". After successful pairing, you will hear the "di-di" prompt tone.

How do I power on/off the speaker?

Long press the power button until the blue indicator light flashes, then release the power button to turn on the speaker. To turn it off, long press the power button again until the indicator light goes off.

How long does it take to fully charge the speaker?

It takes about 5-6 hours to fully charge the speaker before first use.

How should I clean the speaker?

Before cleaning, turn off the speaker and disconnect it from all audio devices. Do not use alcohol, benzene, or other chemicals to clean the speaker.

Documents / Resources



[comiso X26 Waterproof Wireless Bluetooth Speaker](#) [pdf] Instruction Manual
0260, 2AEZG-0260, 2AEZG0260, X26, Waterproof Wireless Bluetooth Speaker