

Height Adjustable Computer Desk User Manual

Home » Computer Desk » Height Adjustable Computer Desk User Manual



Height Adjustable Computer Desk User Manual



Contents

- 1 Safety Instructions
- **2 Package Contents**
- **3 Specifications**
- **4 Assembly Instructions**
- 5 Documents /
- **Resources**
- **6 Related Posts**




- 1. Children are not allowed to operate this product without sufficient supervision guidance provided by adults.
- 2. Never crawl under the desk for safety concerns.
- 3. Ensure that no obstacles are in the desk's patch.
- 4. Do not sit or stand on the desktop.
- 5. Never put an object over the desk's weight capacity on desktop.

Package Contents



Desk Body x 1






Side Bracket x 2

Actionto Window


Specifications

Overall Dimensions (Lx W x H	31 1/2" x 23 5/8" x 17" (80 x 60 x 43 cm)
Weight Capacity	33 lbs (15 kg)
Adjustable Height	from 5 1/8" to 17" (from 13 to 43 cm)

Assembly Instructions



Keep pressing the lock bars on both sides of the desk and lift the desktop up.



Loosen the knobs under both sides of the desktop a little bit. After that, hook the brackets with the knobs respectively and then retighten the knobs.



next step.





Fasten the keyboard tray on the two side brackets with the four screws as shown above.

Documents / Resources



<u>Computer Desk Height Adjustable Computer Desk</u> [pdf] User Manual Computer Desk

Manuals+,