



CONAIR Compact Rollers HS29T Instruction Manual

[Home](#) » [ConAir](#) » CONAIR Compact Rollers HS29T Instruction Manual 



IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER DANGER

To reduce the risk of electrocution:

1. Always unplug this appliance immediately after using it.
2. Do not use while bathing.
3. Do not place or store appliances where they can fall or be pulled into a tub or sink.
4. Do not place in or drop into water or other liquids.
5. Do not reach for an appliance that has fallen into the water. Unplug immediately.

WARNING – To reduce the risk of burns, electrocution, fire, or injury to persons:

1. An appliance should never be left unattended when plugged in.
2. Do not touch the posts that hold the rollers. They are hot.
3. This appliance should not be used by, on, or near children or individuals with certain disabilities.
4. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Conair.
5. Never operate this appliance if it has a damaged cord or plug if it is not working properly, if it has been

dropped or damaged, or dropped into water. Return the appliance to an authorized Conair service center for examination and repair.

6. Keep the cord away from heated surfaces.
7. Never block the air openings of the appliance or place them on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
8. Never use while sleeping.
9. Never drop or insert any object into any opening.
10. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
11. Use setter on a level surface.
12. Do not wrap the cord around the appliance.
13. Do not use a voltage converter.
14. Do not use an extension cord with this appliance.
15. The Center of rollers will be hot. Hold rollers by ends to roll hair.

SAVE THESE INSTRUCTIONS

Contents

- 1 OPERATING INSTRUCTIONS**
- 2 INSTANT HEAT**
- 3 Documents / Resources**
- 4 Related Posts**


OPERATING INSTRUCTIONS

How to Operate Your Setter

1. Place setter on a firm, flat surface. With the pouch lid closed, plug the cord into the outlet. This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
2. Once plugged in, the rollers will heat up in minutes. The fastest, most efficient heat-up is provided when the pouch lid is closed. Once the rollers are hot, you can begin styling your hair. (Please refer to How To Curl and Style Your Hair for further instruction.)
3. Never leave your setter plugged in and unattended. Always unplug the setter when not in use. Allow the Setter to cool down after use. Store the unit in a safe place.
4. When using the setter, your hair should be clean and dry (or slightly damp), never wet.

INSTANT HEAT


12-ROLLER COMPACT SETTER



Features:

- 12 ceramic rollers: 8 large (1 in.), 4 medium (3/4 in.) for better heat transfer
- 12 wire clips
- Compact pouch for easy storage and travel
- Dual voltage (120 or 230 volts, 60/50 Hz)
- Starter strips grip hair on rollers
- Heating base with 12 universal posts

How to Order Extra Rollers and Clips



Each replacement pack comes with three rollers and clips. Each order for any size roller must be for three rollers minimum. Fill out the order form and send a check or money order payable to:

Conair Corporation
150 Milford Rd.

Model	Description	Price
RP308	3 Large Rollers	\$6.00
RP309	3 Medium Rollers	\$5.00

Please add postage and handling to all orders. Postage and handling are as follows: Any order up to \$5.00 – add \$.50 to order. Any order from \$5.01 to \$10.00 – add \$1.00 to order. Any order from \$10.01 and over – add \$1.50 to order.

Name:

Address:

City: _____ State: _____ ZIP: _____

Daytime Phone: () _____

Model #:

Qty:

Note: Prices are subject to change without notice.

How To Curl and Style Your Hair



MEDIUM ROLLERS


Use on short to medium-length hair to create fullness or a tight curl. Tight curls can be created at the nape of the neck and used to frame your face.



LARGE ROLLERS

Can be used on medium to long hair to create a romantic, pretty, and full curl.

Place ends of hair in teeth of starter strip and wind toward the scalp. Roll hair firm and secure roller with a clip by crossing clip over the roller.



The firmness of the curl is regulated by several factors: heat-up time, the diameter of the roller, and the length of time the roller is left in the hair. For tight, firm curls, use small rollers. For longer-lasting curls, the rollers should be allowed to heat up longer and be left in the hair for a longer period of time before removing.

For soft, romantic curls and volume, use large-sized rollers. **IMPORTANT: After using the styling setter several times, you will find the best combination for your hair and the results you desire.**

4. To remove rollers, hold the roller in one hand and remove the clip with the other hand. Gently drop roller (**DO NOT PULL**), and let curl bounce back once roller has been removed from the hair. Let cool for one minute for a good set, then style your hair as desired.

MAINTENANCE

Your setter is designed for household use and is virtually maintenance-free. This product represents the highest standards of workmanship and engineering research.


If cleaning becomes necessary, disconnect the appliance from the power source. Allow the setter to cool. Clean the unit with a cloth. (Occasionally you may want to clean rollers. Use a damp cloth and mild detergent or soap.) If any abnormal condition occurs, unplug the styling setter, allow it to cool, and return it to an authorized service representative for repair.

STORAGE

Allow setter to cool. Handle cord carefully to prolong its life; avoid jerking or straining at plug connections. Place setter out of reach of children in a safe, dry location.

WARNING: IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF, YOU'RE WRONG.

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES

LIMITED ONE-YEAR WARRANTY (U.S. & CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed on the back, together with your purchase receipt and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.




Please register this product at: www.conair.com/registration

SERVICE CENTER CONAIR CORPORATION

Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307
©2016 Conair Corporation
150 Milford Road
East Windsor, NJ 08520
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307
tal.2017.04.01
16PH022328
IB-14494

Documents / Resources



[CONAIR Compact Rollers HS29T](#) [pdf] Instruction Manual
CONAIR, HS29T, Compact, Rollers