



## CONKER NS6 2D Rugged Tablet with Barcode Scanner Instruction Manual

[Home](#) » [CONKER](#) » CONKER NS6 2D Rugged Tablet with Barcode Scanner Instruction Manual 

CONKER NS6 2D Rugged Tablet with Barcode Scanner Instruction Manual



## Contents

[1 Device Specifications](#)

[2 HOW TO USE YOUR NS6 RUGGED  
DEVICE](#)

[3 INSTALLING SIM AND MEMORY CARD](#)

[4 GET IN TOUCH](#)

[5 Documents / Resources](#)


[5.1 References](#)

[6 Related Posts](#)

## Device Specifications


OS	Windows 10 Enterprise	Audio	Waterproof, built-in microphone and speaker
CPU	Intel Quad-Core 1.44GHz	Display	6" IPS Resolution 1280 x 720
IP Rating	IP67	Touch	Capacitive Multi-touch with toughened glass
Drop Test	1.2m	Dimensions/ Weight	185x 93 x 20mm /380g
Battery	5000 mAh	Camera	5.0 MP rear camera with flash 2.0 MP front camera
Wireless Connectivity	Wi-Fi: 802.11 a/b/g/n Dual band, supports Wi-Fi hotspot Bluetooth: 4.1 3G/4G GPS: uBlox Tethering and casting	Ports	USB: Micro USB 2.0 port (supports OTG) Micro SDXC: up to 32GB SIM: Micro SIM Docking: 4 pin pogo
Memory	4GB memory 64GB storage	Other Features	Optional 2D barcode scanner

## HOW TO USE YOUR NS6 RUGGED DEVICE




1. Front camera
2. Ear piece
3. Home button
4. Barcode scanning window
5. Loud speaker
6. Back camera
7. NFC antenna
8. Micro USB/ headphone jack
9. Power button
10. Volume up +
11. Volume down –
12. Barcode trigger
13. Unused

## INSTALLING SIM AND MEMORY CARD




Power off the phone before changing the SIM or Memory Card

Always use the right size of SIM card



The battery is secured in place by a sliding lock as shown below. Slide it to the left and release the battery as shown in the following diagrams



**GET IN TOUCH**



To contact Conker Support:  
01279 295830

[Support@weareconker.com](mailto:Support@weareconker.com)

Conker  
Calf Pens  
Hatfield Park Farm  
Takeley  
CM22 6NG

### **CE Marking and European Economic Area**



Tablet Technologies hereby declares that this equipment is in compliance with Directive 2011/65/EU and 1999/5/EC or 2014/53/EU. The following standards have been applied and tested. Conformity is limited to the essential requirements of the R&TTE.

### **For your safety**

To reduce the potential risk of injury and or damage to equipment or property, always observe the following safety precautions.



## **WARNING**

Do not attempt to repair or modify the product as this could cause harm and will void any warranty.

Do not expose your skin to the product or AC adaptor when using the product for prolonged periods.

Do not puncture the product or battery.

Use only the specified battery (supplied).

Use only the specified AC adaptor (supplied).

Ensure all port and interface covers are closed before exposing the product directly to water or elevated levels of moisture or dust.

Packaging and accessories are choking hazards and should be kept out of reach of children.

Do not operate the product while driving.

Do not expose the AC Adaptor to water and do not use Adaptor when faulty.

Prolonged use of headphones can lead to a loss of hearing.



## CAUTION

Do not operate the product if it shows any visible signs of damage.

To prevent injury or harm, avoid looking directly at the flash or where applicable, the laser barcode scanner.

Do not expose the product to extreme temperatures for a prolonged period. Do not expose the product directly to your skin in extreme temperature environments.

## Battery



## DANGER

The battery is for use solely with the specified product. Do not use it with any other products.

Do not use the battery if it becomes noticeably damaged or deformed.

Do not crush, bend, deform, puncture, shred, throw, or apply high pressure to the battery.

Only charge the battery with the supplied charger or cradle.

Do not subject the battery to an open flame or expose it to excessive heat.


Contents can combust under pressure.

If the electrolyte from the battery comes into contact with the eyes, skin, or clothing, rinse thoroughly with cold water and seek medical advice.

## Battery Information



**CAUTION.** Use only approved batteries. Risk of explosion if battery is charged with an incompatible charger, exposed to heat >60°C or replaced by an incorrect type.



European Battery Directive 2006/66/EC

Dispose of batteries separately and responsibly. All waste batteries are classified as hazardous waste and should be disposed of at a battery recycling centre.



Our rechargeable battery packs are designed and constructed to the highest standards within the industry. However, there are limitations to how long a battery can operate or be stored before needing replacement. Many factors affect the actual life cycle of a battery pack, such as heat, cold, harsh environmental conditions and severe drops. Batteries are considered chemical products. As such, battery performance will deteriorate over time if stored for a long period of time without being used. When batteries are stored over six (6) months, some irreversible deterioration in overall battery quality may occur. Store batteries at half of full charge in a dry, cool place, removed from the equipment to prevent loss of capacity, rusting of metallic parts and electrolyte leakage. When storing batteries for one year or longer, the charge level should be verified at least once a year and charged to half of full charge.

Replace the battery when a significant loss of run time is detected. Standard warranty period for all batteries is one year from order fulfilment, regardless if included as part of a mobile computer with a longer warranty duration or ongoing maintenance contract. The cycle life of batteries will vary according to the charge and discharge conditions, the temperature and other usage conditions. When used in accordance with the IEC charge and discharge specifications the typical cycle life of a battery is between 300 and 400 cycles at room temperature. Individual results may vary.


Lithium batteries do not suffer from “battery memory” therefore you do not need to fully charge to 100% or fully discharge to 0%. Complete discharge of batteries should always be avoided. Shallow discharge is preferable, i.e. recharge at 20% if possible.

### **Battery Safety Guidelines**

- The area in which the units are charged should be clear of debris and combustible materials or chemicals.
- Improper battery use may result in a fire, explosion, or other hazard.
- To charge the mobile device battery, the battery and charger temperatures must be between 0°C and +40°C (+32°F to +104°F).
- Do not use incompatible batteries and Use of an incompatible battery or charger may present a risk of fire, explosion, leakage, or other hazard. If you have any questions about the compatibility of a battery or a charger, contact Tablet Technologies support.
- For devices that utilize a USB port as a charging source, the device shall only be connected to products that bear the USB-IF logo or have completed the USB-IF compliance programme.
- Do not disassemble or open, crush, bend or deform, puncture, or shred.
- Severe impact from dropping any battery-operated device on a hard surface could cause the battery to overheat.
- Do not short circuit a battery or allow metallic or conductive objects to contact the battery terminals.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, or expose to fire, explosion, or other hazard.
- Do not leave or store the equipment in or near areas that might get very hot, such as in a parked vehicle or near a radiator or other heat source.
- Do not place battery into a microwave oven or dryer.
- Battery usage by children should be supervised.
- Please follow local regulations to promptly dispose of used re-chargeable batteries.
- Do not dispose of batteries in fire.
- Seek medical advice immediately if a battery has been swallowed.
- In the event of a battery leak, do not allow the liquid to come in contact with the skin or If contact has been made, wash the affected area with large amounts of water and seek medical advice immediately.
- If you suspect damage to your equipment or battery, contact Tablet Technologies support to arrange for

inspection.

Documents / Resources

	<p><a href="#">CONKER NS6 2D Rugged Tablet with Barcode Scanner</a> [pdf] Instruction Manual NS6 2D Rugged Tablet with Barcode Scanner, NS6, 2D Rugged Tablet with Barcode Scanner</p>
---	--

References

-  [Best Conker Rugged Devices | #1 Reliable Tech Solutions](#)