Manuals+ — User Manuals Simplified.

connect2go UNO5500 Security System Keypads
System Keypads

connect2go UNO5500 Security System Keypads User Guide

Contents

connect2go UNO5500 Security System Keypads

Specifications

- **Product Model:** UNO5500 & UNO5500RF
- **Manufacturer**: Connect2Go
- **Address**: PO Box 3382 Station Main, Meaford, ON, Canada N4L 1A5
- **Contact**: (+1) **647-503-3406**
- **Website**: **www.connect2go.com**

Product Information:
The UNO5500 & UNO5500RF are advanced security systems designed to provide comprehensive monitoring and control capabilities for residential and commercial properties. With a user-friendly interface and robust features, these systems offer peace of mind and enhanced security.

Product Usage Instructions

- **SPECIAL BUTTONS:**

  The system includes special buttons for specific functions. Refer to the user manual for detailed information on

  each button's functionality.
- **IDLE SCREENS:**

  When the keypad is inactive, the LCD will display various status modes including system time, system status,

  open zones, or trouble conditions. Monitor the screen for important alerts or information.
- **MENU STRUCTURE:**

  The menu structure provides access to different settings and features of the security system. Navigate through

  the menu options using the keypad or touchscreen to customize the system according to your preferences.

The UNO5500 and UNO5500RF are full-message, graphic display security system keypads designed to work with a UNO Alarm Panel. The UNO5500 can also be used as a retrofit on a DSC Power Series system. The UNO5500RF contains an RF receiver that can work to pick up either SOLO-formatted sensors or DSC-format sensors. You can have multiple UNO5500RF keypads on a system and they will act as range extenders.

For installation instructions see the UNO5500/UNO5500RF Keypad User Guide under **www.connect2go.com/guides**.

SPECIAL BUTTONS

1. **STAY ARM –** Press and hold to cause the system to arm in STAY mode.
2. **AWAY ARM** – Press and hold to cause the system to arm in AWAY mode.
3. **PANIC** – Press and hold to initiate an emergency signal.

IDLE SCREENS
The LCD will display various status modes while the keypad is inactive, cycling between the system time, the system status, and any open zones or trouble conditions that may exist.

MENU STRUCTURE

- **ARMING/DISARMING** – these sequences can be initiated any time the keypad is not otherwise active by simply entering your 4-digit user code. The screen will display confirmation of arming status.
- **Functions** – Pressing the * key will display a menu of various options that can be selected.

Once in the * menu you can select the following options:

- **1 – Bypass**. Enter the zone number that you wish to bypass.
- **2 – Troubles.** Will display a list of current system troubles.
- **4 – Chime.** Selecting 4 will toggle the Door Chime feature on an off.
- **7 – PGM Toggle.** Follow this with a number for the PGM. For example, entering *71 will toggle PGM 1.

Functions – pressing the # button and the following buttons at the same time will jump to the menu indicated.

- **1 – User Configurations.**
  - **LCD Contrast** – Adjust the contrast of the LCD here.
- **3 – Installers.**
  - **Partition** – Select the partition for the keypad.
  - **Slot** – Select slot for the keypad
  - **RF Format** – Choose between SOLO RF format and DSC RF format.

Connect2Go PO Box 3382 Station Main, Meaford, ON, Canada N4L 1A5 T: (+1) **647-503-3406**
www.connect2go.com

FAQ

Q: How do I reset the system?
A: To reset the system, navigate to the settings menu and look for the reset option. Follow the on-screen instructions to reset the system to its default settings.

Q: How can I add new users to the system?
A: To add new users, access the user management section in the settings menu. Follow the prompts to create profiles for additional users with unique access codes.

Documents / Resources

connect2go UNO5500 Security System Keypads [pdf] User Guide
UNO5500, UNO5500RF, UNO5500 Security System Keypads, UNO5500, Security System Keypads, System Keypads

References

- **User Manual**