



# Conquer CQL1972-B Bluetooth Speaker Instruction Manual

Home » CONQUER » Conquer CQL1972-B Bluetooth Speaker Instruction Manual

#### **Contents**

- 1 Conquer CQL1972-B Bluetooth Speaker
- **2 Product Usage Instructions**
- 3 Getting Started
- 4 To charge the battery
- **5 Playing Music via Bluetooth**
- 6 FCC
- 7 Documents / Resources
  - 7.1 References

# Conquer

Conquer CQL1972-B Bluetooth Speaker



# **Specifications**

Product: CQL1972-B Bluetooth Speaker
 Power Source: Micro USB Charging Cable

LED Light: Syncs with musicCompliance: FCC Part 15

# **Product Usage Instructions**

# **Charging the Speaker**

- 1. Use the included Micro USB Charging Cable to connect the speaker's micro USB port to a power source.
- 2. Connect the other end of the cable to a powered USB source like a computer or USB AC adapter.
- 3. The indicator light will turn red when charging. It will turn off once fully charged.

# Powering ON/OFF

- 1. Slide the [POWER] switch located on the back of the unit to the ON position to power the speaker.
- 2. A tone will be heard, and the LED light will turn on, syncing with your music.
- 3. For best results, adjust the volume for a more dynamic light display.

#### **Safety Precautions**

- 1. This device is not a toy and should be kept away from children.
- 2. Avoid exposure to water and heat to prevent damage.
- 3. Low battery power can lead to poor Bluetooth connection or functionality.
- 4. Do not overcharge the battery to ensure its longevity.

#### **FCC Compliance**

This device complies with FCC Part 15 regulations regarding interference. Follow guidelines for optimal operation.

#### **FAQ**

#### Q: What should I do if the Bluetooth connection is unstable?

• A: Ensure the speaker is adequately charged and within range of the paired device. Avoid obstacles that may interfere with the signal.

#### Q: Can I use the speaker near water?

• A: No, it is recommended to keep the speaker away from water to prevent damage.

# Q: How do I know when the speaker is fully charged?

• A: The indicator light will turn off once the speaker is fully charged.

# **Getting Started**

• Please charge your Bluetooth speaker fully before its first use.

# To charge the battery

- Using a Micro USB Charging Cable (included), insert the USB power cable into the micro USB port located on the back of the speaker.
- Connect the other end of the USB cord to a powered USB source such as a computer, laptop, or USB AC adapter.
- When your Bluetooth speaker is charging, the indicator light will turn red.
- Once your Bluetooth speaker is fully charged, the red light will turn off.

# Powering ON/OFF

- Slide the [POWER] switch on the back of the unit to the ON position to power on.
- A tone will be heard and the LED light on and the speaker will enter Bluetooth pairing mode.
- The speaker will automatically re-pair to any nearby previously paired devices.
- Slide the [POWER] switch to the OFF position to power off.

# **Playing Music via Bluetooth**

- Turn your Bluetooth speaker on by sliding the power switch located on the back of the speaker to the ON
  position to activate the Bluetooth function.
- A tone will be heard and the speaker will enter Bluetooth pairing mode.
- Make sure the Bluetooth function on your device is turned on.

- · Search for the speaker named," XXX".
- Once you have selected the speaker, your device will pair without a password. (If your device prompts for a password, enter the password"0000".)
- Start playing music on your device. Make sure that you keep your device within a 33 feet range of your Bluetooth speaker.
- Adjust the volume of your device to a comfortable level.
- Turn off the unit when not in use.

#### **Using the Light:**

• The LED light will automatically turn on when the speaker is powered on, and dance to the beat of your music. For best results, turn the volume up.

#### Caution:

- This is not a toy. Please keep away from children.
- Please keep away from water/heat.
- Low power may cause poor connection even if not working of Bluetooth.
- Do not overcharge the battery.
- Battery packs shall not be exposed to excessive heat such as sunshine, fire, or the like.

#### **FCC**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference,
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

# **Documents / Resources**



<u>Conquer CQL1972-B Bluetooth Speaker</u> [pdf] Instruction Manual CQL1972-B Bluetooth Speaker, CQL1972-B, Bluetooth Speaker, Speaker

# References

• User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.