CoolKiller CooKiller CK75 **Triple Mode** Transparent Mechanical Keyboard





# CooKiller CK75 Triple Mode Transparent Mechanical Keyboard **User Manual**

Home » Cookiller » Cookiller CK75 Triple Mode Transparent Mechanical Keyboard User Manual



#### **Contents**

- 1 CooKiller CK75 Triple Mode Transparent Mechanical **Keyboard**
- 2 Keyboard lighting settings
- 3 FN Key combination Function list
- 4 Keyboard connection
- 5 Documents / Resources
  - **5.1 References**
- **6 Related Posts**




CooKiller CK75 Triple Mode Transparent Mechanical Keyboard



## **Keyboard lighting settings**



- FN+. : Keyboard lighting mode change.
- FN+< : Monochrome light switch
- FN+Enter: Switch backlight



## FN Key combination Function list

WIN:				MAC:			
FN+ESC	Reset	FN+E7	Pause playback	FN+ESC	Reset	FN+E7	F7
FN+F1	Multimedia	FN+F8	CD Stop	FN+F1	F1	FN+F8	F8
FN+F2	Volume ↓	FN+F9	Email	FN+F2	F2	FN+F9	F9
FN+F3	Volume ↑	FN+E10	IE	FN+F3	F3	FN+E10	F10
FN+F4	Volume mute	FN+FII	My Computer	FN+F4	F4	FN+FII	F11
FN+F5	Last song	FN+F12	Calculator	FN+F5	F4	FN+F12	F12
FN+F6	Next song			FN+F6	F6		

## WIN/MAC:

WIN/MAC:	
FN+1	Bluetooth 1
FN+2	Bluetooth 2
FN+3	B1ietooth 3
FN+4	2.4G mode
FN+5	Wiredmode
FN+ENTER	Switch backlight
FN+、	Light mode switch
FN+<	Monochrome light switch
FN+↑	Backlight brightness↑
FN+↓	Backlight brightness↓
FN+←	Backlight speed reduction
FN+→	Backlight speed plus
FN+Y	Partsc
FN+U	Scrlk
EN+H	Pause
FN+J	Ins
FN+N	Home
FN+M	End



## **Keyboard connection**

• Bluetooth mode: Press and hold the FN+I / 2/3 key combination for 3S to make the keyboard enter pairing

mode, the 1 /2/3 indicator flashes quickly, and the 1 / 2/3 indicator stays on for 3S after connecting to the device, if not connected device, lights off, keyboard goes to sleep.



2.4G Mode: Press and hold the FN+4 key combination for 3S to make the keyboard enter 2.4G mode, the indicator light flashes quickly, insert the 2.4G dongle, exit the pairing after successful pairing, and exit the pairing mode after 30s if the paired device is not found, the indicator light is off, the keyboard go to sleep.



• Wired mode: Press and hold the FN+5 key combination for 3S to make the keyboard enter wired mode.



### **Documents / Resources**



<u>CooKiller CK75 Triple Mode Transparent Mechanical Keyboard</u> [pdf] User Manual CK75 Triple Mode Transparent Mechanical Keyboard, CK75, Triple Mode Transparent Mechanical Keyboard, Transparent Mechanical Keyboard, Mechanical Keyboard

### References

- Your Ultimate Resource for Millions of User Manuals
- User Manual

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.