Manuals+ — User Manuals Simplified.

COOPER CASES CPR185BLK100-FBA Executive Bluetooth Keyboard Instruction Manual

Contents

**COOPER CASES CPR185BLK100-FBA Executive Bluetooth Keyboard**

FEATURES

- Magnetically removable QWERTY keyboard

- 100 hours of battery life

- Claws that hold your tablet securely in place

- Compatible with iPadOS, Android and Windows 10

- Built in stand for the most comfortable viewing angle

- Touchpad with multi-touch gesture capability

  To learn more about your product and it's full feature list, please visit us at **www.coopercases.com**

KNOW YOUR PRODUCT

GET STARTED

- Place the tablet into the case by arranging the 'Tablet Holder Grips' into the corners of your device. The grips are very sturdy. To remove your device, unhook the clamps from corners.
- Place the strap at the back of the case. Magnets will hold it in place so it does not interfere with your viewing.
- Turn the On/Off switch to 'On' (The power indicator light will turn in green for 3 seconds and then switch off.This is just to save battery. Your keyboard is still on).
- Press the combination of keys FN + C (The Bluetooth Indicator light will turn blue to make the keyboard discoverable and be able to pair the device).

Android/ Windows	**On Android tablet:** Open Settings>Bluetooth **On Windows 10 tablet:** Open Settings>Devices>Bluetooth 1. Turn Bluetooth On 2. Search for available devices 3. Choose 'Bluetooth Keyboard' 4. You are connected.

iPadOS	**Connect keyboard:** Open Settings>Bluetooth 1. Turn Bluetooth On 2. Search for available devices 3. Choose 'Bluetooth Keyboard' **Connect Touchpad:** Open Settings>Accessibililty>Touch 1. Turn AssistiveTouch On 2. Select Devices>Bluetooth 3. Choose 'Bluetooth Keyboard' **Adjust pointer speed:** Open Settings>Accessibililty>Touch 1. Adjust tracking speed

Note: Some devices will show a 4,6 or 8 digit pairing code on the screen. Simply type this code on your Touchpad Executive keyboard and hit 'Enter' to connect. If no code is displayed then you can also try 0000 or 1234.

## FUNCTION KEYS

Android Devices
To use the function keys, hold down the 'fn' key on your keyboard and at the same time press your desired function key.

Icon	Function	Icon	Function
⌂	Home	🌐	Language
🔍	Search	⏮	Previous Track
All	Select All	⏯	Play/Pause
📄	Copy	⏭	Next Track
📋	Paste	🔉−	Volume Down
✂	Cut	🔉+	Volume Up
✉	Email	🖱	Deactivate Touchpad

Windows Devices

Icon	Function	Icon	Function
✉	Email	🅔	Internet Explorer
🖱	Deactivate Touchpad		

iPadOS Devices

Icon	Function	Icon	Function
🔍	Search	⏮	Previous Track
🔉−	Volume Down	⏯	Play/Pause
🔉+	Volume Up	⏭	Next Track
🖱	Deactivate Touchpad		

CHARGING THE KEYBOARD

1. Before first use, we recommend charging the Touchpad Executive for a minimum of 6 hours
2. If the Battery Indicator turns red or if your keyboard will not turn on, it is time to charge the keyboard.
3. Connect the keyboard to a computer/wall outlet with the USB Charging Cable.
4. Your keyboard is now charging.
5. When the light turns off, your keyboard is fully charged. This usually takes around 2 hours.
   Note: If you experience any issues with your keyboard (e.g. buttons not working, typing delays or buttons repeating) then please charge your keyboard for 4-6 hours.

TECHNICAL SPECS

- **Operating Distance:** 10 Meters
- **Operation Voltage:** 3.0-4.2 V
- **Operation Current:** <2.5 mA

- **Standby Current:** <0.3 mA
- **Charging Capacity:** 200 mA
- **Uninterrupted Work Time:** 60-100 Hours
- **Key Life:** 3,000,000 Strokes

TROUBLESHOOTING

- Scan the below QR code to watch a helpful video that will help you set up your TOUCHPAD EXECUTIVE Keyboard.
- If you have any questions, drop us an email at **hello@coopercases.com**
- For a digital version of this manual please visit the link below

  coopercases.com/touchpadexec

ACTION 1

One finger tap mode
Tap one time while on main interface. Function: Mouse cursos manipulation

ACTION 2

Tap two times and slide.
Jump out of the mode: See Action 3. Function: Select or move the icon.

ACTION 3

Two fingers tap mode
Tap the pad one time. Function: Cancel the selection.


ACTION 4

Two fingers scroll
Slide fingers up or down. Function: Scroll web page or file up/down or scroll split screen.

ACTION 5

Two fingers zoom

- Slide two fingers in the direction shown in image for zooming in.
- Slide in opposite direction for zooming out. Suitable for PDF pages, images or internet pages that can be zoomed.

ACTION 6

Three fingers swipe down

- Swipe three fingers down.
- Function: Switch between main interface and previous program or page.

ACTION 7

Three fingers swipe up

- Swipe three fingers up.
- Function: Switch between main interface and split screen .

Documents / Resources

	COOPER CASES CPR185BLK100-FBA Executive Bluetooth Keyboard [pdf] Instruction Manual CPR185BLK100-FBA Executive Bluetooth Keyboard, CPR185BLK100-FBA, Executive Bluetooth Keyboard

References

- **Cooper Touchpad Executive Premium Leather Bluetooth Keyboard Tablet Fo - Cooper Cases**
- **Cooper Cases | Best Tablet & Phone Accessories of the Year**