




CORSAIR 2000D AIRFLOW ITX AIRFLOW Mini-ITX PC Case User Guide

[Home](#) » [Corsair](#) » CORSAIR 2000D AIRFLOW ITX AIRFLOW Mini-ITX PC Case User Guide 





**2000D AIRFLOW
ITX – TOWER CASE**

Contents

[1 CASE SPECIFICATIONS](#)

[2 ACCESSORY KIT CONTENTS](#)

[3 CASE FEATURES](#)

[4 FRONT, TOP & SIDE PANELS ARE
REMOVABLE](#)

[5 FAQ](#)


[6 Documents / Resources](#)

[6.1 References](#)






CASE SPECIFICATIONS

Length	271mm
Width	200mm
Height	450mm
Maximum GPU length	320mm
Maximum CPU height	90mm
Maximum PSU length	130mm
Fan locations:	
Front	3x 120mm
Top	1x 120mm slim fan (1x AF120S included)
Rear	2x 120mm*
Side	3x 120mm / 2x 140mm
Radiator compatibility:	
Front	NA
Top	NA
Rear	240mm*
Side	360mm / 280mm


*GPU dependent



ACCESSORY KIT CONTENTS




CASE FEATURES




A — MESH PANELS
B — SIDE FAN BRACKET
C — REAR DUST FILTER

D — 1x AF120S
E — 1x REMOVABLE SSD TRAYS
F — REMOVEABLE PSU SHROUD

FRONT, TOP & SIDE PANELS ARE REMOVABLE




REMOVING SIDE PANELS




REMOVING & INSTALLING FAN / RAD BRACKET


#1




#2




#3





INSTALLING MOTHERBOARD (ITX ONLY)





INSTALLING PSU (SFX & SFX-L ONLY)




INSTALLING PSU (SFX & SFX-L ONLY)





INSTALLING SSD




INSTALLING SSD




INSTALLING TOP FAN



CABLE ROUTING OUT OF THE BACK



FRONT I/O CONNECTIONS



FAQ

1. Does the polarity matter with the I/O panel's power and reset header?

No, only the LED headers.

2. Who should I contact if I received my case damaged or one of the fans is no longer working?

Please go to support.corsair.com and request an RMA so that we can replace the damaged part(s).

3. Where can I mount a fan?

Fan mount locations Front 3x 120mm Top 1x 120mm slim fan Rear 2x 120mm (GPU dependent) Side 3x 120mm / 2x 140mm

To learn more about this case visit the product page at corsair.com.

Web:	corsair.com
Phone:	(888) 222-4346
Warranty:	corsair.com/support/warranty

Support:	support.corsair.com
Blog:	corsair.com/blog
Forum:	forum.corsair.com
YouTube:	youtube.com/corsairhowto




CORSAIR

© 2022 CORSAIR MEMORY, Inc. All rights reserved. CORSAIR and the sails logo are registered trademarks of CORSAIR in the United States and/or other countries. All other trademarks are the property of their respective owners. Product may vary slightly from those pictured.

49-002576 AB



Documents / Resources

 2000D AIRFLOW ITX - TOWER CASE  Front  Top  Right Side  Left Side  Bottom  Rear  Front  Top  Right Side  Left Side  Bottom  Rear	CORSAIR 2000D AIRFLOW ITX AIRFLOW Mini-ITX PC Case [pdf] User Guide 2000D AIRFLOW ITX, 2000D AIRFLOW ITX AIRFLOW Mini-ITX PC Case, 2000D AIRFLOW ITX, AIRFLOW Mini-ITX PC Case
---	--

References

-  [PC Components | Gaming Gear | CORSAIR](#)
-  [Corsair Blog - Corsair Community](#)
-  [Home - Corsair Community](#)

Manuals+