



CosmicByte Firefly Mechanical Gaming Keyboard User Manual

[Home](#) » [CosmicByte](#) » CosmicByte Firefly Mechanical Gaming Keyboard User Manual 

Contents

- [1 CosmicByte Firefly Mechanical Gaming Keyboard](#)
- [2 User Manual](#)
- [3 Specifications](#)
- [4 Multimedia Key Combination](#)
- [5 Troubleshooting](#)
- [6 Software Download](#)
- [7 Warranty](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



CosmicByte Firefly Mechanical Gaming Keyboard



User Manual

CONGRATULATIONS ON THE PURCHASE OF COSMIC BYTE FIREFLY MECHANICAL KEYBOARD We recommend that you read the user manual before using the product.

If you still have any queries, you can contact us at cc@thecosmicbyte.com

Specifications

- Model Name: Firefly
- Model Number: CB-GK-16 or CB-GK-18
- Style: 87 Key Mechanical Keyboard
- Switch Brand: Outemu
- Polling Rate: 1000Hz
- LED Modes: 11
- Media Functions: Yes, with FN key
- Software: Yes
- Keyboard size: 360*127*40mm
- Keyboard Weight: 758g Approx.
- Anti-Ghosting: All Key
- OS Compatibility: Windows, Mac, Linux (Software works only with Windows)

Multimedia Key Combination

- FN+F1= Music
- FN+F2= Volume Down
- FN+F3= Volume Up
- FN+F4= Mute
- FN+F5= Pause
- FN+F6= Prev Track
- FN+F7= Play/Pause
- FN+F8= Next Track
- FN+F9= Email

- FN+F10= Home
- FN+F11= Calculator
- FN+F12= Search

FN Combination Keys

- FN+INS= Change LED Mode
- FN+HM= 3 Dynamic LED Modes
- FN+"-/="= 7 Level Speed Adjustment
- FN+ Arrow Up/Down= 7 Level Brightness Adjustment
- FN+ESC= Press and Hold for 3S to factory reset keyboard
- FN+DEL= Color Selection (Works with specific LED modes only)
- FN+Arrow Left/Right= Left and Right LED Adjustment

Troubleshooting

1. Resetting the Keyboard

If you face any issue with the keyboard, we will first recommend you reset the keyboard by pressing FN+ESC key for 3 seconds. This will reset the keyboard to its factory default settings.

2. PC not detecting keyboard

Kindly try and change the USB port used to connect the keyboard. We recommend you connect the keyboard directly to the back of the PC to avoid any issue with detection.

Use of USB extensions can cause the PC failure in detecting the Keyboard.

3. Additional Support:

Contact our customer care team on cc@thecosmicbyte.com to troubleshoot or claim warranty. Please note warranty will not be valid if purchased from Unauthorized Sellers or for products tampered by third party technicians.

Software Download

Download software for the keyboard by visiting the website www.thecosmicbyte.com

Social Links

Follow us on Social media for offers and Giveaways

<https://www.instagram.com/thecosmicbyte/>

<https://www.facebook.com/thecosmicbyte/>

<https://twitter.com/cosmicbyteindia/>

Warranty

The keyboard carries 1 Year warranty against manufacturing defects only. Physical, Water damage and tampered products are not covered under warranty.

Documents / Resources



[CosmicByte Firefly Mechanical Gaming Keyboard](#) [pdf] User Manual
Firefly Mechanical Gaming Keyboard, Firefly, Mechanical Gaming Keyboard, Gaming Keyboard, Keyboard

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.