

COSTWAY
CB10359
Folding
Computer
Desk



COSTWAY CB10359 Folding Computer Desk Instruction Manual

[Home](#) » [COSTWAY](#) » COSTWAY CB10359 Folding Computer Desk Instruction Manual 

Contents

- 1 COSTWAY CB10359 Folding Computer Desk
- 2 Product Specifications
- 3 Product Usage Instructions
- 4 FAQs
- 5 Before You Start
- 6 PARTS&TOOLS
- 7 INSTALLATION
- 8 Damage ClaimInstructions
- 9 CONTACT INFORMATION
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts



COSTWAY CB10359 Folding Computer Desk



Product Specifications

- Product Name: Folding Computer Desk
- Model Number: CB10359

Product Usage Instructions

Before You Start:

Read all instructions carefully. Keep the instructions for future reference. Sort and count all parts and accessories. Follow each step in the correct order. Assemble all elements close to the intended usage area to avoid unnecessary movement once assembled. Place the product on a flat, stable, and firm surface.

Assembly Steps:

1. Identify and organize all parts and accessories.
2. Follow the assembly instructions provided in the manual step-by-step.
3. Ensure all screws and fasteners are securely tightened.
4. Double-check that the desk is stable and balanced before use.

Cleaning and Maintenance:

Regularly dust the desk with a soft cloth. Avoid using harsh chemicals that may damage the surface. For stains, use a mild detergent with a damp cloth and dry immediately. Check for loose screws or fittings periodically and tighten if needed.

FAQs

- **Q: What should I do if I need to return or claim damages?**

- **A:** Do not discard the original box or packaging. To initiate a return, the item must be in the original box. Take photos of box markings and any damaged parts. Contact us via email with the required images and a description of your claim.

- **Q: How can I contact customer support?**

- **A:** You can reach our customer support team via email. Here are our contact emails based on region:
 - USA: cs.us@costway.com
 - AUS: cs.au@costway.com
 - GBR: cs.uk@costway.com

Before You Start

- Please read all instructions carefully.
- Retain instructions for future reference.
- Separate and count all parts and hardware.
- Read through each step carefully and follow the proper order.
- We recommend that, where possible, all items are assembled near the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- Always place the product on a flat, steady, and stable surface.
- Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

PARTS&TOOLS


① x1




② x1




③ x1




④ x2




⑤ x2




⑥ x2




⑦ x2




⑧ x1




⑨ x1




⑩ x1




⑪ x1



⑫ x3



⑬ x1



⑭ x1



⑮ x1



⑩ x2



⑪ x2



⑫ x3



⑬ x3



⑭ x6



⑮ x1



⑯ x3



⑰ x2



⑱ x2



⑲ x3



⑳ x3



Ⓐ x12



Ⓑ x12



Ⓒ x4



M6*35

Ⓓ x6



M6*50

Ⓔ x4



M5.5*55

Ⓕ x24



M4*12

Ⓖ x8



M4*10

Ⓖ x6



M4*18

Ⓙ x12




M4*30




INSTALLATION


1




2




3




4




5




6



7




8




x2


9




10




11




12




13



14





Damage Claim Instructions


- **DO NOT discard the box / original packaging.**
 - In case a return is required, the item must be returned in the original box. Without this, your return will not be accepted.
- **Take a photo of the box markings.**
 - A photo of the markings (text) on the side of the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.
- **Take a photo of the damaged part (if applicable).**
 - A photo of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.
- **Send us an email with the images requested.**
 - Email us directly from the marketplace where your item was purchased with the attached images and a description of your claim.

CONTACT INFORMATION

- USA office: Fontana
- AUS office: Truganina
- GBR office: Ipswich
- ITA office: Milano
- POL office: Gdańsk
 - SA: cs.us@costway.com
 - AUS: cs.au@costway.com
 - GBR: cs.uk@costway.com

- POL: sklep@costway.com
- DEU: cs.de@costway.com
- FRA: cs.fr@costway.com
- ITA: cs.it@costway.com

Documents / Resources



[COSTWAY CB10359 Folding Computer Desk](#) [pdf] Instruction Manual
CB10359 Folding Computer Desk, CB10359, Folding Computer Desk, Computer Desk, Desk

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.