



COSTWAY HW63277 8-Gallon Stackable Locking Storage Container User Manual

[Home](#) » [COSTWAY](#) » COSTWAY HW63277 8-Gallon Stackable Locking Storage Container User Manual 



HW63277 8-Gallon Stackable Locking Storage Container User Manual




Contents

- [1 Contact Us!](#)
- [2 Steps to Set the Password of the Cipher Lock](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

Contact Us!

Do NOT return this item.








Contact our friendly customer service department for help first.




US: cs.us@costway.com

UK: cs.uk@costway.com


Before You Start

-  Please read all instructions carefully.
-  Retain instructions for future reference.
-  Separate and count all parts and hardware.
-  Read through each step carefully and follow the proper order.
-  We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
-  Always place the product on a flat, steady, and stable surface.
-  Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.




1. Find the bottom plate, the left (A), and right (B) side panels. Insert the left (A) and right (B) side panels into the corresponding slots on the bottom plate, as shown in Figure 1.

2




2. Reinforce left and right side panels with two screws on each side, as shown in Figure 2.

3



3. Insert the buckles of the front (D) and rear (C) panels into the side panels in the X direction and then insert them into corresponding slots on the bottom plate in the Y direction, as shown in Figure 3.


4



4. Reinforce the front and rear panels with two screws respectively, and then reinforce each of the four corner posts with a screw, as shown in Figure 4.



5. Find the top plate, align the hinges with the corresponding positions on the backplate, and then fix the hinges with four screws, as shown in Figure 5.




6. set the password to complete the assembly.

Steps to Set the Password of the Cipher Lock


1. The initial password is 0000. Please check the initial state, as shown in the figure below.



2. After confirming the initial password, switch the control level from Point B to Point A.



3. Reset the password according to your preferences, for example, 1314.



4. After the new password is set, move the lever from Point A back to Point B.



5. If you need to change the password, please recall and enter the password you set last time and repeat steps 2 to 4 to set the new password.

Kind Reminder:

For safety purposes, the storage box is designed without external unlocking devices.

The material of the box is very sturdy and the box is double reinforced by buckles and screws during assembly, which is not easy to disassemble. Please follow the instructions when setting the password, especially when turning the numbers, be sure to align them, then turn the lever back to the B position. Please don't forget the new password you set to avoid unnecessary trouble.

Documents / Resources

	<p>COSTWAY HW63277 8-Gallon Stackable Locking Storage Container [pdf] User Manual HW63277, 8-Gallon Stackable Locking Storage Container, HW63277 8-Gallon Stackable Locking Storage Container</p>
---	---