



COSTWAY PS6502 Bird Feeder User Manual

[Home](#) » [COSTWAY](#) » COSTWAY PS6502 Bird Feeder User Manual 

COSTWAY PS6502 Bird Feeder



THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Contents

- [1 Contact Us!](#)
- [2 Before You Start](#)
- [3 CUSTOMERS SUPPORT](#)
- [4 Documents / Resources](#)
- [4.1 References](#)

Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start



Please read all instructions carefully.



Retain instructions for future reference.



Separate and count all parts and hardware.



Read through each step carefully and follow the proper order.



We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.




Always place the product on a flat, steady and stable surface.



Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.


PART	DESCRIPTION	QUANTITY
A	Bowl	1
B	Post	1
C	Post Connector	1
D	Base	1

Parts Detail



Carefully remove the contents from the package. If any parts are missing do not attempt to use the product until they have been obtained and correctly installed.

Figure 1



1. Connect post(B) and post connector(C) together. Rotating clockwise to tighten.
2. Thread the lower end of post connector(C) into base(D). Rotating clockwise to tighten.
3. Thread the bowl(A) onto the upper end of post(B). Rotating clockwise to tighten.

CUSTOMERS SUPPORT

Please give us a chance to make it right and do better

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com





COSTWAY®

Documents / Resources



[COSTWAY PS6502 Bird Feeder](#) [pdf] User Manual
PS6502 Bird Feeder, PS6502, Bird Feeder, Feeder

References

- [COSTWAY - More Than Just Furniture](#)
- [COSTWAY - Mehr als einfache Möbel](#)
- [COSTWAY - Más Que Mobiliario Con Comodidad](#)
- [COSTWAY - Plus que des Meubles](#)
- [COSTWAY - Più che semplici mobili](#)