

COTO TECHNOLOGY RR122 Bluetooth TMR Digital Magnetic Sensor Instructions


[Home](#) » [COTO TECHNOLOGY](#) » COTO TECHNOLOGY RR122 Bluetooth TMR Digital Magnetic Sensor Instructions 

Contents

- [1 COTO TECHNOLOGY RR122 Bluetooth TMR Digital Magnetic Sensor](#)
- [2 INTRODUCTION](#)
- [3 Step by Step How to Programming Instructions](#)
- [4 FCC](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)



COTO TECHNOLOGY RR122 Bluetooth TMR Digital Magnetic Sensor



INTRODUCTION

- **Model:** RR122-4BT
- **P/N:** RR122-903

Step by Step How to Programming Instructions

This vehicle is not on board programmable and requires a qualified professional to program smart key remote fobs.

1. Locate an automotive locksmith in your area.
2. If your vehicle is still mobile, it may save you money by driving to the locksmith instead of having them come to you.
3. The locksmith will then hook up specialized computer equipment to your vehicle in order to program the smart key remote fob.

FCC

Please take attention that changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and.
2. This device must accept any interference received, including interference that may cause undesired operation.

Documents / Resources

	COTO TECHNOLOGY RR122 Bluetooth TMR Digital Magnetic Sensor [pdf] Instructions RR122, 2A5U7-RR122, 2A5U7RR122, RR122 Bluetooth TMR Digital Magnetic Sensor, Bluetooth TMR Digital Magnetic Sensor, TMR Digital Magnetic Sensor, Digital Magnetic Sensor, Magnetic Sensor
---	---