

Contour Stream Player RTL19-32200 User Manual

Home » Cox » Contour Stream Player RTL19-32200 User Manual

Contents

- 1 Maximize your Contour Stream Player with this antenna quick start quide.
 - 1.1 Tips for receiving channels:
- **2 Related Posts**

Maximize your Contour Stream Player with this antenna quick start guide.



- 1. Connect the coax cable to the TV's "antenna/cable in" port.
- 2. Verify the HDMI connection from Contour Stream Player to TV.
- 3. Using the source/input button on your TV remote, change the source of your TV to "antenna."
- 4. Run a TV channel scan. Your TV user manual will provide details on how to do this.

Tips for receiving channels:

Visit <u>fcc.gov/mb/engineering/maps</u> to obtain signal strength at your location. For troubleshooting, contact the manufacturer directly.

To access local channels through Cox, visit your local Cox store or contact us at (844) 347-2220 for more information.

Contour Stream Player RTL19-32200 User Manual – Optimized PDF Contour Stream Player RTL19-32200 User Manual – Original PDF

Manuals+.