

CP PLUS CP-Z44R ezykam Plus Wireless Security Camera **User Guide**

Home » CP PLUS » CP PLUS CP-Z44R ezykam Plus Wireless Security Camera User Guide 🖫



Contents

- 1 CP PLUS CP-Z44R ezykam Plus Wireless Security
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Add Camera
- **5 Frequently Asked Questions**
- 6 Documents / Resources
 - 6.1 References
- **7 Related Posts**




CP PLUS CP-Z44R ezykam Plus Wireless Security Camera



Thank you for choosing CP PLUS ezykam+. Get Started using your new devices by downloading ezykam+ app, one convenient app that manages everything straight from your smart phone. Easily connect to 4G SIM Network and control multiple devices from the touch of your fingertips.

Product Information

What's In the Box



Specifications

• Model: CP-Z44R

Power Source: Solar PanelNetwork: 4G SIM Network


• Supported OS: iOS 10.0 or higher, Android 8.0 or higher

Product Usage Instructions

Get Ready

Make sure your mobile device is running 105° 9.0 or higher or Android™ 8.0 or higher.

1. Download the ezykam+ app from the App Store or Google Play.



2. Register an account on your ezykam+ app.



STEP 1

- Select the country.
- Enter the email address.



STEP2

- Enter the verification code and create a password
- 3. Plug in the ezykam+ Camera to a power source.

How do I reset my camera?

• Use the reset pin to press the Reset Button for several seconds until hear the reset beep sound. Camera will be reboot.


Optional: Insert Miao SD card



- 4. Attach the Solar Panel to the camera using the provided Iron Bracket and Screw.
- 5. Make sure the camera is in a suitable location with access to sunlight for efficient charging.
- 6. Ensure that your smartphone is connected to the internet.

Add Camera

- Open ezykam+ app, click "+" on the top right corner of the "HOME" page, then select "Specific model to add."
- Power on the camera and ensure that the internet is connected to the camera.





• Align the QR code or barcode in the frame and scan it.



Add Camera


To add the camera to your ezykam+ app:

- 1. Open the ezykam+ app on your smartphone.
- 2. Select "Add Camera" from the app's main menu.
- 3. Follow the on-screen instructions to complete the camera setup process.

APP will scan the Device, In n"1WOrk & after device will be searched It will register on the cloud. After that device will added successfully.







Status Light Prompt of 4G Camera Tail Line

The status light on the camera's tail line indicates the network status:

• 4G mode:

- Slow flashing: Normal network connection. The 4G module Is abnormal or the SIM card Is abnormal, and flashes once every 2s.
- Fast flashing: No dialing number (no or bad signal), flashes once every 0.5s.
- Always on: The network is normal.

System Requirements

- Smartphone running 105° 9.0 or higher or Android 8.0 or higher
- 4G SIM Network with internet connection

Technical Specifications

- Camera: up to 4MP (2560×1440) at 15frames / sec. H.265 encoding
- Audio: Internal Speaker and Microphone
- Storage: supports up to 256 GB Micro SD card (not included)

Frequently Asked Questions

Can I share the camera with family and friends?

Yes, you can share your cameras with family and friends who will have access to view the camera.

To share the camera:

- 1. Open the ezykam+ app on your smartphone.
- 2. Select the camera you want to share.
- 3. Go to the camera settings and find the "Share" option.
- 4. Add the email addresses or usernames of the people you want to share the camera with.

5. They will receive an invitation to access the camera.

The camera appears offline or unreachable? If the camera appears offline or unreachable, please check the following:

- Make sure the camera is powered on and connected to the internet.
- Ensure that your smartphone is connected to the internet.
- Check if there are any network issues or interruptions in your area.
- Restart the camera and your smartphone.
- If the problem persists, contact our support team at ezycare@cpplusworld.com for further assistance.

Q: The camera appears offline or unreachable?

A: If the camera appears offline or unreachable, please check the troubleshooting steps mentioned in the user manual. If the problem persists, contact our support team at ezycare@cpplusworld.com for further assistance.

Which SIM card is supported?

All 4G3G SIM cards are supported by device.

The camera appears offline or unreachable?

Make sure you inserted the SIM in correct position during the setup. Check whether there is any Internet connection problem in SIM. If the SIM signal is too weak, Keep the camera in good network area.

cannot connect to your SIM network?

Make sure there should be active Internet plan on SIM card which is inserted on camera.

How many cameras can I control?

CP Plus app can control unlimited number of cameras in unlimited amount of locations. Your router may have a limit of how many cameras can be connected to one router.

Quick Operation Guide CP-Z44R

Thank you for choosing CP PLUS ezykam+. Get started using your new devices by downloading the ezykam+ app, one convenient app that manages everything straight from your smartphone. Easily connect to the 4G SIM Network and control multiple devices from the touch of your fingertips.

Contact Information

For further assistance, you can reach us via email at ezycare@cpplusworld.com.

Thank you for choosing CPPlus ezykam+

Please read the instruction carefully before using the product

Documents / Resources



<u>CP PLUS CP-Z44R ezykam Plus Wireless Security Camera</u> [pdf] User Guide CP-Z44R, CP-Z44R ezykam Plus Wireless Security Camera, ezykam Plus Wireless Security Camera, Wireless Security Camera, Camera

References

• User Manual

Manuals+, Privacy Policy