

CPPLUS D32A ezykam Wi-Fi Camera



CPPLUS D32A ezykam Wi-Fi Camera Installation Guide

[Home](#) » [CPPLUS](#) » CPPLUS D32A ezykam Wi-Fi Camera Installation Guide 

Contents

- 1 CPPLUS D32A ezykam Wi-Fi Camera
- 2 What's in the Box
- 3 Get Ready
- 4 Download the ezykam+ app from App Store or Google Play.
- 5 Register an account on your ezykam+ app.
- 6 Plug in How do I reset my camera?
- 7 Add Camera
- 8 Frequently Asked Questions
- 9 Documents / Resources
 - 9.1 References
- 10 Related Posts



CPPLUS D32A ezykam Wi-Fi Camera



Specifications

- Works with Alexa and Google Assistant
- Supports unlimited cameras in multiple locations
- System Requirements: iOS 10 or higher, Android 8 or higher

Step 1: Get Ready

1. Download the ezykam+ app from the App Store or Google Play.
2. Register an account on the ezykam+ app.
3. Plug in the ezykam Wi-Fi Camera using the provided Power Adapter.

Step 2: Add Camera

Follow the steps below to add a camera:

1. Open the ezykam+ app and click on “Add Camera”.
2. Wait for the indicator light on the device to turn steady blue, indicating network connection.
3. Follow any voice prompts or audible signals during the setup process.

Troubleshooting|

If you encounter any issues such as the camera appearing offline or unreachable, or being unable to connect to your Wi-Fi network, follow these steps:

- Ensure the correct Wi-Fi password is entered during setup.
- Check for Internet connection problems.
- If the Wi-Fi signal is weak, reset your router and try again.

Frequently Asked Questions

1. Can I share the camera with family and friends?

Yes, you can share your cameras with family and friends who will have access to view the camera.

2. What's the Wireless Range?

The range of your home Wi-Fi is heavily dependent on your home router and room conditions. Check with your router manufacturer for exact range data.

3. How many cameras can I control?

You can control an unlimited number of cameras in multiple locations. Note that your router may have a limit on how many cameras can be connected.

Thank you for choosing CP PLUS ezykam+. Get started using your new devices by downloading ezykam+ app, one convenient app that manages everything straight from your smart phone. Easily connect to your home Wi-Fi and control multiple devices from the touch of your fingertips.

What's in the Box



ezykam Wi-Fi Camera



Power Adapter




Quick Operation
Guide

Get Ready

- Know your Wi-Fi network and password.
- Make sure your mobile device is running iOS® 9.0 or higher or Android™ 8 or higher
- Make sure you're connecting to a 2.4GHz Wi-Fi network (It can't connect to 5GHz networks)

Download the ezykam+ app from App Store or Google Play.



Register an account on your ezykam+ app.

1. STEP 1.

- Select the country.
- Enter the email address.


2. STEP 2.

- Enter the verification code and create a password



Plug in How do I reset my camera?

- Use the reset pin to press the Reset Button for several seconds until the camera starts to beep.
- Optional: Insert Micro SD card





Thank you for choosing CPPlus ezykam+


For further assistance, you can reach us via ezycare@cpplusworld.com
Please read the instruction carefully before using the product **

Add Camera

- Open ezykam + app, click "+" on the top right corner of the "HOME" page, then select "Specific model to add".
- Make sure that the Red LED indicator is blinking and voice prompt is audible.




- Enter your “Wi-Fi network and password”, click “CONFIRM”.




Add Camera

- Read the instruction about “Scan the camera QR code” and click “Continue”.
- Scan the QR Code on your phone with camera. Heard a voice prompt, click “Heard the beep”



Add Camera

- When the indicator light on the device turn to steady blue light, the network configuration is complete.
- Please refer to the specific APP interface if there are any difference.



Frequently Asked Questions

1. Can I share camera with family and friends?

Yes, you can share your cameras with family and friends who will have access to view the camera.

2. What's the Wireless Range?

The range of your home Wi-Fi is heavily dependent on your home router and the conditions of the room. Check with your router for exact range data.

3. The camera appears offline or unreachable?

Make sure you entered the correct Wi-Fi password during the Wi-Fi setup. Check whether there is any Internet connection problem. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

4. Cannot connect to your Wi-Fi network.

Make sure you entered the correct Wi-Fi password during the Wi-Fi setup. Check whether there are any Internet connection problems. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

5. How many cameras can I control?

cameras in unlimited amount of locations. Your router may have a limit of how many cameras can be connected to one router.

Works with Alexa and Google Assistant

- Now Stream your camera video using Alexa and Google Assistant.



System Requirements

- Smartphone running iOS® 9.0 or higher or Android™ 8.0 or higher
- Existing Wi-Fi Network with internet connection

Technical Specifications

- Camera: up to 3MP (2304×1296) at 20frames / sec. H.265 encoding
- Viewing Angle: 104°
- Audio: Internal Speaker and Microphone
- Storage: supports up to 128GB Micro SD card (not included)
- Wi-Fi: IEEE 802.11b/g/n, 2.4GHz (not compatible with 5GHz Wi-Fi networks)

Documents / Resources



[CPPLUS D32A ezykam Wi-Fi Camera](#) [pdf] Installation Guide
D32A ezykam Wi-Fi Camera, D32A, ezykam Wi-Fi Camera, Wi-Fi Camera, Camera

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.