

CREATIVE EF0980 USB-C Headset with Swivel to Mute Moise Cancelling Mic and Inline Controls User Guide

Home » Creative » CREATIVE EF0980 USB-C Headset with Swivel to Mute Moise Cancelling Mic and Inline Controls User Guide [™]

Contents


- 1 CREATIVE EF0980 USB-C Headset with Swivel to Mute Moise Cancelling Mic and Inline Controls
- **2 OVERVIEW**
- **3 SMARTCOMMS KIT**
- **4 TECHNICAL SPECIFICATIONS**
- **5 CONTROLS**
- 6 Documents / Resources
- **7 Related Posts**




CREATIVE EF0980 USB-C Headset with Swivel to Mute Moise Cancelling Mic and Inline Controls



OVERVIEW





SMARTCOMMS KIT

Set up your product, personalize audio settings, enhance your product's performance, and more with the Creative app*.

- Access and control our all-new SmartComms Kit's suite of smart communication features such as VoiceDetect,
 NoiseClean-in, and NoiseClean-out for improved online calls experience
- Enjoy the ability to customize Graphic EQ
- Perform software upgrades, product registration, and more Download the Creative app from creative.com/support/chatusb

The Creative app and SmartComms Kit are currently available on Windows platform via USB audio playback only

TECHNICAL SPECIFICATIONS

Headphones:

• 40 mm Neodymium Driver x 2

• Frequency Response: 20–20,000 Hz

Microphone Type: Noise-cancelling Condenser x 1

USB Interface: USB-C


Operating Temperature: 0–45°C

CONTROLS

(A) Power On / Off

| i) Button | ii) Action |
|-------------|------------|
| <u>~</u> | оС |
| <u>∟</u> 25 | OFF |

(B) Playback



Note:


Volume Control on PS5™ / PS4™

Simultaneously press the Volume – and Mic Mute / Unmute buttons once to switch over to PS5 / PS4 volume control mode. This allows the headset to control volume adjustments when connected to the gaming console. This action is meant only for volume control on the PS5 / PS4 and does not support playback functions such as play, pause, or skip track.

(C) Calls

| i) Button | ii) Action |
|-------------|------------|
| <u>~</u> | Co/T |
| <u>∟</u> 2s | © |

(D) Microphone



Note:

- Mic-monitoring feature will not be activated when microphone is muted
- The built-in retractable microphone also acts as a mic mute / unmute switch. Push the microphone back up to its original position to reactivate the mute function

OTHER INFORMATION

Please visit <u>creative.com/compliance/chatusb</u> for the user guide, safety and regulatory information.

Please visit <u>creative.com/support/chatusb</u> for all other support related to your product.

Documents / Resources



CREATIVE EF0980 USB-C Headset with Swivel to Mute Moise Cancelling Mic and Inline C ontrols [pdf] User Guide

EF0980, USB-C Headset with Swivel to Mute Moise Cancelling Mic and Inline Controls

Manuals+,