



# Crocpad MINIMA Inflatable Water Slides User Manual

[Home](#) » [Crocpad](#) » Crocpad MINIMA Inflatable Water Slides User Manual 

## Crocpad MINIMA Inflatable Water Slides User Manual



Stop! Read this manual carefully before using this product!

Thank you for purchasing this Crocpad product. It has been designed and constructed to provide lasting memories of hours of exciting fun on the water.

We at Crocpad want your experience with our products to be the best it can be. Therefore, please take a few minutes to read the information contained in this manual before inflating and using your product. Although the product is simple to use, this manual contains important safety and maintenance information that you and others must understand to safely enjoy it.

### Contents

- [1 Package Contents:](#)
- [2 ROCPAD INFLATABLE SLIDE SAFETY INSTRUCTIONS](#)
- [3 Care and Maintenance:](#)
- [4 Cleaning and Storage:](#)
- [5 Warranty:](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)

### Package Contents:

#### MINIMA

Included in the package

- 1 x Inflatable slide MINIMA
- 1 x Stepping pad (attached)

- 1 x Electric pump
- 1 x Storage bag
- 1 x Repair kit
- 1 x Hose adaptor
- 1 x Manual



## MIKROS

Included in the package

- 1 x Inflatable slide MIKROS
- 1 x Stepping pad
- 1 x Electric pump
- 1 x Storage bag
- 1 x Repair kit
- 2 x Connectors
- 1 x Hose adaptor
- 1 x Manual



## MEGALO

Included in the package

- 1 x Inflatable slide MEGALO
- 1 x Stepping pad
- 1 x Electric pump
- 1 x Storage bag
- 1 x Repair kit
- 2 x Connectors
- 1 x Hose adaptor
- 1 x Manual



## PONTOON

Included in the package

- 1 x Inflatable slide PONTOON
- 1 x Electric pump
- 1 x Storage bag
- 1 x Repair kit
- 4 x Velcro Straps
- 1 x Manual



## Safety Rules and Information:



### WARNING

**READ AND FOLLOW INSTRUCTIONS AND WARNINGS TO AVOID DROWNING OR SERIOUS INJURY.**

- Improper use of this product, including reckless or careless behavior, neglect or misuse of the product, or inadequate supervision of children and others using the product, can result in serious personal injury or death.
- Always act responsible and provide proper supervision for Children and others using the product.
- The Inflatable slides are designed for ages 3+ and maximum user/s weight of 250kg.
- It is the owner's responsibility to inform all users of the product safety rules and warnings contained herein.
- Do not dive head first.
- Do not jump, leap or dive from the product.
- Make sure landing area is clear of swimmers.
- Megalo slide, can be used in large pools with a minimum water depth of 1.8m and 3m clearance distance from the slide.
- Use at appropriate water depth and at a safe distance from hazardous objects.

**CAUTION:** DO NOT OVER-INFLATE.

- Inflation and setup should be done, or supervised, by a competent adult.
- Inflate slowly until most of the wrinkles in the material are gone and the air chambers first feel firm to the touch.  
Do not continue to inflate past this point!
- Do not use air compressors or compressed air to inflate. Use of an air compressor or over-inflation can rupture the product beyond repair, voiding the warranty.

## **ROCPAD INFLATABLE SLIDE SAFETY INSTRUCTIONS**

DO NOT USE THE SLIDE UNLESS IT IS SECURELY ANCHORED TO THE STEPPING PAD

AN ADULT MUST SUPERVISE THE CHILDREN AT ALL TIMES

MAXIMUM 2 PEOPLE ON SLIDE AT ONE TIME

ALLOW A SM CLEAR DISTANCE FROM THE SLIDE

DO NOT MOVE INFLATABLE WHILE, CHILDREN USING SLIDE

NO SLIDING DOWN THE SAFETY WALL

NO JUMPING FROM THE TOP OF SLIDE TO BOTTOM, ALWAYS SLIDE DOWN

DO NOT SWIM UNDER SLIDE

DO NOT INFLATE/DEFLATE WHILE CHILDREN USING

DO NOT USE IN HEAVY RAIN OR WIND

DO NOT SLIDE INTO OTHERS BELOW

NOT BOUNCE ON THE TOP OF THE SLIDE

ROUGH PLAY, BOUNCING OFF WALLS, OR KICKS

NEVER SLIDE DOWN HEAD FIRST ALWAYS FEET FIRST

NOT FOR CHILDREN UNDER 3 YEARS OF AGE

KEEP IT AWAY FROM SHARP EDGES



NO SHOES, NO FOOD OR DRINKS, NO PETS, NO JEWELLERY OR SHARP ITEMS

### **Setup Instructions:**

(Please check out the latest manuals and Instruction videos)

**Step 1:** (Preparation)

Choose a smooth surface and make sure there are no sharp objects under the product which might puncture the vinyl then lay out the slide facing up on a flat surface.

**Step 2:** (Connect the pump)

Locate the valves. The main air chamber has a valve and the two side rails have valves.

**Note:** Minima has one air valve for the slide and safety rails.

To lock open valve, depress the stem and rotate  $\frac{1}{4}$  turn clockwise. To close valve, depress the stem and rotate  $\frac{1}{4}$  turn counter-clockwise. The valve stem should be in the depressed position while inflating. Replace the cap on valve after inflation to ensure air tight seal.

Using the electric pump in the package, lock the adaptor onto the end of the pump and insert it into the valve body with the special inflation adaptor included with the pump. Turn  $\frac{1}{4}$  turn to lock it in place.

**Step 3:** (Inflate the slide)

- Using an electric inflator or pump, inflate the main (1) chamber first until firm. You can toggle the valve by pressing the middle button to open/close the valve.

Close the valve by screwing the cap back on.

- Inflate one side rail until firm (2),
- Repeat for the other chambers (3).

**NOTE:** For Minima slide, the side safety rails are part of the slide and they will inflate with the slide.

**CAUTION:** DO NOT OVER-INFLATE

**NOTE:** Release a little air when the weather becomes hot. If you're inflating the water slide in the morning while the air is still cool, remember that the internal air pressure may expand later in the afternoon. Prevent the build-up of unwanted air pressure by releasing some of the air later in the day.

**Note:** Steps 4 and 5 are not applicable for the Pontoon slide.

**Step 4:** (Fill the stepping pad (4) with 30-50L of water then inflate it) Using the water hose adapter which can be found in the repair kit, fill the stepping pad with water (30-50L) to secure the slide and prevent it from moving. After you put 30-50L of water, remove the hose adapter and start inflating the stepping pad until firm.

**Note:** Minima slide stepping pad only requires water.

**Step 5:** (Anchor the slide to the stepping pad) Use the 304 stainless steel connectors to connect the slide and stepping pad. The connectors can be found in the repair kit.

**Note:** The stainless steel connectors are made from 304 grade material, which is resistant to rust under normal conditions. However, for pools located near the beach, it is necessary to clean and wash the connectors regularly to prevent corrosion.

**Note:** The Mikros and Megalo slides, additional D rings are available at the front bottom of the slide. In extremely windy conditions, use the D-rings at the front bottom of the slide to secure it to an anchor bag or point for stabilization. Otherwise, their use is not necessary.

## Care and Maintenance:

Crocpad slides come with a safety relief valve to protect the slide from over inflation. Saying that, we highly recommend to protect your slide from over inflation which could be caused by the sun or pump. The main thing you need to be concerned about with your inflatable slide is the relationship with the sun is over inflation. Over inflation can damage or make a dramatic change in the form or appearance of the slide.

When you blow up an inflatable slide, you fill it with warm air via the electric pump. The air during the day gains kinetic energy from the sun, expands, and causes your inflatable to become stiff.

How do you protect your slide from the sun?

- The best practice is to deflate the slide (including the stepping pad) and store it in a shady area or room. You can also disconnect the slide from the pad and simply move it to a shady area.
- If you would like to keep the slide outdoors for a few days, please make sure you deflate it enough to avoid any heatwave damage or a dramatic change in the form or appearance of the slide.
- Release a little air when the weather becomes hot. If you're inflating the water slide in the morning while the air is still cool, remember that the internal air pressure may expand later in the afternoon.  
Prevent the buildup of unwanted air pressure by releasing some of the air later in the day.
- When it is not used, please make sure you deflate it enough to avoid the slide expanding from the heat.
- The stainless steel connectors are made from 304 grade material, which is resistant to rust under normal conditions. However, for pools located near the beach, it is necessary to clean and wash the connectors regularly to prevent corrosion.
- The Mikros and Megalo slides, additional D rings are available at the front bottom of the slide. In extremely windy conditions, use the D-rings at the front bottom of the slide to secure it to an anchor bag or point for stabilization. Otherwise, their use is not necessary.

**Please note:** heatwave and over inflation damages will not be covered under our warranty.

## Cleaning and Storage:

Clean the surfaces with mild soap and water to stay clean and only store when completely dry. The inflatable water slides only need a wash with mild soap and water to stay clean. Avoid using oil-based or chlorinated solutions on the surface.

- Clean the surfaces with mild soap and water. Wipe off with a towel and let it dry before you put it in the storage bag.

- Empty the water from the stepping pad using the special hose adapter.
  - Connect the hose adapter (which comes with the slide)
  - Once the adapter is plugged in, the valve will be fully open, allowing water to flow out easily. Lift up the pad so the water comes out.
- After making sure there are no more water inside the stepping pad, deflate the Slide and Stepping pad using the electric pump “deflate mode”.
- Put the slide, pad, pump, hose adapter and the repair kit all in the storage bag.
 

**IMPORTANT:** Make sure nothing sharp or hard object sits on the slide/pad.
- Store it in a cool, dry place, away from fire and sharp objects.

## Warranty:

The Crocpad Commercial Inflatable Slides are backed by 1-2 year warranty.

- Minima slide: 1-year warranty
- Mikros slide: 2-year warranty
- Megaloslide: 2-year warranty
- Pontoon slide: 2-year warranty

You need to be aware of the terms and conditions of the warranty to ensure they are eligible for coverage in case of any manufacturing defects.

- The warranty covers manufacturing defects discovered while unpacking the product or during use.
- The warranty is valid for the duration mentioned above from the date of purchase.
- The warranty applies only to products that have not been modified by any third parties.
- To be eligible for the warranty, the product must be used within the specified limits and in accordance with the warnings and instructions given in the user's manual.
- Proper storage and handling of the product, following the manufacturer's recommendations, are required to maintain warranty coverage.
- Customers should thoroughly read the user's manual and warranty documentation provided by Crocpad to understand the specific terms and conditions in detail. If they encounter any issues with the product that may be covered under warranty, they should contact Crocpad's customer support or the authorized dealer where the product was purchased to initiate the warranty claim process.
- Crocpad will repair or replace only the damaged part of the product, not the entire set.
- Crocpad reserves the right to request that the item be sent for additional testing.
- To facilitate the assistance process, we kindly ask for the order number, and detailed claim description, along with supporting photos and evidence.


## IMPORTANT:

It's important to note that Crocpad will not replace any product that has been damaged due to negligence or used in a manner contrary to the owner's manual guidelines. This includes instances such as jumping on the slide, damage caused by sharp or hard objects, and exposure to extreme heat or over-inflated.

## Manuals and Video Instructions



## Documents / Resources

	<p><a href="#">Crocpad MINIMA Inflatable Water Slides</a> [pdf] User Manual</p> <p>MINIMA Inflatable Water Slides, MINIMA, Inflatable Water Slides, Water Slides, Slides</p>
---	--

## References

- [🌐 Crocpad - Endless Hours of Safe Fun](#)
- [User Manual](#)

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.