




CROSLEY AC1050A Record Storage Crate Instruction Manual

[Home](#) » [Crosley](#) » CROSLEY AC1050A Record Storage Crate Instruction Manual 

CROSLEY AC1050A Record Storage Crate



Contents


[1 PARTS LIST](#)

[2 Documents /
Resources](#)

[2.1 References](#)


[3 Related Posts](#)

PARTS LIST

1	2	3	4 & 5
			
Bottom Panel 1pc	Back Side Panel 1pc	Front Side Panel 1pc	Side Panel 2pcs

STEP 1. Place the bottom panel (1) on a flat surface. Attach the back (2) and front (3) panels to the bottom piece and slide into place.

STEP 2. Slide the side panels (4 & 5) on the front and back panels.



CROSLEY®

Documents / Resources

 The image shows the cover of the instruction manual for the Crosley AC1050A Record Storage Crate. It features the Crosley logo at the top, followed by the model number 'AC1050A' and the title 'Record Storage Crate Instruction Manual'. Below the text is a line drawing of the storage crate, which is a rectangular box with a lid and a handle. At the bottom, there is a small line of text: 'Crosley, a Division of Wharfedale, Inc. 10000 Wharfedale Drive, Charlotte, NC 28226-1000. © 1988 Wharfedale, Inc. All rights reserved. Printed in the U.S.A.'.	CROSLEY AC1050A Record Storage Crate [pdf] Instruction Manual AC1050A, Record Storage Crate
--	--

References

-  crosleyradio.com

Manuals+.