

CROSLEY AC1052A Record Storage Display Instruction Manual


[Home](#) » [Crosley](#) » CROSLEY AC1052A Record Storage Display Instruction Manual 

Contents

- [1 CROSLEY AC1052A Record Storage Display](#)
- [2 PARTS LIST](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)



CROSLEY AC1052A Record Storage Display



Questions, problems, missing parts?



Before returning to the store, call Customer Service

8 a.m. – 6 p.m., EST, Monday – Friday

1-888-CROSLEY


www.crosleyradio.com

PARTS LIST




STEP 1. Place the two bases (1) on a flat surface.

Note: Ensure both base pieces are facing the same way.



STEP 2. Slide the panels (2) into place.



Documents / Resources

 CROSLEY AC1052A Record Storage Display Instruction Manual Questions, comments, suggestions? Contact us at: 1-800-451-1000 P.O. Box 1000, St. Louis, MO 63101 www.crosleyradio.com	CROSLEY AC1052A Record Storage Display [pdf] Instruction Manual AC1052A Record Storage Display, AC1052A, Record Storage Display
--	--

References

- crosleyradio.com