

CSP WL121CS Serialized Combination Wedge Laptop Locks Instruction Manual

Home » CSP » CSP WL121CS Serialized Combination Wedge Laptop Locks Instruction Manual



Contents

- 1 CSP WL121CS Serialized Combination Wedge Laptop
- **2 Operation Instructions**
- 3 Instructions
- 4 Remark
- **5 Contact Information**
- **6 Combination Note**
- 7 FAQs
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



CSP WL121CS Serialized Combination Wedge Laptop Locks




Operation Instructions

Components

- Bumper Spacers
- Locking Hook
- Security Cable
- Release Button
- Dial
- Combination Window

Instructions



- 1. Loop the Security Cable around a non-movable object.
- 2. Turn the Dials to the preset opening number which appears in the Combination Window.
- 3. Press and hold the Release Button to unlock.
- 4. Insert the Locking Hook into the security slot of the equipment. Release the Release Button and scramble the Dials to lock up your equipment.

Remark



Specifications			
H 3.2 x L 4.5	5 mm Wedge Slot		

Contact Information

- 5 Star North, LLC dba Computer Security Products
- 100 Factory Street, Nashua NH 03060

• Phone: 1-603-889-9899

• Email: help@computersecurity.com

Combination Note

Write down your combination here:

FAQs

- · What should I do if I forget my combination?
 - Contact customer support at 1-603-889-9899 or help@computersecurity.com for assistance.
- · Can I use this lock on any device?
 - This lock is applicable to devices with a H 3.2 x L 4.5 mm Wedge Slot.
- · How do I reset the combination?
 - Refer to the user manual or contact customer support for detailed instructions on resetting the combination.

Documents / Resources



CSP WL121CS Serialized Combination Wedge Laptop Locks [pdf] Instruction Manual CSP-WL121CS, WL121CS Serialized Combination Wedge Laptop Locks, WL121CS, Serialized Combination Wedge Laptop Locks, Combination Wedge Laptop Locks, Wedge Laptop Locks, Laptop Locks, Locks

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.