cudy LT 700E Cat 6 AC1200 WiFi Router



cudy LT 700E Cat 6 AC1200 WiFi Router Installation Guide

Home » cudy » cudy LT 700E Cat 6 AC1200 WiFi Router Installation Guide



Contents

- 1 cudy LT 700E Cat 6 AC1200 WiFi **Router**
- 2 Specifications
- 3 Insert your SIM card
- 4 Power the device
- **5 Connect the network**
- 6 Enter configuration page
- 7 Input PIN if needed
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



cudy LT 700E Cat 6 AC1200 WiFi Router



Specifications

Model: LT400ENetwork: 4G LTE

• Wi-Fi: Dual-band (2.4GHz and 5GHz)

• SIM Card Type: Nano SIM

• LED Indicators: Power, Network Connection


• Power Input: DC

FAQ

- Q: What should I do if my 4G connection is not working?
- A: Make sure you have entered the correct APN parameters. If further assistance is needed, contact your Internet provider.
- Q: How can I improve cellular signal strength?
- A: Place the 4G router near windows for better signal reception.


Insert your SIM card

Align your nano SIM card with the SIM icon on the bottom side, and insert the card into the SIM slot until you hear a clicking sound.




Power the device

Connect the power adapter and press the power button to turn on the router. Wait 2 minutes for it to start.



Connect the network






- When the CLED turns solid, the router is connected to the cellular network.
- If the LED is off, please continue to configure the router.

Note:

For some ISPs' SIM cards (such as Verizon), it may take longer to connect to the Internet. Please kindly wait another 2~5 minutes


Enter configuration page

Launch a web browser on the connected devices (phone/laptop/tablet) and enter http://cudy.net/ (or http://cudy.net/<




Input PIN if needed

If this message pops up, please enter your PIN and click "Save & Apply", or contact your cellular provider for help



Follow the system instruction

If 4G is not connected, or if you want to customize the router yourself, click "Quick Setup" and follow the step-bystep instructions to configure the router




- 1. If you are not sure about APN parameters, please contact your Internet provider.
- 2. If you encounter any other problems, don't hesitate to contact our technical support team: at support@cudy.com





If the cellular signal strength is weak, try placing the 4G router near windows and check again.



EU Declaration of Conformity

Cudy hereby declares that the device is in compliance with the essential quirements and other relevant provisions of Directive 2014/53/EU, directive 2011/65/EU, and directive (EU) 2015/863. The original EU Declaration of Conformity can be found at http://www.cudy.com/ce.

Documents / Resources



cudy LT 700E Cat 6 AC1200 WiFi Router [pdf] Installation Guide

LT400E, LT700E, LT 700E Cat 6 AC1200 WiFi Router, LT 700E, LT 700E WiFi Router, Cat 6 AC1200 WiFi Router, Cat 6 MiFi Router, Cat 6, AC1200, AC1200 WiFi Router, WiFi Router, Router, WiFi

- G Cudy, Your Home and Business Networking Solutions Provider
- O Download Search Cudy
- © Download Search Cudy
- © Contact Us Cudy
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.