

cudy LT15V Wi-Fi 6 Router with Voice Installation Guide

Home » cudy » cudy LT15V Wi-Fi 6 Router with Voice Installation Guide 🖫





Quick Installation Guide

Contents

- 1 LT15V Wi-Fi 6 Router with
- **Voice**
- 2 Insert your SIM card
- 3 Power the device
- 4 Connect the network
- 5 Check the LED
- 6 Enter configuration page
- 7 Input PIN if needed
- 8 Follow the system instruction
- 9 Declaration of Conformity
- 10 Documents / Resources
- 10.1 References
- 11 Related Posts


LT15V Wi-Fi 6 Router with Voice

NEED TECH HELP?

\triangleright	www.cudy.com/qr_vg_lt	
	www.cudy.com	回統回
\searrow	support@cudy.com	100
<u> </u>	www.cudy.com/download	http://www.cudy.com/qr_vg_lt 810600200


Insert your SIM card

Align your nano SIM card with the SIM icon on the bottom side, and Insert the card into the SIM slot until you hear a clicking sound.




Power the device

Connect the power adapter and press the power button to turn on the router. Wait 2 minutes for it to start.



Connect the network

Connect your devices to the router via Wi-Fi or an Ethernet cable. The Wi-Fi name and password is printed on the back of the router.



Check the CLED


When the C LED turns solid, the router is connected to the cellular network.

 \odot If the $\ensuremath{\bigcirc}$ LED is off, please please continue to configure the router.

Note: For some ISP's SIM card (such as Verizon), it may take longer to connect to the Internet. Please kindly wait another 2~5 minutes.


Enter configuration page

Launch a web browser on the connected devices (phone/laptop/tablet) and enter http://cudy.net/ (or http://cudy.net/<




Input PIN if needed

If this message pops up, please enter your PIN and click "Save & Apply", or contact your cellular provider for help.




Follow the system instruction

If 4G is not connected, or if you want to customize the router yourself, click "Quick Setup" and follow the step-by-step instructions to configure the router.



Note:


- 1. If you are not sure about APN parameters, please contact your internet provider.
- 2. If you meet any other problems, don't hesitate to contact our technical support team: support@cudy.com



Flip the page to connect telephone and more


Connect your telephone if needed


Use an RJ11 cable to plug it into the RJ11 port on the 4G Voice Router and the telephone. Typically, the RJ11 cable comes with the phone.




LED


If the cellular signal strength is weak, try placing the 4G router near windows and check again. If the cellular signal is weak everywhere indoors, try installing extension 4G antennas (which are not included in the box) into the SMA connectors on the back of the router and placing the antennas outdoors.














Declaration of Conformity

Cudy hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU, directive 2011/65/EU, directive (EU) 2015/863. The original EU declaration of conformity can be found at http://www.cudy.com/ce.





Documents / Resources



<u>cudy LT15V Wi-Fi 6 Router with Voice</u> [pdf] Installation Guide
LT15V Wi-Fi 6 Router with Voice, LT15V, Wi-Fi 6 Router with Voice, Router with Voice, with Voice, Voice

References

- <u>O Trying to configure your Cudy Router</u>
- Cudy, Your Home and Business Networking Solutions Provider
- <u>O Download Search Cudy</u>
- © Download Search Cudy
- **©** YouTube

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.