


cudy LT700V Wi-Fi Router with Voice Installation Guide

Home » cudy » cudy LT700V Wi-Fi Router with Voice Installation Guide


cudy LT700V Wi-Fi Router with Voice



Contents 1 Insert your SIM card 2 Power the device 3 Connect the network 4 Check the LED 5 Enter configuration page 6 Input PIN if needed 7 Follow the system instruction 8 Connect your telephone if needed 9 LED **10 EU Declaration of Conformity** 11 Customers Support 12 Documents / Resources 12.1 References **13 Related Posts**


Insert your SIM card

Align your nano SIM card with the SIM icon on the bottom side, and Insert the card into the SIM slot until you hear a clicking sound.




Power the device

Connect the power adapter and press the power button to turn on the router. Wait 2 minutes for it to start.



Connect the network

Connect your devices to the router via Wi-Fi or an Ethernet cable. The Wi-Fi name and password is printed on the back of the router.



Check the [♀] LED


- ⊕ When the
 ⊖ LED turns solid, the router is connected to the cellular network.
- $\ensuremath{\circledcirc}$ If the $\ensuremath{\circlearrowleft}$ LED is off, please please continue to configure the router.

Note:

For some ISP's SIM card (such as Verizon), it may take longer to connect to the Internet. Please kindly wait another 2~5 minutes.


Enter configuration page

Launch a web browser on the connected devices (phone/laptop/tablet) and enter http://cudy.net/ (or http://cudy.net/<




Input PIN if needed

If this message pops up, please enter your PIN and click "Save & Apply", or contact your cellular provider for help




Follow the system instruction

If 4G is not connected, or if you want to customize the router yourself, click "Quick Setup" and follow the step-by-step instructions to configure the router.



Note


- 1. If you are not sure about APN parameters, please contact your internet provider.
- 2. If you meet any other problems, don't hesitate to contact our technical support team: support@cudy.com



Flip the page to connect telephone and more

Connect your telephone if needed


Use an RJ11 cable to plug it into the RJ11 port on the 4G Voice Router and the telephone. Typically, the RJ11 cable comes with the phone.





LED


If the cellular signal strength is weak, try placing the 4G router near windows and check again.


If the cellular signal is weak everywhere indoors, try installing extension 4G antennas (which are not included in the box) into the SMA connectors on the back of the router and placing the antennas outdoors.














EU Declaration of Conformity

Cudy hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU, directive 2011/65/EU, directive (EU) 2015/863. The original EU declaration of conformity can be found at http://www.cudy.com/ce.

Customers Support



NEED TECH HELP?



For technical support, the user guide and more information, please visit: https://www.cudy.com/support 810600188



Documents / Resources



<u>cudy LT700V Wi-Fi Router with Voice</u> [pdf] Installation Guide
LT700V, LT700V Wi-Fi Router with Voice, Wi-Fi Router with Voice, Router with Voice, Voice

References

- © Cudy, Your Home and Business Networking Solutions Provider
- © Download Search Cudy
- © Download Search Cudy
- © Contact Us Cudy
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.