





# cudy WR3000S AX3000 Gigabit Mesh WiFi 6 Router **Installation Guide**

Home » cudy » cudy WR3000S AX3000 Gigabit Mesh WiFi 6 Router Installation Guide 1



#### **Contents**

- 1 cudy WR3000S AX3000 Gigabit Mesh WiFi 6 Router
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 Frequently Asked Questions**
- **5 Installation Instruction**
- 6 Documents / Resources
  - **6.1 References**
- **7 Related Posts**



cudy WR3000S AX3000 Gigabit Mesh WiFi 6 Router



## **Product Information**

### **Specifications:**

• Model: 810600258

Languages: English, Italiano, Deutsch, Eesti, Norsk, Svenska, Ting Vit, Cestina, Suomi, Dansk, Hrvatski,
Magyar, Lietuvi kalba, Latviski

• Support: www.cudy.com/support

## **Product Usage Instructions**

#### **Quick Installation Guide:**


- 1. Connect the power adapter to the router and wait for the System LED indicator light to turn solid on.
- Connect the router's WAN port to DSL/Cable Modem or the Ethernet wall outlet.
- 3. Connect the router via A or B method.
  - A Wi-Fi: Connect your device to the router's Wi-Fi. (the default network name/SSID and Password are printed on the bottom of the router.)

# **Frequently Asked Questions**


- Q: How do I reset the router to factory settings?
  - A: To reset the router to factory settings, locate the reset button on the router and press and hold it for about 10 seconds until the lights on the router flash
- Q: How can I update the firmware of the router?
  - A: You can update the firmware of the router by visiting www.cudy.com/download and following the instructions provided on the website.

### **Installation Instruction**

1. Connect the power adapter to the router and wait for the "System" LED indicator light to turn solid on.



2. Connect the router's WAN port to DSL/Cable Modem or the Ethernet wall outlet.




# 3. Connect the router via A or B method.


**A** Wi-Fi: Connect your device to the router's Wi-Fi. (the default network name/SSID and Password are printed on the bottom of the router.)




**B** Wired: Turn off the Wi-Fi on your computer and connect it to the router's LAN port via an Ethernet cable.




4. Open a browser and follow the pictures to configure the router.




http://cudy.net/





Enjoy the internet.

## LED





Google Play





#### **NEED TECH HELP?**



810600258 www.cudy.com/qr\_vg\_wr www.cudy.com support@cudy.com www.cudy.com/download

# **Documents / Resources**

cudy WR3000S AX3000 Gigabit Mesh WiFi 6 Router [pdf] Installation Guide WR3000S REV1.0, WR3000S AX3000 Gigabit Mesh WiFi 6 Router, WR3000S, WR3000S Gigabit Mesh WiFi 6 Router, AX3000 Gigabit Mesh WiFi 6 Router, AX3000, Gigabit Mesh WiFi 6 Router, Gigabit Mesh Router, WiFi 6 Router, WiFi 6, WiFi, Router

#### References

- © Cudy, Your Home and Business Networking Solutions Provider
- © Download Search Cudy
- G YouTube
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.