



Cuisinart SS-RFC Reusable Filter Cup Instructions

[Home](#) » [Cuisinart](#) » Cuisinart SS-RFC Reusable Filter Cup Instructions 

Cuisinart SS-RFC Reusable Filter Cup Instructions

Contents

[1 Reusable Filter Cup](#)

[2 Documents / Resources](#)

Reusable Filter Cup

How to Use with Your Single-Serve Coffeemaker:

1. Open HomeBarista™ capsule, fill with ground coffee or tea and close lid.
- Note:** Maximum fill is 15 grams (2½ tablespoons).
2. Remove capsule holder from brewing chamber and replace with filled HomeBarista™ Filter Cup.
3. Close brewing chamber, brew and enjoy!

Documents / Resources

	Cuisinart SS-RFC Reusable Filter Cup [pdf] Instructions B01J8PKE2Q, SS-RFC Reusable Filter Cup, SS-RFC, Reusable Filter Cup
---	---