

Custom Dynamics CD-ALT-BS-BCM Alternating Brake Strobe Module Instruction Manual

[Home](#) » [Custom Dynamics](#) » Custom Dynamics CD-ALT-BS-BCM Alternating Brake Strobe Module Instruction Manual 



CD-ALT-BS-BCM Alternating Brake Strobe Module Instruction Manual

Contents

- [1 CD-ALT-BS-BCM Alternating Brake Strobe Module](#)
- [2 Installation Instructions](#)
- [3 Package Contents:](#)
- [4 Installation:](#)
- [5 Output Wiring Schematic](#)
- [6 Brake Strobe Pattern Information](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

CD-ALT-BS-BCM Alternating Brake Strobe Module

Custom Dynamics® Alternating
Brake Strobe Module

Installation Instructions

We thank you for purchasing the Custom Dynamics® Alternating Brake Strobe Module. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best

warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers:

CD-ALT-BS-BCM

Package Contents:

- Alternating Brake Strobe Module (1)
- Y Adapter Harness (1)
- Wire Ties (10)

Fits: 2014-2022 Harley-Davidson® Street Glide (FLHX), Street Glide Special (FLHXS), Street Glide CVO (FLHXSE), Street Glide ST (FLHXST), Road Glide (FLTRX), Road Glide CVO (FLTRXSE), Road Glide Special (FLTRXS), Road Glide ST (FLTRXST), Road Glide Limited (FLTRK), Road Glide Limited CVO™ (FLTRKSE), Road Glide Ultra (FLTRU), Road Glide Ultra CVO (FLTRUSE), Electra Glide Standard (FLHT), Ultra Classic (FLHTCU), Ultra Classic Low (FLHTCUL), Ultra Limited (FLHTK), Ultra Limited Low (FLHTKL), Ultra Limited CVO (FLHTKSE), Road King (FLHR), Road King CVO (FLTRXSE), and Road King Special (FLHRXS).



ATTENTION

Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only.

It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Important: Do not exceed 3 Amps per output.




Installation:

1. Secure motorcycle on level surface. Remove seat. Disconnect negative battery cable from the battery.


2. Locate and unplug the rear fender lighting harness connector.
3. Plug the Y Adapter Harness, in-line, into the rear fender lighting harness and into the bike's main wiring harness. Y Adapter harness MUST be installed in front of any Run/Brake/Turn module or Taillight Brake Strobe module. Plug the Alternating Strobe Module into the Y Adapter Harness.
4. For plug-n-play installation, install Custom Dynamics® Red LED Boltz™ (sold separately). Once the LED Boltz™ are installed connect them to the left and right output white 3 pin connectors.
5. For custom installations, remove the White 3 wire connectors from both outputs. Refer to the Output Wiring schematic on Page 2 for connections.
6. Re-connect the battery's negative battery cable to the negative of the battery.
7. With the power off to the module, select the desired Brake Strobe Pattern using SW1 and SW2 switches. Refer to the Brake Strobe Pattern Information on Page 2.
8. Locate a secure place for the Alternating Strobe Module that will not interfere with the secure placement of the seat or side cover. Secure with tie-wraps, tape or other means so that unit will not move.
9. Test all lighting for proper operation.

Output Wiring Schematic











Brake Strobe Pattern Information

Alternating Strobe Module



- Dial controls the speed of the brake strobe. 0 being the slowest and 9 being the fastest.
- SW-1 and SW-2 Selects the Brake Strobe Pattern:

<div> <div> <div>SW-2</div> <div>ON OFF</div> <div></div> </div> <div> <div>SW-1</div> <div>ON OFF</div> <div></div> </div> </div> <div> <div>ON OFF</div> <div></div> <div>ON OFF</div> <div></div> </div> <div> <div>ON OFF</div> <div></div> <div>ON OFF</div> <div></div> </div> <div> <div>ON OFF</div> <div></div> <div>ON OFF</div> <div></div> </div>	Random Brake Strobe Pattern
	Alternating 2 Flash Pattern
	Alternating 4 Flash Pattern
	Alternating 5 Flash Pattern




Questions?

Call us at: 1 (800) 382-1388

M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Documents / Resources

	<p>Custom Dynamics CD-ALT-BS-BCM Alternating Brake Strobe Module [pdf] Instruction Manual</p> <p>CD-ALT-BS-BCM Alternating Brake Strobe Module, CD-ALT-BS-BCM, Alternating Brake Strobe Module, Brake Strobe Module, Strobe Module, Module</p>
---	--