



# cuzor Classic\_2bat Ensure Uninterrupted Internet with Router UPS Instruction Manual

[Home](#) » [cuzor](#) » **cuzor Classic\_2bat Ensure Uninterrupted Internet with Router UPS Instruction Manual** 



## Classic\_2bat Ensure Uninterrupted Internet with Router UPS Instruction Manual



## Contents

- 1 Classic\_2bat Ensure Uninterrupted Internet with Router UPS
- 2 MiniUPS Packaging Content
- 3 Documents / Resources
  - 3.1 References

## Classic\_2bat Ensure Uninterrupted Internet with Router UPS

Follow these instructions and install your MiniUPS under 3 minutes!

## MiniUPS Packaging Content



### CABLES INCLUDED

- A. 5.5mm / 2.1mm male to 5.5mm / 2.1mm male bridge cable
- B. 5.5mm/2.1mm female to 3.5mm/ 1.35mm male adapter cable
- C. 4.0mm/1.35mm female to 5.5mm/ 2.1mm male adapter or cable



Cable from your Wifi  
Router's adapter

**STEP 1**

Unplug your router's AC/DC adapter and  
connect it to the MiniUPS input (marked 'IN')

**STEP 2**

Connect the bridge cable (A) to MiniUPS output (marked 'OUT')





### STEP 3

Connect the other end of the bridge cable (A) to the WiFi Router or Modem's input






#### STEP 4

Turn on the MiniUPS by moving the switch from off to on



### Connection Diagram 1


As shown with pictures. Most common routers would need this setup.



**NOTE:** For DLink routers you may need to use supplied adapter plug or cable, please refer to the Connection Diagram 2 on the left page for the details.

### Connection Diagram 2


Most DLink routers would need this setup.



### 12 MONTHS WARRANTY

#### WITH DOORSTEP PICKUP AND DROP SERVICE

We understand that your time is valuable, which is why MiniUPS comes with a full 12 Months warranty for your peace of mind. But that's not all – we offer a convenient doorstep pickup service! Just message CuzorLabs customer support on Whatsapp and we take care of the rest. Your satisfaction is our priority. Don't forget to register your MiniUPS for warranty for seamless customer service. Scan the QR code with your phone and follow the steps on at [www.cuzorlabs.com/register](http://www.cuzorlabs.com/register)



[cuzorlabs.com/register](http://www.cuzorlabs.com/register)

# CUZOR

CUZOR

[www.cuzorlabs.com](http://www.cuzorlabs.com)

1st Floor, #38 Greenleaf Extension 3rd  
Cross, 20th Main Rd, Koramangala 4th Bengaluru, Karnataka – 560034, India  
© CuzorLabs, All rights reserved  
**CuzorLabs Customer**  
**Support on Whatsapp**  
+91-6366283839  
Customer Service: E: [support@cuzorlabs.com](mailto:support@cuzorlabs.com),  
P: +91-6366283839, 1st Floor, #38 Greenleaf Extension  
3rd Cross, 20th Main Rd, Koramangala 4th Block,  
Bengaluru, Karnataka – 560034, India  
© CuzorLabs, All rights reserved

---

## Documents / Resources



[cuzor Classic\\_2bat Ensure Uninterrupted Internet with Router UPS](#) [pdf] Instruction Manual  
|  
Classic\_2bat, Classic\_2bat Ensure Uninterrupted Internet with Router UPS, Ensure Uninterrupted Internet with Router UPS, Uninterrupted Internet with Router UPS, Internet with Router UPS, Router UPS, UPS

## References

- [Router UPS - Zero Lag Power Backup for WiFi Routers](#)
- [Warranty Registration | CuzorLabs](#)