



cuzor MiniUPS 12V Mini UPS for WiFi Router User Manual

[Home](#) » [cuzor](#) » cuzor MiniUPS 12V Mini UPS for WiFi Router User Manual 

cuzor MiniUPS 12V Mini UPS for WiFi Router User Manual




Contents

- 1 Accessories included with the MiniUPS
- 2 Connection Diagram 1
- 3 How to use
- 4 Warranty Card
- 5 Documents / Resources

Accessories included with the MiniUPS

A. 5.5mm /2.1mm male to 5.5mm /2.1mm male **bridge cable**



B. 5.5mm/2.1mm female to 3.5mm/ 1.35mm male adapter plug or cable




C. 4.0mm/1.35mm female to 5.5mm/ 2.1mm male adapter plug or cable



Note: Either **Adapter Plug** or **Adapter Cable** would be included in the package. Their function is same.

Connection Diagram 1



***Recommended DC power ratings for input adapters:**

- **Mini UPS 12V2A:** 12V,21A
- **Mini UPS 12V2.5A:** 12V,22A
- **Mini UPS 12V2A:** 9V,20.6A

How to use

1. Unplug your router's AC/DC adapter and connect it to the Mini UPS input (marked 'IN')
2. Connect the supplied bridge cable to the Mini UPS output and your router's power input
3. Turn on the Mini UPS by moving the switch from off to on



4. Now your Wi fi Should be running.


Note: For D Link routers you may need to use supplied adapter plug or cable, please **refer to the Connection Diagram 2** on the left page for the details.

LED Indicator Colors Status

Green: On Mains, Battery Charging

Red: On Battery, Mains Off


Warranty Card



Your MiniUPS comes with a standard 12 months express warranty. Please scan the QR code with your phone and follow the steps on at www.cuzorlabs.com/register

CUZOR MiniUPS

Documents / Resources

	cuzor MiniUPS 12V Mini UPS for WiFi Router [pdf] User Manual MiniUPS 12V Mini UPS for WiFi Router, 12V Mini UPS for WiFi Router, UPS for WiFi Router, Wi Fi Router
---	---

Manuals+.