

CXY T18 Multi Function Portable Car Jump Starter User Manual


[Home](#) » [CXY](#) » CXY T18 Multi Function Portable Car Jump Starter User Manual 



Contents

- [1 CXY T18 Multi Function Portable Car Jump Starter User Manual](#)
 - [1.1 T18](#)
- [2 Friendly Tips](#)
- [3 What's in the Box](#)
- [4 AT A GLANCE](#)
- [5 SPECIFICATIONS](#)
- [6 HOW TO RECHARGE THE JUMP STARTER](#)
- [7 HOW TO JUMP START A CAR](#)
- [8 CHARGE VARIOUS DIGITAL DEVICES WITH T18](#)
- [9 LED FLASHLIGHT](#)
- [10 ATTENTION](#)
- [11 CUSTOMER SERVICE](#)
- [12 Documents / Resources](#)
 - [12.1 References](#)

CXY T18 Multi Function Portable Car Jump Starter User Manual



T18


Friendly Tips

Please carefully read the instruction manual and use product correctly based on the instruction manual so that you can be familiar with the product more conveniently and quickly! Please keep the user manual for future reference.

What's in the Box

- CXY T18 Jump Starter x 1
- Battery clamps with starter cable x1
- High quality USB-A to USB-C cable x1
- Jump starter carry case x1
- User manual x1

AT A GLANCE



① **Power Button**

Netzschalter | Bouton d'alimentation | Pulsante di accensione | Botón de | encendido
電源ボタン

② **Jump Button**

Sprungtaste | Bouton de saut | Pulsante di salto | Botón de salto | ジャンプボタン

③ **Jumping port**

Jumping-Port | Port de saut | Porta di salto | Puerto de salto | ジャンピングポート

④ **USB C input: PD 18W**

USB-C Eingang: PD 18W | entrée USB C : PD 18W | ingresso USB C: PD 18W | entrada
USB C: PD 18W | USBC入力: PD 18W

⑤ **USB output: QC 3.0**

USB-Ausgang: QC 3.0 | Sortie USB: QC 3.0 | Uscita USB: QC 3.0 | Salida USB: QC 3.0 |
USB出力: QC 3.0

⑥ **USB output: 5V/2.4A**

DC-Ausgang: 5V/2.4A | Sortie DC : 5V/2.4A | Uscita DC: 5V/2.4A | Salida de DC: 5V/2.4A
DC出力: 5V/2.4A

⑦ **LED Light**

LED-Licht | Lumière LED | Luce LED | Luz LED | LEDライト

SPECIFICATIONS

Capacity Kapazität Capacité Capacità Capacidad 容量	12800mah / 47.36wh
Weight Gewicht Lester Il peso Peso 重さ	680g / 23.98oz
Size Größe Taille Dimensione Tamaño サイズ	204*93.5*64mm 8.03*3.7*2.5in
USB-C Input USB-C-Eingang Entrée USB-C Ingresso USB-C Entrada USB-C USB-C入力	5V/2A 9V/2A (PD 18W)

USB-C Output USB-C-Ausgang Sortie USB-C Uscita USB-C Salida USB-C USB-C出力	5V/3A (QC3.0)
USB Output USB-Ausgang Sortie USB Uscita USB Salida USB USB出力	5V/2.4A
Starting Current Anlaufstrom Courant de démarrage Corrente di partenza Corriente de arranque 開始電流	400A
Peak Current Spitzenstrom Courant de crête Corrente di picco Corriente pico ピーク電流	1000A

HOW TO RECHARGE THE JUMP STARTER

2 ways to recharge the Jump starter:

1. Use a USB-C charger adapter and the USB-C cable we provided to recharge the jump starter via the USB-C port. Support PD 60W fast charging (60W PD charger adapter required)
2. Use 5521 connector chargers (5521 DC car charger, 5521 laptop charger, 5521 AC to DC adapter charger) to recharge the jump starter via the 5521 DC port.

PLEASE BE NOTED:

- This product is designed for vehicles with 12V battery only. Do not attempt to jump start vehicles with a higher battery rating, or different voltage.
- If the vehicle isn't started immediately, please wait for 1 minute to allow the jump starter to cool down before next attempt. Do not try to restart the vehicle after three consecutive attempts as this may damage the unit. Check your vehicle for other possible reasons why it can't be restarted.
- If your vehicle battery is dead or its battery voltage is under 2V, it's unable to activate the jump cable and your vehicle will not be started.

HOW TO JUMP START A CAR

1. Switch on your jump starter and make sure it's over 25% charged.
2. Insert jumper cable into jumping port.
3. Connect red clamp to positive(+) terminal and black clamp to negative(-) terminal of the car battery.
4. Press the Jump button for 3 seconds.

FIG 6 HOW TO JUMP START A CAR.JPG

- Display screen shows Orange "READY" means the jump starter and clamps are at standby mode.
- Display screen shows Green "READY" means it's all ready to start your car.
- Display screen shows "RC" means the clamps and car battery negative and positive poles are connected reversely. Please connect them correctly and try again.
- Display screen shows "LV" means low voltage, please recharge the jump starter then try again.
- Display screen shows "HT" means clamps over heat, please wait for several minutes to cool down then try again.
- Display screen flicker "188" means the jump starter over heat, please wait for several minutes to cool down then try again.

FIG 7 HOW TO JUMP START A CAR.JPG

CHARGE VARIOUS DIGITAL DEVICES WITH T18

This product has 3 output ports for multiple charging demands. Such as cellphone, tablet, iPad, laptop, PSP, gamepad, car vacuum cleaner (with the provided cigarette lighter converter) and more.

1. USB-C PORT: PD 1 SW MAX
2. USB-A PORT: QC 3.0 MAX
3. USB-A PORT: SV / 2.4A

LED FLASHLIGHT

FIG 9 LED FLASHLIGHT.JPG

Long press the power button for 3 seconds to turn on I turn off the flashlight. Quick press the power button to switch 3 flashlight modes.

ATTENTION

- To preserve battery lifespan, use and recharge It at least once every 6 months.
- Must use our standard jump cable to jump start your car.
- DO NOT recharge the jump starter immediately after starting your car.
- Avoid dropping
- DO NOT heat the product or use It near fire.
- DO NOT put It into water or disassemble the product.

CUSTOMER SERVICE



24-months warranty | 24 Monate Garantie | Garantie 24 mois
24 mesi di garanzia | 24 meses de garantía | 24ヶ月保証



Lifetime technical support
Lebenslanger technischer Support | Assistance technique à vie
Supporto tecnico a vita | Soporte técnico de por vida
生涯テクニカルサポート

EC	REP
----	-----

eVatmaster Consulting GmbH
Bettinastr. 30, 60325 Frankfurt am Main, Germany
contact@evatmaster.com

UK	REP
----	-----

EVATOST CONSULTING LTD
Suite 11, First Floor, Moy Road Business Centre, Taffs
Well, Cardiff, Wales, CF15 7QR contact@evatmaster.com


E-mail: cxyeuvc@outlook.com



MADE IN CHINA

Read More About This Manual & Download PDF:

Documents / Resources

	CXY T18 Multi Function Portable Car Jump Starter [pdf] User Manual T18 Multi Function Portable Car Jump Starter, T18, Multi Function Portable Car Jump Starter, Function Portable Car Jump Starter, Portable Car Jump Starter, Car Jump Starter, Jump Starter, Starter
---	---

References

- [User Manual](#)