

# Cybertruck Front Trunk L-Track Plus Cargo Net Instructions

[Home](#) » [Cybertruck](#) » Cybertruck Front Trunk L-Track Plus Cargo Net Instructions 




Contents

1 What's Included


2 Documents / Resources

2.1 References


## What's Included



Use a flathead screwdriver to unclip the plastic bolt covers (2x)




Use a 10mm socket to remove the exposed bolts (4x). Install the L-track brackets (B & C) using the same bolts.



# Cybertruck

## Documents / Resources

 Cybertruck Front Trunk L-Track Plus Cargo Net	<a href="#">Cybertruck Front Trunk L-Track Plus Cargo Net</a> [pdf] Instructions Front Trunk L-Track Plus Cargo Net, Trunk L-Track Plus Cargo Net, L-Track Plus Cargo Net, Plus Cargo Net, Cargo Net, Net
---	--

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.