



cybex B0524 Priam
Jeremy Scott Wings



cybex B0524 Priam Jeremy Scott Wings Instruction Manual

[Home](#) » [CYBEX](#) » cybex B0524 Priam Jeremy Scott Wings Instruction Manual 

Contents

- [1 cybex B0524 Priam Jeremy Scott Wings](#)
- [2 SAFETY INSTRUCTIONS](#)
- [3 MAINTENANCE AND CLEANING](#)
- [4 WARRANTY](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)



cybex B0524 Priam Jeremy Scott Wings



WARNING

- Failure to follow all warnings and instructions may result in serious injury or death.
- For your child's safety, read this owner's manual and all labels before using the product.
- KEEP OWNER'S MANUAL FOR FUTURE REFERENCE.
- ADULT ASSEMBLY REQUIRED.
- Take care when unpacking and assembling; contains small parts and some items with sharp edges.
- Follow all instructions carefully.
- Incorrect use will damage the stroller.
- NEVER LEAVE CHILD UNATTENDED.
- Always keep the child in view while in or around the stroller.
- AVOID SERIOUS INJURY from falling or sliding out.
- Always use complete five point safety harness.
- After fastening buckles, adjust belts for a snug fit around your child.
- Child may slip into leg openings and strangle.
- NEVER use in reclined carriage positions unless child is secured in 5-point harness system.
- The brake must be locked while taking the child in and out of the stroller, and when parked.
- AVOID FINGER ENTRAPMENT.
- Take extra care and keep child clear of stroller when folding and unfolding the stroller.
- Make sure the stroller is fully opened and locked into position before allowing your child near the stroller.
- Audible click must be heard to confirm that all locks are properly engaged.
- Also verify visually that the locks are properly engaged.
- The maximum weight of the child in the seat is 50 lbs (22.7 kg).
- The accessory seat has the same maximum weight limit of 50 lbs (22.7 kg).
- The maximum weight of the child in the seat on lower adapter rearward-facing is 35 lbs (15.9 kg).
- The maximum size of the child should not be greater than 41 in (104 cm).

- The maximum weight in the shopping basket is 30 lbs (13.6 kg).
- The maximum weight in the shopping basket attachment is 25 lbs (11.3 kg).
- The maximum load for the Cup Holder is 1.1 lbs (0.5 kg).
- The maximum weight in the stroller (seat units AND shopping basket AND cup holder) should not exceed 131.1 lbs (59.5 kg).
- Exceeding these figures will cause excessive wear and stress on the stroller.
- This stroller is intended to be used with one child per seat only.
- TO PREVENT A HAZARDOUS, UNSTABLE CONDITION, never place purses, shopping bags, parcels or accessory items on the canopy or handle.
- DO NOT CARRY additional children, goods or accessories in or on this stroller.
- They may cause the stroller to become unstable and tip over, or could lead to breakage.
- Do not attempt to attach any infant car seat to the stroller other than CYBEX infant car seats or seats that have been approved by CYBEX.
- DO NOT place hot liquids in cup holder.
- Spills can burn you or your child.
- DO NOT LIFT STROLLER with child in it.
- NEVER USE THE STROLLER ON STAIRS OR ESCALATORS with child in it as you may suddenly lose control of the stroller or your child may fall out.
- MANEUVER CAREFULLY OVER CURBS and gravel roads and uneven surfaces and never use stroller for anything other than transporting your child.
- Repeated impact will damage stroller.
- NEVER leave stroller on a hill or incline, even with brakes set.
Stroller may tip, injuring the child.
- Stroller may tip, injuring the child.
- To avoid serious injury from child falling out of stroller, DO NOT raise or recline seat with child in stroller.

AVOID STRANGULATION

- DO NOT suspend strings or toys from the canopy.
- DO NOT place stroller anywhere near cords from window blinds, draperies, phone, etc.
- DO NOT place items with a string around your child's neck such as hood strings or pacifier cords.
- STROLLER TO BE USED ONLY at walking speed.
- Faster strolling, can cause a loss of control and injury to the child.
- When making adjustments to the stroller, ALWAYS ensure that all parts of the child's body are clear of any moving parts of the stroller.
- This stroller is not intended for use while jogging, running, skating, etc.
- DO NOT LEAVE stroller in direct sunlight to avoid potential fading.
- NEVER ALLOW stroller to be used as a toy.
- DISCONTINUE USE OF STROLLER should any parts become damaged or broken.
- Do not use accessories, spare parts, or any component not supplied or approved by CYBEX as they may make the stroller unsafe.
- NEVER use or attach any additional child platform (kid board).
- ALWAYS activate the brake whenever you park the stroller and before you place or take your child out of the stroller.

SAFETY RULES

- Always make sure to use the correct adapter-position for each configuration (see overview in use instruction).
- Always use position when using only one attachment.
- Always remove upper attachment first when using two attachments.
- Always use the highest handle position when using an infant car seat in position or .
- Never use a configuration which is not illustrated (see use instruction).
- Avoid placing the product with activated e-system in an external magnetic field.
- Never use the stroller with weight in the upper seat position only.

SAFETY INSTRUCTIONS

- Do not attach any load (excluding the Cup Holder) to the handle and/or on the back of the backrest and/or on the sides of the stroller and/or any other part as this will affect the stability of the stroller.
- Only use approved accessories.
- Use only original replacement parts.
- Always empty the stroller basket prior folding.
- The components (especially the battery) can become damaged through extreme temperature.
- Never charge the battery unattended.
- While charging, the battery and the charger may become hot.
- Be aware of the risks presented by an open fire and other heat sources such as electrical heaters, gas flames etc. especially if they are in the immediate vicinity of the stroller & battery.

MAINTENANCE AND CLEANING

- The user is responsible for regular maintenance and care.
- It is particularly important to ensure that all moving parts and mechanisms are treated regularly with dry lubricant.
- After treatment wipe the product with a soft cloth.
- Clean the frame with a soft damp cloth and mild detergent, wiping away any excess water with a dry cloth.
- Please always check the care label before washing.
- Please contact our Customer Service team at ParentLink.
- Battery & stroller is rated as IP65 which makes it dust tight and resistant against water jets from any direction.

WARRANTY

- The following warranty applies solely in the country where this product was initially sold by a retailer to a customer.
- The warranty covers all manufacturing and material defects, existing and appearing, at the date of purchase or appearing within a term of two (2) years from the date of purchase from the retailer who initially sold the product to a consumer (manufacturer's warranty).
- Please check the product with respect to completeness and manufacturing or material defects immediately at the date of purchase or immediately after receipt.

- Please always keep your dated proof of purchase.
- In case of a defect, stop using the product immediately.
- To make a warranty claim or if you have any warranty questions please contact CYBEX Customer Service at ParentLink.
- You may need to provide original proof of purchase (sales receipt or invoice).
- The battery warranty covers workmanship and material defects within a term of one (1) year from the date of purchase from the retailer who initially sold the product to a consumer (manufacturer's warranty).
- Please do not take or ship the product to the manufacturer or retailer directly.
- This warranty does not cover any damages which result from misuse, environmental influence (water, fire, accidents etc.), normal wear and tear or failure to comply with the instructions provided in this user manual.
- The warranty does not apply if modifications and services were performed by unauthorized persons or if non-original components and accessories were used.
- This warranty does not affect any statutory consumer rights, including claims in tort and claims with respect to a breach of contract, which the buyer may have against the seller or the manufacturer of the product.
- The warranty is not transferable to anyone who obtains possession or ownership other than the original purchaser.



DISPOSAL

In order to protect the environment, please observe the waste disposal regulations in your country and properly dispose of your product.

To protect the environment we ask the user to separate and dispose the waste arising at the start (packaging) and the end (product parts) of the stroller lifespan.

- Frequency band 2.402 -2.480GHz, 0.6mW
- Maximum output power of the transmitter 1.24 mW
- Battery Pack: Lithium-Ion, Nominal 36V dc,
- Max charging 42V dc, 2600 mAh



AMERICAS

Columbus Trading-Partners USA Inc.
12915 Whitehall Park Drive, Suite 300 | Charlotte, NC 28273, USA
Customer Service: 1-[877-242-5676](tel:877-242-5676) | info.us@cybex-online.com

CANADA

Goodbaby Canada Inc.
2 Robert Speck Parkway, Suite 750 | Mississauga, ON L4Z 1H8
Customer Service: 1-[877-242-5676](tel:877-242-5676) | info.us@cybex-online.com
www.cybex-online.com

Documents / Resources

	cybex B0524 Priam Jeremy Scott Wings [pdf] Instruction Manual CY_172_1060_B0524, B0524 Priam Jeremy Scott Wings, B0524, Priam Jeremy Scott Wings, J eremy Scott Wings, Scott Wings, Wings
---	---

References

- [CYBEX Online | Discover Strollers & Car Seats Online](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.