



CYBEX Eezy S Twist 2 Stroller Instructions

[Home](#) » [CYBEX](#) » CYBEX Eezy S Twist 2 Stroller Instructions

Contents [[hide](#)]

- [1 CYBEX Eezy S Twist 2 Stroller](#)
- [2 SAFETY INSTRUCTIONS](#)
- [3 MAINTENANCE AND CLEANING](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)



CYBEX Eezy S Twist 2 Stroller



WARNING

- Never leave the child unattended
- Ensure that all the locking devices are engaged before use.
- To avoid injury ensure that the child is kept away when unfolding and folding this product
- Do not let the child play with this product
- Always use the restraint system
- Check that the pram body or seat unit or car seat attachment devices are correctly engaged before use
- This product is not suitable for running or skating
- Use a harness as soon as the child can sit unaided

SAFETY INSTRUCTIONS

Do not attach any load (excluding the Cup Holder) to the handle and/or on the back of the backrest and/or on the sides of the stroller and/or any other part as this will affect the stability of the stroller.

- Always use the most reclined position for new born babies.
- Never ascend or descend stairs or escalators with the child inside or when using other means of transportation.
- Take special care when going up or down a curb or when you maneuver on other uneven surfaces.
- This stroller does not replace a cot or a bed.
- This product is intended only for use with one child.
- Always activate the brake before you place or take your child out of the stroller.
- Regularly inspect the stroller for any signs of wear or damaged parts and refer to the Maintenance and Cleaning instructions.
- Only use approved accessories.

- Do not use if any part of the product is broken, torn or missing.
- Use only original replacement parts.
- It may be unsafe to use substitutes.

MAINTENANCE AND CLEANING


- The user is responsible for regular maintenance and care.
- It is particularly important to ensure that all moving parts and mechanisms are treated regularly with dry lubricant.
- After treatment wipe the product with a soft cloth.
- Clean the frame with a soft damp cloth and mild detergent, wiping away any excess water with a dry cloth.
- It is important that brakes, wheels and tires are not impaired during use.
- Inspect and clean them regularly and repair or replace if necessary. Should the stroller be exposed to salt water, please rinse the EN frame with clean damp cloth as soon as possible afterwards.
- Please always check the care label before washing.
- Do not tumble dry, do not iron or dry clean, do not expose to direct sunlight when drying.
- If the product is wet, leave it unfolded and allow all parts to dry completely to prevent mold.
- Never store in a damp environment.
- We recommend to use a rain cover in wet weather.
- Do not make any modifications to the product.
- If you have any complaints or problems, please contact your supplier.
- A service should be scheduled every 24 months.

MANUFACTURER'S WARRANTY AND DISPOSAL REGULATIONS

CYBEX GmbH (Riedingerstr. 18, 95448 Bayreuth, Germany gives you 2 years warranty on this product.

- The warranty is valid in the country, where this product was initially sold by a retailer to a customer.
- The contents of the warranty and all essential information required for the assertion of the warranty can be found on our homepage <https://qr.cybex-online.com/>manufacturerwarranty wheel goods.
- If a warranty is shown in the article description, your legal rights against us for defects remain unaffected.
- Please observe the waste disposal regulations in your country.

Documents / Resources

	<p>CYBEX Eezy S Twist 2 Stroller [pdf] Instructions CY 171, Eezy S Twist 2, Stroller, Eezy S Twist 2 Stroller</p>
---	--

References

- qr.cybex-online.com/manufacturer-warranty-wheelgoods
- [CYBEX Online Shop | Child Car Seats, Strollers, Baby Carriers and Furniture from CYBEX](#)

