


**Hip Anchor
Harness
Locking**



cybex Hip Anchor Harness Locking Instruction Manual

[Home](#) » [CYBEX](#) » cybex Hip Anchor Harness Locking Instruction Manual 

Contents

- 1 [cybex Hip Anchor Harness Locking](#)
- 2 [Specifications](#)
- 3 [Product Usage Instructions](#)
- 4 [FAQ](#)
- 5 [Documents / Resources](#)
 - 5.1 [References](#)



cybex Hip Anchor Harness Locking



Specifications

- **Color:** Black
- **Material:** High-quality plastic

- **Dimensions:** 10 inches x 5 inches x 3 inches

Product Usage Instructions

ATTN: Do not assemble parts until after you have read entire set of instructions, parts cannot be separated once connected. Pictures in these instructions are in white for demonstration, actual parts are black

Steps

1. Remove two sets of Part A and Part B from envelope. An extra set is included.



2. Undo chest clip, crotch buckle and remove infant insert if present. Pull coverset back on both sides starting at the bottom.



3. Locate where the hip anchor harness comes through the shell on one side.



4. Insert Part A through the loop in the anchor harness. Start from rear of seat and insert toward front of seat.




5. Slide long tab of Part A into the Connection Point on Part B



Note: Tabs should be pointing up on both parts




6. Lock the two pieces securely, pushing them together as far as possible. You will hear a clicking sound as parts engage.



7. Push down on Part B and Pull the end of Part A to tighten the parts as much as possible. Make sure that both tabs are tightly pressed against the anchor harness.

Note: To ensure proper engagement try pulling Part A and Part B apart, they should be fully locked together. Repeat Steps 4-7 on other side



8. Once you have completed this process on both left and right hip anchors, turn seat over and verify that metal pin on both sides is fully inserted in harness strap, as shown in picture on right. If pin is not fully inserted, please insert and repeat step 7. Once verified please replace coverset.



For questions or additional support, please contact Cybex at 1-[877-242-5676](tel:877-242-5676)

Scan QR Above for Instructional Video




FAQ

Q: Can the parts be disassembled once connected?

A: No, parts cannot be separated once connected. It is important to follow the assembly instructions carefully.

Documents / Resources

	<p>cybex Hip Anchor Harness Locking [pdf] Instruction Manual Hip Anchor Harness Locking, Anchor Harness Locking, Harness Locking, Locking</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.