

**CYCPLUS
AS2 Pro
Bicycle Tire
Inflator**



CYCPLUS AS2 Pro Bicycle Tire Inflator user manual

[Home](#) » [CYCPLUS](#) » CYCPLUS AS2 Pro Bicycle Tire Inflator user manual 

Contents

- [1 CYCPLUS AS2 Pro Bicycle Tire Inflator](#)
- [2 FAQs](#)
- [3 Packing List](#)
- [4 OVERVIEW](#)
- [5 Air Nozzle Adaptation](#)
- [6 Operation](#)
- [7 Charge](#)
- [8 Specifications](#)
- [9 Factory Info](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)

CYCPLUS

CYCPLUS AS2 Pro Bicycle Tire Inflator




FAQs

- **Q: How should I charge the inflator?**
 - A: Charge it with a suitable charger. The battery indicator lights will show the charging progress, with all lights illuminated when fully charged.
- **Q: What should I do if the valves are at risk of melting?**
 - A: For TPU inner tubes with resin valves, always use an extension air hose to prevent overheating and potential valve damage.
- **Q: How do I switch between Presta and Schrader valves?**
 - A: Adjust the nozzle mode accordingly for each valve type. For Presta valves, remove the pillar; for Schrader valves, install the pillar.


Warning

For TPU inner tubes with resin valves, be sure to connect them with an extension air hose, or the valves may melt due to overheating.


Packing List



OVERVIEW



Air Nozzle Adaptation




The inflator is ready for the Presta valve right out of the box. For the Schrader valve, please adjust the nozzle accordingly. The hose can be directly connected and used, regardless of the presence of a pillar in the nozzle. When the target air pressure is above 100 PSI, please use with the hose to prevent air leakage from the nozzle.

Operation

1. Connect the air valve


- **A. Connect the nozzle directly to the valve**
 - Adjust the nozzle mode and connect it to the valve. Keep a tight grip on the nozzle while inflating.



Note:
Always loosen
the nut first.


- **B. Use the hose**

- Hold the hose and the suitable adapter, then connect it to the valve. it's recommended to use the hose when using the Schrader valve.



2. Power on and set target air pressure

- Long-press the Power button to power on, and the screen illuminates, showing the real-time air pressure reading.




3. Inflating

- Press the Power Button to start inflation. It will auto shut off when the target air pressure is reached.

④ Shut down

Long-press the **Power Button** to power off. If the air pump is not started and there is no operation within 1 minute while it is powered on, the air pump will automatically shut down.




Notes

1. Fully charge the inflator before use.
2. The inflator may get hot during operation, and please use it with the silicone case.
3. Press the inflator against the valve before and during inflation, and adjust the position to prevent air leakage.
4. It is normal to feel a sense of traction when pulling the inflator off a presta valve after inflation.

Charge

Charge it with a suitable charger. While charging, the screen battery indicator light illuminates and flashes incrementally. Once the battery is fully charged, all the battery indicator lights will be illuminated.



Specifications


- Size: 70*49*28 mm
- Weight: 120g
- Battery: 420mAh 7.4V 3.11Wh
- Charging Port: Type-C 5V 1.5A
- Current: 2.5~7.5 A
- Max Pressure: 120 PSI

Factory Info

- **Manufacturer:**
 - Chengdu Chendian Intelligent Technology Co., Ltd
- **Warranty:**
 - Free repair or replacement within one year after purchase.

- After-sales email:
 - steven@cycplus.com
 - Points de collecte sur www.quefairedemesdechets.fr

Documents / Resources

 <p> CYCPLUS AS2 Pro Bicycle Tire Inflator </p> <p> User manual [01 - 04] 用戶手冊 [05 - 08] Benutzerhandbuch [09 - 12] Manuel de l'utilisateur [13 - 16] Manual de usuario [17 - 20] Manuale d'uso [21 - 24] 取扱説明書 [25 - 28] After-sales email: steven@cycplus.com </p>	<p> CYCPLUS E0N1 Bicycle Tire Inflator [pdf] User Manual E0N1, E0N2, E0N1 Bicycle Tire Inflator, E0N1, Bicycle Tire Inflator, Tire Inflator, Inflator </p>
--	---

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.