



CZUR TouchBoard V1 Wireless Bluetooth Touchpad Keyboard User Manual

[Home](#) » [CZUR](#) » CZUR TouchBoard V1 Wireless Bluetooth Touchpad Keyboard User Manual 

Contents

- [1 CZUR TouchBoard V1 Wireless Bluetooth Touchpad Keyboard](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 How to Use the TouchBoard](#)
- [5 Touchpad standby and sleep](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)



CZUR TouchBoard V1 Wireless Bluetooth Touchpad Keyboard



Product Information

The Touchboard V1 is a versatile input device that can be used with the StarryHub. It has two modes: Touch mode and Board mode. In Touch mode, you can use finger touch gestures to operate the StarryHub, such as sliding, tapping, zooming, and more. In Board mode, the Touchboard functions as a keyboard for inputting text.

Specifications

- Power On: Press and hold the Touch/Board button for 5 seconds until the indicator blinks in blue.
- Pairing: Place the TouchBoard back on the charging dock and wait for 10 seconds until the icons on the first row light up.
- Input Modes: Touch mode and Board mode.
- Low Battery Indicator: The LED indicator turns red when the battery is low.

Product Usage Instructions

Using Touch Mode

In Touch mode, you can use various finger touch gestures to operate the StarryHub:

- Slide: Use one finger to slide across the TouchBoard.
- Tap: Use one finger to tap on the TouchBoard.
- Slide with 2 fingers: Use two fingers to slide across the TouchBoard.
- Zoom in/out with 2 fingers: Pinch or spread two fingers on the TouchBoard to zoom in or out.
- Tap with one finger then slide: Tap with one finger and then slide to drag a target.
- Tap with 3 fingers: Tap with three fingers to pop up more operation options.
- Double-click with one finger then slide: Double-click with one finger and then slide for a specific action.
- Click with 3 fingers: Click with three fingers for a specific action.
- En or Shift + Space bar: Use these keys to switch the input language.

Using Board Mode

In Board mode, the TouchBoard functions as a keyboard for inputting text. The keyboard will light up, allowing you to type on the TouchBoard.

Note: When the battery of the TouchBoard is low, the LED indicator on the upper right will turn red. Please place the TouchBoard back on the charging dock (the 3 pins on the top of StarryHub) to recharge.

FAQ

Q: How do I switch between Touch mode and Board mode?

A: To switch between Touch mode and Board mode, simply press and hold the Touch/Board button for 5 seconds until the indicator blinks in blue.

Q: How do I know if the battery of the TouchBoard is low?

A: The LED indicator on the upper right of the TouchBoard will turn red when the battery is low.

Q: Can I use multiple fingers for gestures in Touch mode?

A: Yes, you can use multiple fingers for gestures in Touch mode. For example, you can slide with 2 fingers or tap with 3 fingers for specific actions.

Q: How do I recharge the TouchBoard?

A: To recharge the TouchBoard, simply place it back on the charging dock, which is located on the top of the StarryHub. Wait for the battery to recharge before using the TouchBoard again.

How to Use the TouchBoard

TouchBoard acts as a wireless controller to the StarryHub.
You can operate StarryHub with the TouchBoard easily.

Before using the TouchBoard, please turn the power button (on the back of the TouchBoard) to ON status. Put the TouchBoard back to charging dock (on the top of StarryHub) after each use.




Pair the TouchBoard with the StarryHub


TouchBoard and the StarryHub are paired by factory default.


1. Power on StarryHub and the TouchBoard.


Main unit power on




TouchBoard power on



2. Long press the Touch/Board  for 5 seconds until the indicator on the upper right corner blinks in blue color.




- Put the TouchBoard back to the charging dock, wait for 10 seconds until the icons on the first row of the TouchBoard light up. Pairing is completed.




Touch/Board

Tap on Touch/Board to switch input method (touch panel or keyboard).






Volume adjustment

Tap on V- V+ to adjust volume of the StarryHub.





Auto-focus

- Tap on  to focus the projector lens automatically. Long press  to use manual focus.
- If Auto-focus function is set (from StarryHub Settings page), when moving StarryHub, auto-focus will start immediately until StarryHub stops moving.




Switch signal source

Tap on  to switch projection screen source: StarryHub, HDMI or Wireless Screen Casting.





Back

Tap to get back to previous page or previous operation.



Finger touch

- In Touch mode  , you can use finger touch to operate StarryHub e.g. slide, tap, slide with 2 fingers, zoom in/out with 2 fingers.
- Tap with one finger then slide: drag target.
- Tap with 3 fingers: to pop up more operation options.



Slide



Slide with 2 fingers



Zoom with 2 fingers



Double-click with one finger then slide




Click with 3 fingers

* ⇌En or Shift + Space bar switch the input language.

Keyboard

In Board mode Board ⇌ Touch, keyboard will light up so you can use the TouchBoard as an input method.



Low battery status

The LED indicator on the upper right will turn red when the battery of the TouchBoard is low. Please put the TouchBoard back to the charging dock (the 3 pins on the top of StarryHub) to recharge.

Touchpad standby and sleep

- Touch pad standby: Touch mode has no operation for 5 minutes then will enters standby mode automatically. Keyboard mode without operation for 1 minute, will enter touch mode; Touch mode for 5 minutes without operation, will enter standby mode.
- Standby definition: Only the power indicator light is on, and the backlight lights in the functional area and keyboard area are off.
- Touchpad enters standby wake-up mode: Use any key to wake up the touchpad.
- Touchpad Sleep: Bluetooth connected for 24 hours without any operation, will enter sleep mode automatically. Bluetooth not connected for 30 minutes without any operation,will enter sleep automatically.
- Sleep definition:All indicator lights are off, and the device enters deep sleep.
- The touchpad enters sleep mode, and the wake-up method is: Place the touchpad in the charging area of the projector, and the touchpad will automatically wake up, or turn off the power switch and then turn it on again.

Documents / Resources

 Touchboard V1 User manual	CZUR TouchBoard V1 Wireless Bluetooth Touchpad Keyboard [pdf] User Manual TouchBoard V1, TouchBoard V1 Wireless Bluetooth Touchpad Keyboard, Wireless Bluetooth T ouchpad Keyboard, Bluetooth Touchpad Keyboard, Touchpad Keyboard, Keyboard
--	---

References

- [User Manual](#)